

## INDEX

### INTRODUCTION

I - HEAD IDENTIFICATION	Pag. 5
II - TECHNICAL DATA OF CLASS	" 5
III - TECHNICAL DATA OF SUB-CLASSES	" 6

### INSTRUCTIONS

I - INSTALLATION AND SETTING UP	Pag. 11
a - Positioning of head	" 11
b - Transmission assembly	" 11
c - Lubrication	" 11
d - Assembling and Adjusting Sewing Parts	" 11
e - Adjusting and locking presserfoot arm	" 16
f - Setting front cover plate	" 16
g - Needle thread take-up adjustment	" 16
h - Electric lubrication control device	" 17
II - USE	" 19
a - Threading	" 19
b - Changing the needle	" 23
c - Setting the presserfoot	" 23
d - Setting of tensioning discs	" 23
e - Stitch length adjustment	" 23
f - Seam width adjustment	" 23
g - Problems due to improper handling of machine	" 24
III - MAINTENANCE	" 25
a - Every day	" 25
b - Every week	" 25
c - Every three months	" 25
d - Sharpening the knives	" 25

### SPARE PARTS CATALOGUE

I - HOW TO USE THIS CATALOGUE	" 29
a - Introduction	" 29
II - HOW TO ORDER	" 29
a - All parts	" 29
b - Needles	" 29
III - TABLES	" 31
IV - NUMERICAL INDEX OF PARTS	" 73

ХЭДЛҮҮЛГЭР

ИНСТРУКЦИОННЫЙ

- I - HEAD IDENTIFICATION
- II - TECHNICAL DATA OF CLASS
- III - TECHNICAL DATA OF SUB-CLASS

ИНСТРУКЦИОННЫЙ

- I - INSTRUCTION AND SETTING UP
  - a - Preparation of parts
  - b - Preparation of tools
  - c - Preparation of equipment
  - d - Assembly and adjustment of parts
  - e - Adjustment of tools
  - f - Adjustment of equipment
  - g - Preparation of materials
  - h - Preparation of components
  - i - Preparation of parts and tools
  - j - Preparation of components and tools
  - k - Preparation of parts and tools
  - l - Preparation of parts and tools
  - m - Preparation of parts and tools
  - n - Preparation of parts and tools
  - o - Preparation of parts and tools
  - p - Preparation of parts and tools
  - q - Preparation of parts and tools
  - r - Preparation of parts and tools
  - s - Preparation of parts and tools
  - t - Preparation of parts and tools
  - u - Preparation of parts and tools
  - v - Preparation of parts and tools
  - w - Preparation of parts and tools
  - x - Preparation of parts and tools
  - y - Preparation of parts and tools
  - z - Preparation of parts and tools
- II - USE
  - a - Preparation of parts
  - b - Preparation of tools
  - c - Preparation of equipment
  - d - Preparation of materials
  - e - Preparation of components
  - f - Preparation of parts and tools
  - g - Preparation of parts and tools
  - h - Preparation of parts and tools
  - i - Preparation of parts and tools
  - j - Preparation of parts and tools
  - k - Preparation of parts and tools
  - l - Preparation of parts and tools
  - m - Preparation of parts and tools
  - n - Preparation of parts and tools
  - o - Preparation of parts and tools
  - p - Preparation of parts and tools
  - q - Preparation of parts and tools
  - r - Preparation of parts and tools
  - s - Preparation of parts and tools
  - t - Preparation of parts and tools
  - u - Preparation of parts and tools
  - v - Preparation of parts and tools
  - w - Preparation of parts and tools
  - x - Preparation of parts and tools
  - y - Preparation of parts and tools
  - z - Preparation of parts and tools
- III - MAINTENANCE
  - a - Fuel gas
  - b - Fuel water
  - c - Fuel oil
  - d - Fuel water
  - e - Fuel oil
  - f - Fuel water
  - g - Fuel oil
  - h - Fuel water
  - i - Fuel oil
  - j - Fuel water
  - k - Fuel oil
  - l - Fuel water
  - m - Fuel oil
  - n - Fuel water
  - o - Fuel oil
  - p - Fuel water
  - q - Fuel oil
  - r - Fuel water
  - s - Fuel oil
  - t - Fuel water
  - u - Fuel oil
  - v - Fuel water
  - w - Fuel oil
  - x - Fuel water
  - y - Fuel oil
  - z - Fuel water

САНКТА-ПЕТЕРБУРГСКАЯ КАТАЛОГИЧЕСКАЯ

НОВЫЙ КОМПЛЕКСНЫЙ КАТАЛОГ

ПО ИНСТРУКЦИОННЫМ

ИЗДАНИЯМ НАУЧНО-ИССЛЕДОВАТЕЛЬСКОГО

Института Аэродинамики

III - TAGLES

VI - NUMERICAL INDEX OF PARTS

# **INTRODUCTION**



## I. HEAD IDENTIFICATION

CLASSIFICATION NUMBER	CLASS	SUB-CLASS	HEAD NUMBER	GASH
2320.0110382	1	1	1001	10-00-855
	1	1	1002	10-00-855
	1	1	1003	10-00-855
	1	1	1004	10-00-855
	1	1	1005	10-00-855
	1	1	1006	10-00-855
	1	1	1007	10-00-855
	1	1	1008	10-00-855
	1	1	1009	10-00-855
	1	1	1010	10-00-855
	1	1	1011	10-00-855
	1	1	1012	10-00-855
	1	1	1013	10-00-855
	1	1	1014	10-00-855
	1	1	1015	10-00-855
	1	1	1016	10-00-855
	1	1	1017	10-00-855
	1	1	1018	10-00-855
	1	1	1019	10-00-855
	1	1	1020	10-00-855
	1	1	1021	10-00-855
	1	1	1022	10-00-855
	1	1	1023	10-00-855
	1	1	1024	10-00-855
	1	1	1025	10-00-855
	1	1	1026	10-00-855
	1	1	1027	10-00-855
	1	1	1028	10-00-855
	1	1	1029	10-00-855
	1	1	1030	10-00-855
	1	1	1031	10-00-855
	1	1	1032	10-00-855
	1	1	1033	10-00-855
	1	1	1034	10-00-855
	1	1	1035	10-00-855
	1	1	1036	10-00-855
	1	1	1037	10-00-855
	1	1	1038	10-00-855
	1	1	1039	10-00-855
	1	1	1040	10-00-855
	1	1	1041	10-00-855
	1	1	1042	10-00-855
	1	1	1043	10-00-855
	1	1	1044	10-00-855
	1	1	1045	10-00-855
	1	1	1046	10-00-855
	1	1	1047	10-00-855
	1	1	1048	10-00-855
	1	1	1049	10-00-855
	1	1	1050	10-00-855
	1	1	1051	10-00-855
	1	1	1052	10-00-855
	1	1	1053	10-00-855
	1	1	1054	10-00-855
	1	1	1055	10-00-855
	1	1	1056	10-00-855
	1	1	1057	10-00-855
	1	1	1058	10-00-855
	1	1	1059	10-00-855
	1	1	1060	10-00-855
	1	1	1061	10-00-855
	1	1	1062	10-00-855
	1	1	1063	10-00-855
	1	1	1064	10-00-855
	1	1	1065	10-00-855
	1	1	1066	10-00-855
	1	1	1067	10-00-855
	1	1	1068	10-00-855
	1	1	1069	10-00-855
	1	1	1070	10-00-855
	1	1	1071	10-00-855
	1	1	1072	10-00-855
	1	1	1073	10-00-855
	1	1	1074	10-00-855
	1	1	1075	10-00-855
	1	1	1076	10-00-855
	1	1	1077	10-00-855
	1	1	1078	10-00-855
	1	1	1079	10-00-855
	1	1	1080	10-00-855
	1	1	1081	10-00-855
	1	1	1082	10-00-855
	1	1	1083	10-00-855
	1	1	1084	10-00-855
	1	1	1085	10-00-855
	1	1	1086	10-00-855
	1	1	1087	10-00-855
	1	1	1088	10-00-855
	1	1	1089	10-00-855
	1	1	1090	10-00-855
	1	1	1091	10-00-855
	1	1	1092	10-00-855
	1	1	1093	10-00-855
	1	1	1094	10-00-855
	1	1	1095	10-00-855
	1	1	1096	10-00-855
	1	1	1097	10-00-855
	1	1	1098	10-00-855
	1	1	1099	10-00-855
	1	1	1100	10-00-855
	1	1	1101	10-00-855
	1	1	1102	10-00-855
	1	1	1103	10-00-855
	1	1	1104	10-00-855
	1	1	1105	10-00-855
	1	1	1106	10-00-855
	1	1	1107	10-00-855
	1	1	1108	10-00-855
	1	1	1109	10-00-855
	1	1	1110	10-00-855
	1	1	1111	10-00-855
	1	1	1112	10-00-855
	1	1	1113	10-00-855
	1	1	1114	10-00-855
	1	1	1115	10-00-855
	1	1	1116	10-00-855
	1	1	1117	10-00-855
	1	1	1118	10-00-855
	1	1	1119	10-00-855
	1	1	1120	10-00-855
	1	1	1121	10-00-855
	1	1	1122	10-00-855
	1	1	1123	10-00-855
	1	1	1124	10-00-855
	1	1	1125	10-00-855
	1	1	1126	10-00-855
	1	1	1127	10-00-855
	1	1	1128	10-00-855
	1	1	1129	10-00-855
	1	1	1130	10-00-855
	1	1	1131	10-00-855
	1	1	1132	10-00-855
	1	1	1133	10-00-855
	1	1	1134	10-00-855
	1	1	1135	10-00-855
	1	1	1136	10-00-855
	1	1	1137	10-00-855
	1	1	1138	10-00-855
	1	1	1139	10-00-855
	1	1	1140	10-00-855
	1	1	1141	10-00-855
	1	1	1142	10-00-855
	1	1	1143	10-00-855
	1	1	1144	10-00-855
	1	1	1145	10-00-855
	1	1	1146	10-00-855
	1	1	1147	10-00-855
	1	1	1148	10-00-855
	1	1	1149	10-00-855
	1	1	1150	10-00-855
	1	1	1151	10-00-855
	1	1	1152	10-00-855
	1	1	1153	10-00-855
	1	1	1154	10-00-855
	1	1	1155	10-00-855
	1	1	1156	10-00-855
	1	1	1157	10-00-855
	1	1	1158	10-00-855
	1	1	1159	10-00-855
	1	1	1160	10-00-855
	1	1	1161	10-00-855
	1	1	1162	10-00-855
	1	1	1163	10-00-855
	1	1	1164	10-00-855
	1	1	1165	10-00-855
	1	1	1166	10-00-855
	1	1	1167	10-00-855
	1	1	1168	10-00-855
	1	1	1169	10-00-855
	1	1	1170	10-00-855
	1	1	1171	10-00-855
	1	1	1172	10-00-855
	1	1	1173	10-00-855

### III. TECHNICAL DATA BY SUB-CLASS

HEAD No.	TECHNICAL CHARACTERISTICS						SPECIFIC USES
	No. threads	Width of bight	Diff. pos.	S P E E D		Knives	
				No. of revs. 1" max.	St. per inch		
228-00-01	3	1/8" 15/64"		7000	8-30	si	ASSEMBLY SEAMING WITH OR WITHOUT CURLED IN EDGES For medium cut knit fabrics in wool, cotton, etc.
228-00-02	3	5/64" 9/64"		7000	8-30	si	For perfectly straight hanging seams on warpknit nylon fabrics etc.
228-00-03	3	5/64" 9/64"		7000	8-30	si	Same as 228-00-02 but with cutting device adjustable while the machine is in operation
228-00-04	3	1/8" 15/64"		6500	8-20	si	For medium and heavy fabrics, with a maximum presserfoot throw of 19 64" - maximum bight 15 64".
228-00-05	3	3/32" 5/32"		7000	8-30	si	Same as 228-00-01 but with a slightly narrower bight, for light cotton and woollen cut knit fabrics
228-00-06	3	3/64" 1/16"		6200	20-40	si	For closing the toes of nylon stockings
228-00-07	2	1/16" 5/64"		6200	20-40	si	For closing the toes of helanca and cotton socks
228-00-08	3	3/64" 1/16"		6200	14-40	si	For very light nylon warpknit fabrics, etc. (15 deniers), with very fine seam
228-00-11	3	5/64" 1/8"		7000	8-30	si	For very light and light woven fabrics (nylon, satin, very light flannel, etc.) with attachment to turn the fabric downwards into the seam.
228-00-12	3	3/32"		7000	8-30	si	For light woven fabrics, with attachment to turn the fabric upwards into the seam.
							ASSEMBLY SEAMING WITH OR WITHOUT CURLED IN EDGES, WITH ATTACHMENTS AND/OR INSERTIONS
228-01-01	3	1/8" 15/64"		7000	8-30	si	For medium cut knit fabrics in wool, cotton etc., with attachment for inserting a reinforcement tape into the seam
228-01-02	3	1/8" 15/64"		6500	8-20	si	For medium and heavy fabrics, with a maximum presserfoot throw of 19 64" - maximum bight 15 64". With attachment for inserting a reinforcement tape into the seam.
228-01-03	3	3/32" 5/32"		7000	8-30	si	Same as 228-01-01 but with a slightly narrower bight, for light cotton and woollen cut knit fabrics.

### III. TECHNICAL DATA BY SUB-CLASS

HEAD No.	TECHNICAL CHARACTERISTICS							SPECIFIC USES
	No. of threads	Width of bight	Diff. pos.	S P E E D		Knives	Sp. attach- ments on req.	
				No. of revs. 1" max.	St. per inch			
HEMMING								
228-10-01	3/2	5/64" 1/8"		7000	8-30	si	100 106 107	For welting knit fabrics in general with invisible seam on right side, with fixed hinged welting folder - with a blind looper to work also with 2 threads.
228-10-02	3/2	5/64" 1/8"		7000	8-30	si	100 106 107	With folder, throat plate, feed dog and presserfoot specially designed for welting along the non-stretchy direction of warp knit, jersey fabrics, etc. with invisible seam on right side, with a blind looper to work also with 2 threads
228-10-03	3/2	5/64" 1/8..		7000	8-30	si	100 106 107	Same as 228-10-02 but with welting folder moveable by means of knee-press, guaranteeing a regular hem even at cross-seams
228-10-05	3/2	5/64" 1/8"		7000	8-30	si	100 106 107	For welting of knit fabrics with invisible seam on right side, with swingout welting folder and with work plate cut out to accept preclosed sleeves, with blind looper to work also with 2 threads
228-10-06	3/2	5/64" 1/8"		7000	8-30	si	100 106 107	For welting of knit fabrics with invisible seam on right side, with blind looper to work also with 2 threads
228-10-07	3/2	5/64" 1/8"		7000	8-30	si	100 106 107	Same as 228-10-01 but with special work plate cut out to accept preclosed sleeves
OVEREDGING								
228-28-01	2	1.8" 15/64"		7000 6500	8-14 6-7	si	100 106 107 120 121 900 901 902	For serging and/or overedging light and medium woven and knit fabrics where the use of the differential is particularly requested.
228-28-02	3/2	1.8" 15/64"		7000 6500	8-14 6-7	si	100 106 107 120 121 900 901 902	Same as 228-28-01 but with looper to work also with three threads
228-28-07	3	3/32" 9/64"		6000	14-40	si	100 106 107	For serging and/or overedging headcovers, veils, scarves, etc. made from lightweight fabrics such as nylon, silk, japonette, etc. turning the edge of the fabric into the seam.



**INSTRUCTIONS : FOR**

- INSTALLATION AND TIMING**
- USE**
- MAINTENANCE**

КОНСИЛІУМ  
СВЯТИХ АПОСТОЛІВ ПІД  
ПІДПАДЧИСТІВІМ

## I. INSTALLATION AND SETTING-UP

### a) Positioning of head

After motor is mounted on stand, proceed as follows:

1. Push the four shock absorbing rubbers onto the appropriate head mounting plate pins.
2. Place the machine head on the table and center the lower head holes onto the shock absorbing pins.

### b) Transmission assembly

1. Fit the transmission belt as in fig. 1.
2. Make sure that back of driving belt rides firmly and squarely on pump pulley.
3. Take-up belt play by adjusting motor clamp.
4. Level the machine head by adjusting the nuts of the bolts which fix the plate to the table.
5. Tighten up the lock nuts on these bolts.




fig. 1

### c) Filling sump with lubricating oil

1. Unscrew cap A.
2. Pour in 1 3/4 pts. of VR. 604 oil (Esso Standard Teresso 43) (Bear in mind that the sump holds 2 pts.)
3. Check oil level. The oil visible through indicator glass G, should be between the two red lines.
4. Replace and tighten cap 'A'.
5. Put a few drops of oil on the needle clamp guide rod and upper looper bar before starting machine.
6. Run the machine free of work for about 5 minutes, progressively increasing the speed from 1500 r.p.m. to working speed.




fig. 2

### d) Assembly and adjustment of sewing parts

Note: The following operations serve to adjust the timing of the machine.

1. Timing gauges required:
  - S. 1665.00 for all operations except No. 4 (fig. 4)
  - S. 1555.00 for operation No. 4 (fig. 4).
2. Preliminary stripping off:
  - Front cover plate
  - The two thread take-ups of the lower looper holder
  - Plate holding thread tensioners
  - Upper plate with oil spy-glass
  - Side plate protecting needle movement
  - Front feed dog.

3. Positioning the needle (fig. 3).

- With the needle plate properly mounted the needle should be centered for passage through the appropriate hole in the throat plate.
- With the needle at top dead centre the distance between the tip of the needle and the work plate, should be  $25/64''$ .
- For 228-00-04 and its derivates, this distance should be  $3/8''$ .
- If adjustment of the needle clamp is necessary, loosen bolt A (fig. 3) and set distance with gauge S. 1665.00




fig. 3




fig. 4

4. Setting lower looper (fig. 4).

**Setting height**

- Loosen screw E.
- Firmly screw gauge S.1555.00 into the lower looper shaft.
- Adjust looper height so that its point coincides with the lower notch on the gauge. For 228-00-04 and its derivates, the looper point should coincide with the upper notch.
- Lightly lock looper with screw E.
- Set height of thread guide bracket 'A' by raising it to top of looper shank and lock by tightening up screw B.
- Remove gauge S. 1555.00.

**Adjusting angle**

- Slightly loosen screw D.
- Rest the gauge S.1665.00 on the milled base as in fig. 5; obtain correct inclination by moving lever C and by rotating the looper (previously having only been held in its seating and not locked).
- The exact position corresponds to that given in the setting tables.
- Firmly tighten screw E (fig. 4).

**Positioning the looper with respect to the needle fig.6.**

- With the looper hard to the left, check the figure given in the timing table.
- Move lever C up and down the shaft it rotates on. When moving from left to right the looper point should pass 0,2 mm. from the bottom of the needle groove.
- Firmly tighten screw D.




fig. 5

## 5. Setting upper looper.

Note: To obtain the figure of  $5/16'' - 23/64''$  in fig. 9 it is necessary to move lever E up or down, at the same time remembering that by doing this the distances in figs. 7 and 8 will increase or decrease.

- Slightly loosen screw B.
- Slightly loosen screw A.
- Adjust the crossing of the upper and lower loopers by rotating the upper until its point grazes the back of the lower.
- Check the settings shown in fig. 7-8-9 (setting table). The upper looper should graze the needle when passing from left to right.
- Should this condition not exist, slightly loosen screw D and push the whole assembly towards the interior or exterior of the machine without altering the settings previously obtained. Ensure perfect kinematic motion.
- Tighten screw D.
- Re-check the crossing of the two loopers and all the other settings.
- Tighten screws A and B.
- To finish off, make sure that all assemblies move freely.




fig. 6




fig. 7

## 6. Attaching needle guards (fig. 10).

- Attach front needle guard A.
- With the needle at its lowest point, adjust the front needle guard so that the lower looper point grazes the needle.
- Tighten screw C.
- Attach rear needle guard B and adjust until close to the needle, still in the low position.
- Tighten screw D.




fig. 8




fig. 9

- It must be checked that the needle will not get broken during operation due to any bending causing it to hit the lower looper. To do this, bend the needle towards the interior of the machine and ensure that the looper, when passing from left to right, touches the needle, without breaking it.
- Thread the needle, then bring it right down and gently push it against rear needle guard B.
- The thread should run freely. If it does not it means that the needle is too low and the thread is being caught between the needle and the needle guard.

Note: The looper point should pass through the lower part of the groove on its right hand run, and through the upper part on its left hand run.

- For hard synthetic materials, make the needle bend more against the needle guard.




fig. 10

## 7. Fitting the lower knife (fig. 11).

- Fix bracket P to the knife holder with screw Q.
- Insert knife D into its seat.
- The cutting edge of the knife should not protrude above the surface of the plate.
- Tighten screw A.
- With the needle in the lowest position, slide bracket O towards the needle guard and lock bush L and washer G with screw F.
- Ensure that knife holder C slides freely and then adjust it in relation to the width of stitching required.
- Lightly tighten screw N.
- With the needle in the lowest position move bracket P towards front needle guard and lock with screw Q.
- Having positioned the upper knife in contact with the lower, loosen screw N. Spring M, with pin H, creates correct contact pressure between the knives.
- Rest a finger on screw A and thus exert a very light pressure to lock screw N.
- This pressure must be light in order not to cause strong friction between the two knives and their consequent damage.

Note: The following sub-classes:

228-00-05 228-00-03 228-00-08 and their derivates do not have brackets O and P.




fig.11

## 8. Fitting and adjusting feed dogs (figs. 12 and 13).

- Fit the rear feed dogs C and D (fig. 12) and match the feed dog slides.
- Inserting a small screw driver through the threaded holes in the slides, tighten, but not completely, screw F, by means of the groove in its point.
- Fit the front differential feed dog E with screw G but do not lock (fig. 13).
- Loosen screw A.
- Adjust the feed dog inclination by rotating the eccentric B.




fig.12




fig.13


- The feed dog teeth, protruding from the needle plate, should be perfectly parallel with this plate.
- With the feed dogs at the highest point, the distance between their teeth and the plate surface, measured on the front of the feed dog differential, should be  $3/64''$ .
- Feed dog C should be lower than the other two feed dogs.
- Lock screws F, G and A.

9. Feed (fig. 14).

Note: The machines illustrated in this manual are supplied with the feed adjusted to suit the work for which the machines are destined.

Should it ever be desired to alter the feed, then proceed as follows:

- Substitute eccentric A or eccentric B, or both A and B. For eccentric substitution, according to the length of stitch, consult the appropriate tables. Use extractor drawing No. 280-715.



ECCENTRICITY E	No. stitches per inch	DRAWING No.
$2,57 \pm 0,03$	3,5	280-0451/3,5
$2,12 \pm 0,03$	4	280-0451/4
$1,49 \pm 0,03$	5	280-0451/5
$1,06 \pm 0,03$	6	280-0451/6
$0,76 \pm 0,03$	7	280-0451/7
$0,53 \pm 0,03$	8	280-0451/8
$0,36 \pm 0,03$	9	280-0451/9
$0,22 \pm 0,03$	10	280-0451/10
$0 \pm 0,03$	12	280-0451/12

ECCENTRICITY E	No. stitches per inch	DRAWING No.
$0,15 \pm 0,02$	14	280-0461/14
$0,26 \pm 0,02$	16	280-0461/16
$0,35 \pm 0,02$	18	280-0461/18
$0,42 \pm 0,01$	20	280-0461/20
$0,48 \pm 0,01$	22	280-0461/22
$0,53 \pm 0,01$	24	280-0461/24
$0,57 \pm 0,008$	26	280-0461/26
$0,6 \pm 0,008$	28	280-0461/28
$0,63 \pm 0,005$	30	280-0461/30
$0,65 \pm 0,005$	32	280-0461/32
$0,68 \pm 0,005$	34	280-0461/34
$0,7 \pm 0,005$	36	280-0461/36
$0,74 \pm 0,005$	40	280-0461/40
$0,76 \pm 0,005$	44	280-0461/44
$0,8 \pm 0,005$	50	280-0461/50
$0,84 \pm 0,005$	60	280-0461/60
$0,87 \pm 0,005$	70	280-0461/70
$0,88 \pm 0,005$	74	280-0461/74




fig. 15

10. Fitting upper knife (fig. 15).

- Fit upper knife C into its seat in block A.
- Attach block D and brackets E and G with bolt F.
- Bracket E should be very near the cutting plane of knife C.
- When knife C is at the bottom of its stroke, its cutting edge should be  $1/32''$  below the cutting edge of the lower knife.
- To obtain this, adjust knife C in its inclined seat and block A on the body of the upper knife holder B.
- Lock bolt F and then make sure that when the upper knife reaches the bottom of its stroke it does not touch the front needle guard.




fig. 14

e) Locking and adjusting presserfoot lever (fig. 16).

- Slide the lever shaft L into bush C to which lever D is hinged.
- Insert shaft L and bush C into the appropriate hole in the base.
- Slide lever A and spring E onto shaft L.
- Attach spring clip F to end of shaft L.
- Adjust lever A to eliminate axial play of shaft L.
- Lightly tighten screw B.
- Insert lever D into the guiding fork with the needle at top dead center.
- Connect lever A to the rod joined to the presserfoot raising pedal.
- When the pedal is depressed there should be some free play before lever D is acted upon.




fig.16

- Adjust the screw in the base under lever A until this raises the presserfoot to the required position.
- Ensure that when the upper looper is in movement it does not touch the presserfoot tongue when this is in its highest position. A better guard against the upper looper and the presserfoot tongue hitting, is supplied by adjusting the eccentric washer M which is under lever D and attached to the side cover.
- Lock screw B.




fig.17

f) Adjusting the front cover plate (fig. 17).

- Adjustment is carried out with the plate closed.
- The movable part C should not interfere with the front needle guard or the lower knife holder.
- Slacken-off nut A.
- Adjust screw B to move the plate to left or right.
- Lock nut A.

g) Adjusting needle thread take-up

- When working with very hard materials adjust the needle thread take-up 270-274/2 by moving it forward, that is towards the operator.

## ELECTRICAL EQUIPMENT FOR LUBRICATION CONTROL (PRESSURE SWITCH)

### h) Dismantling and replacing the pressure switch

- Remove the sump from the base and empty the oil.
- Remove the screw fixing the pressure switch bracket to the sump.
- Remove the two screws holding the cable end.
- Remove the plastic tube from the pressure switch which connects to the rubber union.
- Remove the support bracket and fix it to the new pressure switch.
- Attach the cable end with the screws, slide the plastic tube into the pressure switch and replace in sump with appropriate screw.
- Replace the sump and fill with oil as described on page 11 para. c.

### Changing the pressure switch bulb.

- Carry out operations 1 and 2 as explained for the substitution of the pressure switch.
- Remove tube, extract the bulb, which has a bayonet fitting, and replace with a new one.
- Re-attach the tube, position the pressure switch in the sump and attach with the screws.
- Replace sump and fill with oil as explained on pag. 11 para. c.

### Electrical connection of pressure switch on Zefir motors.

- Plug the connecting cable into the pick-up socket and plug the other end into the 12 V. light socket on the motor.

Note: if connection has to be made to a motor not equipped with a light socket, but equipped with a 12 V. take-off in the connection box, proceed as follows:

- Cut a piece of cable to about 5" length and to one end attach a Mignon socket type 13 and to the other the pins of the 12 V. light voltage.
- Plug the connecting cable into the pick-up socket and plug the other end into the Mignon socket.

### Regulating flow of lubricating oil through the main shaft. (fig. 18).

- Remove cap
- Adjust index B with a screw driver. (Movement towards the C engraved on the plate, decreases the oil flow, towards the letter A increases flow.)






fig.18

## TABLE OF SETTINGS

ELECTRICAL COMPONENT FOR LUBRICATION CONTROL (LUBRICATOR)





HEAD SYMBOLS	A	B	C	D	E
228-00-01 = 228-00-04 = 228-00-05 = 228-00-11 = 228-00-12 = 228-01-01 = 228-01-02 = 228-01-03 = 228-10-01 = 228-10-02 = 228-10-03 = 228-10-05 = 228-10-06 = 228-10-07 = 228-28-01 = 228-28-02 =	2,5	1,5	0,8	4,5	3,5
228-00-02 = 228-00-03 = 228-00-06 = 228-00-08 =	2,3	1,5	0,8	—	5
228-00-07 = 228-28-07 =	2,3	1,5	0,8	5	—




II. USE


a) Threading







228-00-06



### b) Changing the needle

1. Switch off the motor
2. Depress the pedal which starts the motor to ensure the machine is completely off.
3. Move the needle to top dead center.
4. Press lever B right down (fig. 19).
5. Remove the presserfoot from its working position.
6. Slacken the needle locking screw half a turn with screw driver 1161/2.
7. Remove the needle.
8. Fit new needle.
9. The notch through which the looper passes should face towards the rear needle guard, that is towards the interior of the machine.
10. Using the tweezers supplied ensure that the needle touches the end of the needle holder.
11. Tighten the locking screw being careful not to alter the position of the needle.
12. Do not over-tighten.




fig. 19

### c) Positioning and adjusting presserfoot pressure (fig. 19).

1. Check correct positioning of presserfoot
2. The needle should pass between the presserfoot shoe and tongue.
3. To adjust presserfoot slacken off screw F.
4. Center the presserfoot in the correct position and lock F.
5. To increase or decrease the presserfoot pressure, slacken off screw G with spanner 633-742 and adjust knob A.
6. Lock knob A with screw G.

### d) Tension adjustment

1. Tighten the tensioners sufficiently to permit a regular stitch formation.
2. Never tighten too much

### e) Stitch length adjustment (fig. 14).

For stitch length adjustment see para. a) 9 Feed, pag. 15.

### f) Adjustment of seam width.

The seam width can only be varied to a very limited extent after which the needle plate has to be changed.  
To vary the width within these fine limits proceed as follows:

1. Slacken off screw N in the lower knife holder (fig. 11).
2. Slacken off screw F (fig. 15).
3. Move upper knife support A (fig. 15) to right or left till desired seam width is obtained.
4. Lock screw F (fig. 15).
5. Lower knife holder re-setting should be carried out in accordance with the instructions in para. a) 7.

**g) Faults due to improper handling of the machine**

n°	FAULT	PROBABLE CAUSE
1	Irregular stitch	<ul style="list-style-type: none"> <li>– Tensioners badly adjusted</li> <li>– Thread take-ups badly adjusted</li> <li>– Incorrect threading</li> <li>– Yarns not gauged</li> </ul>
2	Feed and material slipping	<ul style="list-style-type: none"> <li>– Insufficient presserfoot pressure</li> <li>– Bad adjustment of feed dog height and inclination</li> <li>– Knives need sharpening</li> <li>– Differential badly adjusted</li> </ul>
3	Skip stitching	<ul style="list-style-type: none"> <li>– Upper or lower looper badly adjusted with respect to needle consequently blunting looper.</li> <li>– Loopers too far apart when crossing</li> <li>– Loopers too close when crossing with consequent blunting.</li> <li>– Front needle guard too far from needle</li> <li>– Needle badly positioned</li> </ul>
4	Thread breaking	<ul style="list-style-type: none"> <li>– Tensions too tight</li> <li>– Thread wound irregularly on the reel.</li> </ul>
5	Needle breaking	<ul style="list-style-type: none"> <li>– Bent needle</li> <li>– Needle badly fitted</li> </ul>
6	Puncturing of material	<ul style="list-style-type: none"> <li>– Blunt needle</li> <li>– Needle size not suitable to throat plate</li> <li>– Needle with unsuitable point</li> </ul>
7	Loss of oil	<ul style="list-style-type: none"> <li>– Screw holding sump to base not tightened enough</li> <li>– Sump plug not screwed up properly</li> <li>– Sump gasket badly fitted.</li> </ul>
8	Lack of lubrication	<ul style="list-style-type: none"> <li>– Oil level too low</li> <li>– Drive belt badly fitted</li> <li>– Upper tube clogged</li> <li>– Lubrication pump filter blocked.</li> </ul>

### III. MAINTENANCE

#### a) Every day

Briefly clean all machine parts relating to feed and stitch formation.

#### b) Every week

1. Remove needle plate and clean the feed dogs, needle guards and loopers.
2. Open front cover plate and carefully clean inside
3. Carefully clean inside the plate covering the needle movement assembly.

#### c) Every three months

1. Using the spanner supplied, remove the sump drain plug and drain off oil completely.
2. Remove screw 007-L-20 which attaches filter to plug.
3. Extract filter and clean by immersing in petrol.
4. Air blast filter and sump plug.
5. Soak felt with clean oil.
6. Replace sump plug.
7. Refill machine with 1 3/4 pts. of new VR. 604 oil.




fig. 19

#### IMPORTANT

In operation 1 para. c) do not completely remove the plug to begin with, so that most of the oil runs out through the side holes in the plug (fig. 19).

#### d) Knife sharpening

1. When sharpening the knives use the RIMOLDI sharpener and special block which guarantees exact sharpening angle. This block is supplied on request.

#### e) Instructions for removal of cam shaft

- Necessary tools supplied on request only.
- Pliers model S. 0560/00.
- Pliers model S. 0459/00.
- Extractor S. 0416/00

#### IMPORTANT

It is absolutely essential that the principal components of the crank-shaft/con-rod assembly are replaced in their original positions. To this aim proceed as follows:

- Replace the T flanges with the lubrication hole towards the bottom.
- Leave the screws holding the con-rod caps in their holes.
- Con-rods J and L are distinguishable one from the other by means of a 2 stamped on the top surface of L and three lines on J.
- The con-rod caps are engraved with similar markings and should be matched to the respective con-rod. Both marks should be on the same side.
- The position of con-rod N is given by the drawing number which should be on the pulley side.
- Carefully follow the cup spring assembly order.

## SEQUENCE OF OPERATIONS (fig. 20).

1. Open the side cover.
2. Remove screw D.
3. Using extractor 280-715 extract the eccentrics A and B.
4. Remove con rod caps N, O, J, L.
5. Remove screw Z.
6. Remove pulley cover Y.
7. Slacken off hexagonal screw X.
8. Remove washer W.
9. Extract pulley V.
10. Remove flange T.
11. Remove spacer U.
12. Remove springs S.
13. Extract spring ring P using pliers S. 0459/00 slightly turning the shaft to the right.
14. Extract the shaft.



fig.20

TRATROMI

The sequence of operations to be carried out is as follows: 1. Open the side cover. 2. Remove screw D. 3. Extract eccentrics A and B using extractor 280-715. 4. Remove con rod caps N, O, J, L. 5. Remove screw Z. 6. Remove pulley cover Y. 7. Slacken off hexagonal screw X. 8. Remove washer W. 9. Extract pulley V. 10. Remove flange T. 11. Remove spacer U. 12. Remove springs S. 13. Extract spring ring P using pliers S. 0459/00 slightly turning the shaft to the right. 14. Extract the shaft.




fig.20

# **SPARE PARTS CATALOGUE**

ЗИООЈАТА СА СТЯГА ВНАЧА

## I. HOW TO USE THIS CATALOGUE

### a) Introduction

1. This spare parts catalog is made up of a series of tables illustrating the various parts or assemblies which make up the basic head and its sub-classes.
2. In order to make the use of this catalogue easier, the table index shows the position of each assembly inside the head.
3. The conversion assemblies of the basic head and its sub-classes are illustrated in single tables.
4. In the tables, the numbers which identify the sub-classes are printed at top right of page in black.
5. On each table the various components of the assembly illustrated, are cross-referenced by a number. The assemblies, whose components cannot be supplied separately, are cross-referenced by a capital letter. Parts and equipment not normally with the machines but which can be supplied on request, are given at the bottom of each table and are illustrated complete with all their particulars at the end of the book.
6. The catalogue has a general numerical index giving the cross-reference numbers of all component parts of the machine and listing the table on which the parts are illustrated.

## II. HOW TO ORDER SPARE PARTS

### a) All parts

To ensure immediate dispatch of required spare parts, the following instructions should be carefully followed:

1. Quote the serial number of the head.
2. Quote the drawing number of the part required.
3. Give the full name of the part required.
4. The quantity.

### IMPORTANT

The RIMOLDI Company likes to analyse any cases of breakage, wear or irregularities arising in parts manufactured by them. For this reason they kindly ask you to return such pieces along with the order for spare parts.

### b) Needles only


1. Only straight system RIM 27 needles should be used on the machines illustrated in this manual.
2. The needle system and size are marked on the needle shank.
3. The size indicates the average diameter expressed in hundredths of a millimeter calculated on the blade of the needle.
4. The system and size are also shown on the packets containing RIMOLDI needles.
5. When ordering always give the system and size of the needle required (e.g. n. 100 needles size 90 system RIM 27).
6. In case of doubt send a sample needle or an empty packet of the type required.
7. For stitching elastic or elasticised materials there are ball point needles classified SKU.



# INDEX OF TABLES


BUSHES – THREAD GUIDES  
STUDS PRESSED INTO THE  
BASE

Tav. 1



MAIN SHAFT WITH  
CON-RODS

Tav. 2




DIFFERENTIAL  
ASSEMBLY

Tav. 3




SHAFTS AND CON-RODS  
OPERATING LOOPER

Tav. 4




NEEDLE DRIVE  
MECHANISM

Tav. 5



UPPER AND LOWER  
KNIFE MECHANISM


Tav. 6




PRESSERFOOT LIFTING MECHANISM – NEEDLE PLATE	Tav. 7	
CASING – WORK PLATE	Tav. 8	
THREAD GUIDES AND TENSIONERS	Tav. 9	
SUMP AND OIL PUMP	Tav.	
MACHINE MOUNTING BRACKET AND KNEE CONTROL	Tav.	
REEL HOLDERS AND PEDAL	Tav.	
ACCESSORIES	Tav.	

HEAD 228-00-02	Tab. 14	HEAD 228-10-01	Tab. 26
" 228-00-03	Tab. 15	" 228-10-02	Tab. 27
" 228-00-04	Tab. 16	" 228-10-03	Tab. 28
" 228-00-05	Tab. 17	" 228-10-05	Tab. 29
" 228-00-06	Tab. 18	" 228-10-06	Tab. 30
" 228-00-07	Tab. 19	" 228-10-07	Tab. 31
" 228-00-08	Tab. 20	" 228-28-01	Tab. 32
" 228-00-11	Tab. 21	" 228-28-02	Tab. 33
" 228-00-12	Tab. 22	" 228-28-07	Tab. 34
" 228-01-01	Tab. 23	TABLE W1 (100)	Tab. 35 Tab. 36
" 228-01-02	Tab. 24	TABLE X1 (101)	Tab. 37
" 228-01-03	Tab. 25	PARTS ON REQUEST	Tab. 38 Tab. 39


68_det	10-01-855_QASH	69_det	10-09-855_QASH
75_det	10-01-855	81_det	10-00-855
80_det	10-01-855	84_det	10-00-855
82_det	10-01-855	85_det	10-00-855
85_det	10-01-855	86_det	10-00-855
90_det	10-01-855	91_det	10-00-855
95_det	10-01-855	96_det	10-00-855
100_det	10-01-855	101_det	10-00-855
105_det	10-01-855	106_det	10-00-855
110_det	10-01-855	111_det	10-00-855
115_det	10-01-855	116_det	10-00-855
120_det	(001) TABLE WI	125_det	10-70-855
125_det	(101) TABLE XI	126_det	10-70-855
130_det	PARTS ON REQUEST	128_det	10-70-855
135_det			




REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	270-016	bush, shaft	1	9	270-264	thread guide needle	1
2	270-097/1	bush knife holder	1	10	280-002/1	base machine	1
3	270-058/2	bush rear	2	11	270-642	studs cover centering	2
4	270-057/1	bush front	2	12	280-830	tube oil	1
5	270-268	tubes thread guide	2	13	270-082/1	bush presserfoot lift	1
6	270-938	bolt bush	1	14	270-912	locking pin presserfoot work plate	1
7	280-010/3	bush main shaft	1				
8	G.280-002/2	base with bush and thread guides	1				




REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	PM.280.009/4	main shaft complete	1	17	PM.270-059/1	con-rod with coupling	1
2	270-704	seeger ring for right bearing	1	18	270-062	guide con-rod	2
3	270-705	spring	4	19	280-925/1	bolt eccentric locking	1
4	270-620	flange right side	1	20	280-019	woodruff key	1
5	270-614	spacer right	1	21	092-D-26	wick for shaft	1
6	270-008/1	pulley	1	22	023-N-5,5	screw gudgeon pin locating	2
7	270-612/1	washer with guide	1	23	001-E-10	bolt flange	3
8	270-981	bolt pulley fixing	1	24	010-D-11,5	bolt for looper con-rod	8
9	128-608/5	cover pulley	1	25	280-012/3	con-rod needle bar	1
10	270-610	stud pulley	1	26	270-116/2	con-rod knife shaft	1
11	280-009/4	main shaft	1	27	270-061/2	con-rod upper looper	2
12	270-707	ball bearing right	2	28	270-060/1	coupling con-rod	1
13	010-H-13,7	bolt for con-rod 280-012/3 and 270-116/2	4	29	270-059/1	coupling con-rod	1
14	270-975	bolt coupling	4	30	270-613	spacer bearing	1
15	290-944	screw guide fixing	2				
16	PM.270-060/1	con-rod with coupling	1				




REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	PM.280-049/1	slide differential	1	18	280-033/1	connector slide	1
2	280-611/1	block sliding	1	19	280-253	gasket	1
3	026-C-7	screw countersunk	1	20	270-640/3	guide block	1
4	280-023	bolt for feed dog holder	2	21	005-L-11	screw guide block fixing	1
5	270-935	washer	3	22	071-H-5	washer	2
6	092-B-1	wick	1	23	280-207/2	guard oil	1
7	270-039	eccentric shaft for differential	1	24	026-C-7	screw oil guard fixing	2
8	270-937/1	screw shaft fixing	1	25	270-978	screw differential feed dog fixing	1
9	092-D-11	wick	2	26	270-050	feed dog differential	1
10	270-036/1	block sliding	1	27	280-051	feed dog subsidiary	1
11	280-035	bushing joint	1	28	270-052	feed dog chaining	1
12	280-034	bushing joint	1	29	270-977	screw subsidiary feed dog fixing	1
13	280-926	nut slide	2	30	270-250/2	shield rubber	1
14	280-0451/10	eccentric for subsidiary feed dog	1	31	270-249/1	shield	1
15	280-0451/9	eccentric for differential feed dog	1	A	280-049/1	slide main feed dog	1
16	004-L-7	screw shield fixing	2	B	280-043/1	slide subsidiary feed dog	1
17	280-048/1	connector slide	1			On request: 280-0511	Tab. 38







REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	PM.270-138/1	shaft for fork lever	1	19	250-708/1	cage, roller bearing for needle drive lever	1
2	PM.270-137/1	fork lever	1	20	016-B-2,5	screw gudgeon pin fixing	1
3	270-132/1	bush for fork lever	1	21	G.270-025/2	assembly needle bar	1
4	270-728/1	screw bush fixing	1	22	RIM. 27	needle	1
5	290-027/1	ring for needle guide bar	1	A	270-020/1	clamp needle holder	1
6	270-933	nut for guide bar	1	B	290-025/1	needle bar	1
7	270-713	spring washer	1	23	003-A-4,5	screw retaining needle	1
8	270-006/1	shaft operating slide lever	1	24	270-130	gudgeon pin clamp	1
9	073-F-9	washer for upper shaft	2	25	092-B-1	wick gudgeon pin	2
10	270-719	collar for upper shaft	2	26	016-A-2,5	screw needle bar wick retaining	2
11	007-C-11	screw collar	2	27	270-135	bar slide drive	1
12	270-007/1	attachment shaft	1	28	092-D-5	wick gudgeon pin	1
13	270-975/1	attachment screw for 270-007/1	1	29	270-133/1	gudgeon pin fork lever	1
14	270-031/1	gudgeon pin for attachment	1	30	023-N-5,5	grub screw fixing needle bar drive lever	1
15	092-D-6	wick gudgeon pin	1	31	001-E-7	bolt upper shaft end	1
16	071-E-5	washer for upper shaft	1	32	270-131	washer shim	1
17	001-G-10	bolt washer holding	1	33	092-D-11	wick for shaft	1
18	270-708	bearing for upper shaft	1	34	092-A-10	wick	1




REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	270-102	pin for upper knife holder	1	16	250-471	bolt for upper knife driving lever	1
2	270-096/1	holder upper knife	1	17	007-P-10	screw lower knife fixing	1
3	270-112	knife upper serrated	1	18	071-D-5	washer lower knife shaft	1
4	2777-228	guard	1	19	270-104	holder lower knife	1
5	128-111	guard upper knife	1	20	270-105	shaft lower knife holder	1
6	270-987	bolt upper knife fixing	1	21	270-113/1	knife lower	1
7	270-099	block upper knife holding	1	22	270-100	spring lower knife	1
8	270-103	snug upper knife locking	1	23	270-106	pin for lower knife holder	1
9	073-F-9	washer for upper knife holder	1	24	003-L-12	bolt knife holder fixing	1
10	270-719	lock ring for upper knife holder	1	25	270-101	bush support guide	1
11	007-C-11	screw lock ring	1	26	070-F-4	washer bush	1
12	270-108/1	gudgeon pin for attaching fork	1	27	270-877	bolt for lower knife bush	1
13	270-098	coupling fork	1	28	028-B-5	bolt for upper knife holder	1
14	092-C-2	wicks gudgeon pin	2	29	004-A-5	screw guard fixing	1
15	092-D-9	wick knife holder	1	30	27.77-227	stop-plate rear needle guard	1

On request:  
270.112/2      Tab. 39  
270.113/2      "      39







REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	PM.270-208/3	side cover with bush	1	38	270-212	spring clip for closing	1
2	007-H-25	bolt for upper cover	1	39	001-D-6	screw spring clip fixing	1
3	PM.270-205/3	cover with bush	1	40	608-405	knob	1
4	270-241/2	cap oil filler	1	41	280-209/1	cover side	1
5	270-965/2	gasket for oil filler cap	1	42	016-B-4	grub screw	1
6	270-983	screw cover fixing	1	43	280-236	spring	1
7	PM.270-218/2	hinge	1	44	270-715	grub screw locking knob 270-093/1	1
8	007-R-7.5	screw for fixing plate	7	45	270-129/1	cover shaft	1
9	G.270-245/4	plate with bush	1	46	270-731/1	screw for attachment W1	2
10	270-246	gasket plate	1	47	280-921	pad	1
11	270-093/1	knob spring regulating	1	48	270-913	pin for front cover plate	1
12	032-F-9.5	screw for eccentric washer	1	49	016-D-6	screw pin	1
13	605-412	washer	1	50	280-226/1	pin	1
14	270-094	lever presserfoot release	1	51	001-G-12	screw kinge	2
15	270-701	washer spring	1	52	280-225	pin	1
16	270-086	spring tie bar	1	53	270-624	gasket cover disc	1
17	270-078	pin for presserfoot release lever	1	54	270-623/1	disc cover	1
18	270-092	spring presserfoot pressure	1	55	001-D-10	screw cover disc	2
19	270-993	screw stop	1	56	G.270-216/2	assembly front cover plate	1
20	270-935	screw fixing upper cover	2	57	280-203/2	hinge	1
21	270-066/2	caps, rear, for bushes	2	58	280-303	nipple fixing cover	1
22	633-925	spacer	1	59	001-D-4,5	screw spring clip fixing	1
23	280-945	disc felt	1	60	270-973	bolt short	1
24	280-244/1	filter oil	1	61	270-972	bolt long	1
25	C1205/A	screw	3	62	270-214	screw fixing work plate	1
26	PM.270-095/3	shaft presserfoot alignment	1	63	270-110	tie bar	1
27	G.270-090/1	shaft presserfoot release	1	64	270-218	ring for fixing work plate	1
28	PM.270-210/3	plate work	1	65	017-E-4,5	screw for work plate fixing ring	2
29	280-214/1	cover	1	66	004-L-9	screw cover fixing	3
30	270-730/2	plug for blocking hole	2	67	270-174	nameplate for tension holder cover	1
31	270-220/1	pin for front cover plate	1	68	270-175	nameplate on front cover plate	1
32	PM.270-217/2	cover plate with fin	1	69	280-215	spacer	3
33	007-F-14	screw cover plate	1	70	602-E-4434	spring pin	1
34	270-221	spring for front cover plate	1	71	001-E-12	screw fixing filter	1
35	054-D-4	nut for lock screw	1	72	270-090/1	block tie bar	1
36	270-226	lock screw	1	73	290-923	grub screw tie bar	1
37	053-D-4	lock nut knob	1	74	057-E-4	nut for work plate fixing screw	1
				75	016-E-5,5	screw for front cover plate	1





REF. Nº	PART. Nº	DESCRIPTION	QUANT.	REF. Nº	PART. Nº	DESCRIPTION	QUANT.
1	270-941	screw fixing needle thread, thread-guide	1	19	270-270/1	tensioner upper looper thread	1
2	PM.270-263/1	thread guide for needle thread	1	20	004-A-3,2	screw fixing guard	1
3	G.270-262/2	thread clasp complete	1	21	270-276/1	guard looper stop	1
4	004-A-5	screw fixing needle tensioner	1	22	270-275/1	guide upper looper thread	1
5	270-274/3	thread tensioner for needle thread	1	23	032-A-6	screw fixing thread guide	1
6	270-264	thread guide needle	1	24	272-232/1	spring looper	2
7	270-265	bush upper thread guide	1	25	270-233	bush upper tension	3
8	270-265/1	bush upper thread guide	2	26	270-235/1	knob, threaded, for tensioning	3
9	270-266	bush lower thread guide	2	27	603-031	disc tension	6
10	270-268	tube lower thread guide	2	28	270-230	pin, threaded, for tensioning	3
11	781001-0-00	nameplate showing machine class	1	29	270-232/2	spring needle	1
12	270-271	thread guide for lower looper thread	2	30	004-N-5,5	screw fixing thread tensioner	2
13	036-C-7	screw for looper thread tensioner	2	31	PM.270-262/2	body with pin	1
14	270-272	thread tensioner for lower looper thread	1	32	270-255	pin thread clasp	1
15	270-234/1	cap tensioner retainer	3	33	270-259	pin tube	1
16	270-269/1	tensioner lower looper thread	1	34	270-258	spring thread take-up	1
17	016-B-2,5	screw fixing thread guide	1	35	270-261/1	cap thread take-up	1
18	004-L-6	screw fixing thread tensioner	1				




REF. Nº	PART. Nº	DESCRIPTION	QUANT.	REF. Nº	PART. Nº	DESCRIPTION	QUANT.
1	G.270-816/1	assembly oil pump	1	34	270-966/1	gasket	1
2	G.633-833/1	assembly gear	1	35	G.270-646	assembly oil distributor	1
3	PM.270-816/1	body pump	1	36	PM.270-646/1	distributor	1
4	633-812	screw	1	37	057-A-3	nut	2
5	PM.633-817/1	cover	1	38	270-650	valve deviator	1
6	633-816/1	washer	1	39	270-651	gasket	1
7	633-711/1	gaskets	2	40	270-734/1	washer spring	1
8	270-824/1	screw drag	1	41	270-652	pipe connecting	1
9	270-823/1	shaft	1	42	270-8251	pipe oil pump union	1
10	633-708	pin spring	1	43	633-826/1	pipe oil pump union	1
11	633-707	washer spring	1	44	270-645	pointer for oil distributor	1
12	039-G-10	bolt fixing pulley	1	45	016-B-2,5	grub screw pointer	1
13	270-810/2	pulley oil pump	1	46	028-E-10	screw	2
14	633-959/1	spy glass oil	1	47	270-434	pipe from pressure switch	1
15	270-808	gasket	1	48	270-W1-328	clamp pipe	1
16	633-842	pipe	1	49	AS.270-410	pressure switch assembly	1
17	270-811/1	pin	2	50	270-4281	cover	1
18	270-946	gasket	2	51	270-422/1	bulb 15 V. 3 W.	1
19	270-947	gasket	2	52	001-E-7	screw fixing pressure switch	2
20	065-L-6	washer	2	53	270-435	bracket support	1
21	C59-G-6	nut	2	54	270-432	plug with current pick-ups	1
22	270-831/1	pipe	1	55	270-430	gasket rubber	1
23	270-836	pad felt	1	A	633-821/2	gear	4
24	017-H-12	grub screw	1	B	633-822/2	pin gear	1
25	007-L-20	screw	1	C	633-819	plate side	1
26	633-966	gasket	1	D	633-833	plate internal	1
27	270-828/1	grating	1	E	633-818/1	washer internal	1
28	270-996/2	plug	1	F	633-R34/1	pin drag	1
29	270-827/1	pad felt	1	G	270-816/1	body pump	1
30	633-925	spacer	1	H	633-814	sheath roller bearing	1
31	G.270-996/2	plug sump	1	L	633-813	sheath roller bearing	1
32	270-001/2	sump	1	M	670-702	ring sealing	2
33	G.270-001/2	assembly sump	1	56	280-946	spacer for connecting pipe	1



12




REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
<b>SUPPLIED WITH HEAD ONLY</b>							
1	PM.250-133/1	rod thread guide	1	2	28	holder reel	1
2	016-F-6,5	grub screw	1	2	29	rod main support	2
3	250-140	union rod	1	8	910-143	disc reel support	5
4	PM.250-148/1	support rod	1	1	30	pin reel	5
5	250-137	rod thread guide	1	1	31	screws cheesehead	5
6	250-143	rod lower main	1	1	32	rod thread guide	1
7	250-130	rod upper main	1	1	33	grub screw	1
8	G.250-137	frame thread guide	1	1	34	support thread guide	1
9	1146	pin reel	1	1	35	support for reel pin	1
10	01142	plate reel base	1	1	36	knob knurled	2
11	001-G-10	screw fixing plate	1	1	37	frame nut fixing	4
12	001-G-12	screw fixing rod	1	1	38	rod, upper, of frame	2
13	01141	base thread guide	1	1	39	frame thread guide	1
14	AS.250-149	assembly thread guide frame	1	1	40		
15	270-158/1	support rod	1				
16	270-157	rod thread guide	1				
17	G.270-157	support with thread guide rod	1				
18	605-980	grub screw	3				
19	605-937	support	1				
20	AS.270-140	assembly complete thread guide frame	1				
21	TS.20 x 30	screw for fixing frame	2				
22	569	disc spool support	3				
23	PM.910-914	pedal	1				
24	053-H-8	nut pedal	2				
25	910-964	bolt pointed	2				
26	910-934/1	support pedal	1				
27	G.910-914/1	assembly pedal	1				




REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	VR. 604	oil 1 Kg.	1	11	270-112	knife upper	1
2	1175	dust cover for machine	1	12	01160/2	screwdriver	1
3	280-155	vee belt	1	13	280-742	socket spanner 23/64"	1
4	HIM. 27	needle	5	14	280-745	extractor eccentric	1
5	1161/2	screwdriver	1	15	270-743	allen key 5/64"	1
6	633-742	allen key 1/8" for 270-715	1	16	01161/2	screwdriver	1
7	1158	tweezers for threading	1	17	641-LY-743	allen key 3/32"	1
8	1156/1	spanner double ended 7 . 9	1	18	270-431	lead mains	1
9	270-741	socket spanner 9/32"	1	19	639M-745	spanner sump plug	1
10	270-113/1	knife lower	1				
		On request 270-675/1 Tab. 38					
		SC de T 200					
		SC de T 200					
		SC de T 200					
		SC de T 200					


14





REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	270-0751	looper lower	1	14	272-B-191	tongue	1
2	270-232/1	spring lower looper tension	1	15	270-196	locator	1
3	272-B-050	feed dog main	1	16	004-L-8	screw	1
4	282-B-051	feed dog subsidiary	1	17	27-B-183	plate	1
5	272-B-052	feed dog chaining	1	18	272-B-184/1	slide	1
6	781002-0-00	name plate showing machine class	1	19	G.28.21-C2-009/4	main shaft assembly	1
7	272-B-1141	needle plate bight width 9/64"	1	20	G.27.21-C2-067/3	looper drive shaft with connecting rods	1
8	270-074	looper upper	1	21	280-0461/16	eccentric for main feed dog	1
9	272-B-270	tensioner upper looper thread	1	22	280-0451/12	eccentric for subsidiary feed dog	1
10	272-B-272	tensioner lower looper thread	1	23	27.21-C2-056	bush eccentric for upper looper drive	1
11	27.01-P-403/1	screw fixing guard lever	1	24	PM.27.21-C2-059	con-rod with coupling	1
12	272-186	guard presserfoot stop	1	25	27.21-C2-059	coupling	1
13	G.272-B2-181	assembly presserfoot	1	26	G.270-262/3	thread take-up needle thread	1
				272-B-0501	see Tab. 38		
				282-B-0511	see Tab. 38		
				272-B-114	see Tab. 38		
				272-092	see Tab. 38		




REF. Nº	PART. Nº	DESCRIPTION	QUANT.	REF. Nº	PART. Nº	DESCRIPTION	QUANT.
1	003-M-7	screw	1	35	272-BK-1051	shaft	1
2	026-G-10	screw lever lock	1	36	PM.272-BK-110	plate	1
3	272-BK-107	front needle guard	1	37	272-BK-104	holder knife	1
4	272-BK-114	needle plate bight tongue 1/16"	1	38	071-D-5	washer	1
5	282-BK-209	side cover	1	39	272-BK-994	retainer spring	1
6	270-0751	looper lower	1	40	272-BK-976	spring	1
7	270-232/1	spring lower looper tension	1	41	272-BK-986	bolt	1
8	272-B-050	feed dog main	1	42	G.272-BK-181	assembly presserfoot	1
9	282-B-051	feed dog subsidiary	1	43	272-BK-191	bracket	1
10	272-B-052	feed dog chaining	1	44	272-BK-184	slide	1
11	781003-0-00	name plate showing machine class	1	45	270-196	locator	1
12	270-074	looper upper	1	46	004-L-7	screw	1
13	272-B-270	tensioner upper looper thread	1	47	G.272-BK-216/2	assembly front cover plate	1
14	272-B-272	tensioner lower looper thread	1	48	27.21-C2-059	coupling	1
15	27.01-P-403/1	screw guide block fixing	1	49	AS.272-BK-903	knee control, complete	1
16	272-186	guard presserfoot stop	1	50	272-BK-907	washer	1
17	280-0451/12	eccentric for subsidiary feed dog	1	51	272-BK-906	screw	1
18	G.270-262/3	thread take-up complete	1	52	PM.272-BK-903	lever	1
19	G.272-BK-096	holder, upper knife, complete	1	53	272-BK-905	support	1
20	092-C-2	wick	2	54	390-974	screw	2
21	092-D-11	wick	1	55	057-E-4	nut	2
22	092-D-2	wick	1	56	G.272-BK-903	lever for moving knife	1
23	272-BK-991	screw register	1	57	270-574	disc	1
24	059-A-5	nut	1	58	270-582	pad	1
25	004-A-3,2	screw	2	59	272-BK-573	rod	1
26	272-BK-102	guide	1	60	038-M-9	screw	3
27	272-BK-103	locator	1	61	270-572	attachment	1
28	272-BK-099	holder knife	1	62	280-0461/16	eccentric for feed dog	1
29	272-BK-100	spring	1	63	G.282-BK-209/1	cover, side protection	1
30	PM.272-BK-096	lever	1	64	G.28.21-C2-009/4	main shaft assembly	1
31	272-BK-987	screw	1	65	G.27.21-C2-067/3	looper drive shaft with connecting rods	1
32	255-442	pin	1	66	27.21-C2-056	bush eccentric	1
33	272-BK-112	knife	1	67	PM.27.21-C2-059	con-rod with coupling	1
34	G.272-BK-104	holder, knife, complete	1			On request:	
						see Tab. 38	
						see Tab. 38	
						see Tab. 38	








REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	001-D-7	screw guide block fixing		1	23	001-G-10	1
2	003-M-7	screw cap		3	24	G.27.21-C-700	1
3	270-075	lower looper		1	25	27.21-C-702	1
4	270-263	thread guide for needle		1	26	057-R-5	2
5	270-270	tensioner upper looper thread		1	27	PM.27.21-C-708	1
6	27C-274	take-up, needle thread		1	28	27.21-C-708	1
7	781006-0-00	name plate showing machine class		1	29	250-031	6
8	27.21-C-220	guard, feed dog		1	30	27.21-C-709	1
9	270-074	upper looper		1	31	240-035	1
10	27.21-C2-059	coupling		1	32	27.21-C-232	1
11	PM.27.21-C-050	feed dog main		1	33	3710	1
12	PM.28.21-C-051	feed dog subsidiary		1	34	G.27.21-C-703	1
13	PM.27.21-C-114/1	needle plate bight width 3/64" - 1/16"		1	35	G.27.21-C-704	1
14	G.27.21-C-181/2	assembly presserfoot		1	36	3707	1
15	27.21-C-191/2	tongue		1	37	270-701	1
16	270-183	block		1	38	PM.27.21-C-704	1
17	278-184/C2	slide		1	39	280-0461/40	2
18	270-196	locator		1	40	G.27.21-C2-067/3	1
19	004-L-7	screw		1	41	G.28.21-C2-009/4	1
20	270-989	screw fixing block		1	42	27.21-C2-056	1
21	AS.27.21-C-700	tensions assembly and thread pulley		1	43	PM.27.21-C2-059	1
22	27.21-C-983	bolt				PM.27.21-C-114 G.27.21-C-181 G.27.21-C-181/1	see Tab. 38 see Tab. 38 see Tab. 38




REF. Nº	PART. Nº	DESCRIPTION	QUANT.	REF. Nº	PART. Nº	DESCRIPTION	QUANT.
1	270-075	looper lower	1	11	270-183	plate	1
2	781007-0-00	name plate showing machine class	1	12	270-196	locator	1
3	27.21-1143	needle plate	1	13	004-L-7	screw	1
4	27.21-C-050	feed dog main	1	14	270-989	screw	1
5	27.221-C-074/1	looper upper blind	1	15	27.21-C-184	slide	1
6	27.21-C2-059	coupling	1	16	003-M-7	screw cap	1
7	280-0461/6	eccentric for subsidiary and main feed dog	1	17	G.28.21-C2009/4	main shaft assembly with con-rod	1
8	289-051	feed dgo subsidiary	1	18	G.27.21-C2-067/3	looper drive shaft with con-rods	1
9	G.27.21-CC-181	assembly presserfoot	1	19	27.21-C2-056	bush eccentric	1
10	27.21-CC-191	tongue	1	20	PM.27.21-C2-059	con-rod with coupling	1
				21	280-0461/30	eccentric for subsidiary feed dog	1

20




Nº RIF.	Nº DISEGNO	DENOMINAZIONE	QUANT.	Nº RIF.	Nº DISEGNO	DENOMINAZIONE	QUANT.
1	270-0751	looper lower	1	12	004-L-7	screw fixing tongue	1
2	781008-0-00	name plate showing machine class	1	13	270-989	screw fixing block	1
3	27.21-1141	needle plate bight width 3/64" - 1/16"	1	14	27.21-C-184	slide	1
4	27.21-C-050	feed dog main	1	15	280-0461/16	eccentric for subsidiary feed dog	1
5	270-074	looper, upper, with hole	1	16	280-0461/18	eccentric for main feed dog	1
6	289-051	feed dog subsidiary	1	17	G.28.21-C2009/4	main shaft assembly with con-rod	1
7	27.21-C2-059	coupling	1	18	G.27.21-C2-067/3	looper drive shaft with con-rods	1
8	G.27.21-CC-181	assembly presserfoot	1	19	27.21-C2-056	bush eccentric	1
9	27.21-CC-191	tongue	1	20	PM.27.21-C2-059	con-rod with coupling	1
10	270-183	block	1	21	G.270-262/3	thread take-up complete	1
11	270-196	locator	1			On request:	
					27.21-1143	see Tab. 38	
					272-092	see Tab. 38	



21

REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	270-075	looper lower	1	10	G.278-181	presserfoot assembly complete	1
2	27.01-P9-113/1	knife lower	1	11	270-9R9	screw fixing block	1
3	27.277-0745	looper upper	1	12	270-183	block	1
4	278-052	feed dog	1	13	278-191	tongue	1
5	278-114	needle plate bight width 5/64"	1	14	270-196	locator	1
6	781011-0-00	plate machine class	1	15	004-L-7	screw fixing tongue	1
7	279-050	feed dog main	1	16	278-184	shoe	1
8	289-051	feed dog subsidiary	1	17	200-0451/12	eccentric for subsidiary feed dog	1
9	279-112	knife upper	1	18	280-0461/14	eccentric for main feed dog	1
On request: see Tab. 38							


22



S.p.A. V. Rimoldi & C. Milano  
O  
Made in Italy

10

REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	028-B-8	screw fixing block	1	12	G.279-181	presserfoot complete	1
2	270-075	looper lower	1	13	279-191	tongue	1
3	27.277-0745	looper upper	1	14	PM.279-183	block	1
4	279-050	feed dog main	1	15	275-185	plate	1
5	289-051	feed dog subsidiary	1	16	001-A-3,2	screw fixing plate	1
6	279-099	block upper knife holding	1	17	270-196	locator	1
7	279-112	knife upper	1	18	004-L-7	screw fixing tongue	1
8	279-113/1	knife lower	1	19	279-184	shoe	1
9	279-114	needle plate eight width 5/64"	1	20	G.279-216/2	cover plate, front, complete	1
10	781012-0-00	plate machine class	1	21	280-0451/12	eccentric for subsidiary feed dog	1
11	279-987	screw fixing upper knife	1	22	280-0461/14	eccentric for main feed dog	1
Components not shown: 270-075/2 27.277-0745							
On request: see Tab. 38 see Tab. 38							




S.p.A. V.Rimoldi & C. Milano  
Made in Italy

22


REF. Nº	PART. Nº	DESCRIPTION	QUANT.	REF. Nº	PART. Nº	DESCRIPTION	QUANT.
1	G.270-R-181	presserfoot complete	1	12	270-R-267	guide tape	1
2	270-185	plate	1	13	001-C-5,5	screw	1
3	001-A-3,2	screw	1	14	G.250-R-9373	support bobbin carrier	1
4	270-191	tongue	1	15	605-144	rod upper	1
5	270-196	locator	1	16	01141	base	1
6	004-L-8	screw	1	17	001-G-12	screw	1
7	270-R-071	plate	1	18	605-143	rod	1
8	270-R-184	shoe	1	19	605-723	rings cone	2
9	TS.20 x 30	screw	2	20	605-937	support	1
10	PM.270-R-267	guide tape	1	21	605-980	screw	4
11	057-A-3	nut	1	22	781030-0-00	plate machine class	1

24



S.p.A. V. Rimoldi & C. Milano  
Made in Italy


REF. N°	PART. N°	DESCRIPTION	REF. N°	PART. N°	DESCRIPTION
1	781031-0-00	plate machine class	1	13	270-R-267
2	001-A-3,2	screw plate fixing	1	14	001-C-5,5
3	277-191	tongue presserfoot	1	15	G.250-R-9373
4	27.77-183	plate	1	16	605-144
5	004-L-9	screw tongue fixing	1	17	01141
6	27.277-R-071	plate tape guiding	1	18	001-G-12
7	004-G-3	screw plate fixing	1	19	605-143
8	G.277-R-181	presserfoot complete	1	20	605-723
9	277-R-184	shoe presserfoot	1	21	605-937
10	27.77-195	locator	1	22	605-980
11	PM.27.77-R-267	guide tape	1	23	TS. 20 x 30
12	057-A-3	nut	1	24	277-185
On request:					
270-075/2					
27.277-074					
28.00-B7-0511					





25

S.p.A. V. Rimoldi & C. Milano  
Made in Italy


REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	781032-0-00	plate machine class	1	12	004-L-8	bolt	1
2	TS 20 x 30	screw	1	13	270-R-071	plate	1
3	PM.270-R-267	tape guide	1	14	270-R-184	shoe	1
4	057-A-3	nut	1	15	G.250-R-9373	holder reel	1
5	270-R-267	tape guide	1	16	605-144	rod upper	1
6	001-C-5,5	bolt	1	17	01141	base	1
7	G.270-R-181	presserfoot complete	1	18	001-G-12	screw	1
8	270-185	plate	1	19	605-143	rod	1
9	001-A-3,2	screw fixing plate	1	20	605-723	ring conical	2
10	270-191	tongue	1	21	605-937	support	1
11	270-196	locator	1	22	605-980	screw	4



REF. N°	PART. N°	DESCRIPTION	REF. N°	PART. N°	DESCRIPTION	REF. N°
1	001-D-7	screw for fixing guide	1	18	275-184	shoe
2	270-075	loopper lower	1	19	AS.275-413	hemming guide complete
3	270-D-074/1	loopper upper blind	1	20	275-426	bolt
4	27-277-0745	loopper upper with eye	1	21	PM.275-417	support
5	275-050	feed dog main	1	22	PM.275-408	body guide
6	285-051	feed dog subsidiary	1	23	275-403	screw
7	275-114	needle plate bight width 1/8"	1	24	275-411	plate
8	781060-0-00	plate machine class	1	25	275-408	body guide
9	280-0451712	eccentric for subsidiary feed dog	1	26	275-410	pin
10	G.275-181	presserfoot complete	1	27	275-409	hinge
11	275-185	plate	1	28	275-425	knob
12	001-A-3,2	screw plate fixing	1	29	275-404	screw
13	270-196	locator	1	30	PM.275-407	plate with spring
14	004-L-7	screw tongue fixing	1	31	275-407	plate
15	275-191	tongue	1	32	275-415	guide sliding
16	275-183	block	1	33	275-416	spring
17	270-989	screw	1	34	280-0451/8	eccentric for main feed dog
On request:						
				270-075/2	see tab. 38	
				27-277-074	see tab. 38	
				275-1141	see tab. 38	
				PM.275-1882	see tab. 38	
				285-0511	see tab. 38	




S.p.A. V. Rimoldi & C. Milano  
○   ○  
Made in Italy



S.p.A. V. Rumoldi & C. Milano  
Made in Italy


REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	G.275-B-210/3	work plate	1	31	275-B-430	spring leaf	1
2	G.282-BK-209/1	cover side	1	32	275-B-403	screw stop	1
3	012-H-5	screw for lever junction	1	33	275-BS-4252	screw adjustment	1
4	001-G-10	screw fixing lever assembly	1	34	275-B-407	plate hem	1
5	275-B-050	feed dog main rod	1	35	275-B-411	guide	1
6	620-565	needle plate bight width 1/8"	1	36	275-B-409	block	1
7	275-B-114	plate machine class	1	37	275-BS-6412	pin threaded	1
8	781062-0-00	lever moving vertical guide	1	38	275-BS-4142	guide	1
9	275-BS-6002	presserfoot complete	1	39	004-A-3,2	screw	2
10	G.275-B-181	plate	1	40	275-BS-4082	body	1
11	275-185	screw fixing plate	1	41	G.275-BS-6012	lever assembly for moving guide	1
12	001-A-3,2	locator	1	42	053-D-4	nut	1
13	275-B-196	screw fixing tongue	1	43	275-BS-6052	spring	1
14	004-L-7	tongue	1	44	275-BS-6032	transmission	1
15	275-B-191	block	1	45	275-BS-6012	support	1
16	275-B-183	screw	1	46	039-D-6	screw	1
17	270-989	shoe	1	47	057-B-3	nut	1
18	275-B-184	lever horizontal connecting chain	1	48	275-BS-6062	pin	1
19	275-BS-5992	screw fixing knee control	1	49	063-N-4	washer	1
20	TS. 22 x 35	chain	4	50	270-573	rod	1
21	PM. 275-BS-1482	assembly movable hem guide	1	51	G. 620-570	knee control complete	1
22	AS.275-BS-4132	support	1	52	270-998	screw pointed	2
23	PM.275-BS-4172	guide complete	1	53	059-P-8	nut hexagonal	2
24	G.275-BG-4132	screw	1	54	620-570	support	1
25	001-D-6	slide	2	55	270-571	shaft	1
26	275-BS-4062	body guide	1	56	270-579	anchor	1
27	PM.275-BS-4082	spring	1	57	038-M-9	screw hexagonal	9
28	275-BS-4152	screw	1	58	270-720	ring spring tensioning	1
29	275-404	pin threaded	1	59	270-575	spring	1
30	275-B-410		1	60	620-572	union	2
			1	61	270-574	disc	1
			1	62	270-582	pad disc	1

On request:  
AS.275-BS-4132/1 Tab. 39




S.p.A. V.Rimoldi & C. Milano  
Made in Italy

2



29

REF. Nº	PART. Nº	DESCRIPTION	QUANT.	REF. Nº	PART. Nº	DESCRIPTION	QUANT.
1	039-R-8,5	bolt guide fixing	1	16	255-404	screw	1
2	781064-0-00	plate machine class	1	17	27.53-2221	plate guide blocking	1
3	G.27.53-210/3	work plate complete	1	18	001-C-4	screw	1
4	AS.27.53-4132	hemming guide complete	1	19	PM.255-434	spring with hinge	1
5	PM.27.53-4081	guide	1	20	G.27.53-3792	attachment complete,	1
6	275-426	screw locking	1	21	250-980	knob	1
7	275-404	screw	1	22	27.53-4011	rod	1
8	PM.275-408	body with hinge	1	23	27.53-4172	support	1
9	275-404	screw	1	24	27.53-4181	pawl	1
10	275-411	plate	1	25	27.53-4251	knob	1
11	275-408	body guide	1	26	27.53-2201	fork	1
12	275-410	pin	1	27	27.53-4121	washer spring	1
13	275-409	hinge	1	28	27.53-4261	knob	1
14	27.53-2231	plate stop	1	29	27.53-2211	nut	1
15	255-415	block	1	30	27.53-4071	support rotating	1




S.p.A. V. RIMOLDI &amp; C. Milano

O O

Made in Italy


1

2




30

REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	039-R-8,5	screw guide fixing	1	16	255-404	screw	6,8-R
2	781065-0-00	plate machine class	1	17	27.53-2221	plate guide blocking	00-0-000
3	G.27.54-210/3	work plate complete	1	18	001-C-4	screw	0015-000
4	AS.27.53-4132	hemming guide complete	1	19	PM.255-434	spring with hinge	SETA-000
5	PM.27.53-4081	guide	1	20	G.27.53-3792	attachment complete	1004-000
6	275-426	screw locking	1	21	250-980	knob	000
7	275-404	screw	1	22	27.53-4011	rod	000
8	PM.275-408	body with hinge	1	23	27.53-4172	support	200-210
9	275-404	screw	2	24	27.53-4181	pawl	000
10	275-411	plate	1	25	27.53-4251	knob	000
11	275-408	body guide	1	26	27.53-2201	fork	000
12	275-410	pin	1	27	27.53-4121	washer spring	000
13	275-409	hinge	1	28	27.53-4261	knob	000
14	27.53-2231	plate stop	1	29	27.53-2211	nut	000
15	255-415	block	1	30	27.53-4071	support rotating	000



31


REF. N°	PART. N°	DESCRIZIONE	TRAS. N°	QUANT.	REF. N°	PART. N°	DESCRIZIONE	TRAS. N°	QUANT.
1	781066-0-00	plate machine class	200-0-00	1	7801	plate right side, left side	5811-0-00	200-0-00	1
2	G.27.53210/3	work plate complete	200-0-00	1	7802	plate left side, right side	200-0-00	200-0-00	1



32


REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	270-1142	needle plate bight width 11/64"	1	14	255-404	screws	2
2	039-R-8,5	screw guide fixing	1	15	PM.276-B-403	guide	1
3	270-D-074/1	looper upper blind	1	16	G.276-B-403/1	support complete	1
4	G.274-B1-1811	presserfoot complete	1	17	032-F-6,5	screw for eccentric	1
5	270-185	plate	1	18	605-412	eccentric	1
6	001-A-3,2	screw plate fixing	1	19	057-E-4	nut	1
7	270-196	locator	1	20	276-B-412	washer spring	1
8	004-L-7	screw tongue fixing	1	21	011-E-13	screw collar	1
9	270-191	tongue	1	22	276-B-417/1	support guide	1
10	001-A-5,5	screw guide fixing	1	23	276-B-407/1	support rotating	1
11	274-B1-1921	guide	1	24	781110-0-00	plate machine class	1
12	276-B-184	shoe	1	25	003-M-7	screw cap	1
13	AS.276-B-403/1	guide rotating					

On request:  
270075 Tab. 38



REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	270-1142	needle plate bight width 11/64"	1	14	255-404	screws	2
2	039-R-8,5	screw guide fixing	1	15	PM-276-B-403	guide	1
3	270-D-074/1	looper upper blind	1	16	G.276-B-403/1	support complete	1
4	G.274-B1-1811	presserfoot complete	1	17	032-F-6,5	screw for eccentric	1
5	270-185	plate	1	18	605-412	eccentric	1
6	001-A-3,2	screw plate fixing	1	19	057-E-4	nut	1
7	270-196	locator	1	20	276-B-412	washer spring	1
8	004-L-7	screw tongue fixing	1	21	011-E-13	screw collar	1
9	270-191	tongue	1	22	276-B-417/1	support guide	1
10	001-A-5,5	screw guide fixing	1	23	276-B-407/1	support rotating	1
11	274-B1-1921	guide	1	24	781111-0-00	plate machine class	1
12	276-B-184	shoe	1	25	280-0451/6	eccentric feed dog	2
13	AS.276-B-403/1	guide rotating	1				

On request:  
 270075 Tab. 38  
 27.277-0745 Tab. 38




S.p.A. V. Rimoldi & C. Milano  
Made in Italy

6

N° RIF.	N° DISEGNO	DENOMINAZIONE	QUANT.	N° RIF.	N° DISEGNO	DENOMINAZIONE	QUANT.
1	001-D-7	screw guide block fixing	1	14	G.28.21-C2-009/4	main shaft assembly	1
2	270-0751	looper lower	1	15	G.27.21-C2-057/3	looper drive shaft with connecting rods	1
3	272-B-052	feed dog chaining	1	16	270-196	locator	1
4	272-B-270	tensioner upper looper thread	1	17	004-L-8	screw	1
5	272-B-272	tensioner lower looper thread	1	18	27.21-C-183/1	plate	1
6	781116-0-00	name plate showing machine class	1	19	270-989	screw	1
7	PM.27.21-C-050	feed dog main	1	20	270-183	block	1
8	PM.28.21-C-051	feed dog subsidiary	1	21	27.21-C-191/1	tongue	1
9	G.27.21-C-181/1	assembly presserfoot	1	22	27.21-C-184/1	slide	1
10	27.21-C-220	guard, holder feed dog	1	23	27.21-C2-056	bush eccentric	1
11	PM.27.21-S-114	needle plate	1	24	PM.27.21-C2-059	con-rod with coupling	1
12	280-0461/40	eccentric for main and subsidiary feed dog	2	25	27.21-C2-059	coupling	1
13	270-074	looper upper	1			gnitor along	1

Numero n°  
BC daT 80055  
BC daT 8470-115.55

SOLENOID  
CHAIN CUTTING  
ATTACHMENT  
(W1) 100




WARNING: the apparatus is designed for 220 V. For different voltages run through an autotransformer type SUT. 1745.00 with relative connectors type PM. T 11-127.

REF. N°	PART. N°	DESCRIPTION	QUANT.	REF. N°	PART. N°	DESCRIPTION	QUANT.
1	AS.270-W1-333	control box complete	1	35	PM.270-W1-343	cover solenoid	1
2	G.270-W1-333	control box electric	1	36	AS.270-W1-351	assembly complete solenoid	1
3	C.001-C-10	screw	11	37	270-W1-323	bracket	1
4	057-B-3	nut	13	38	G.270-W-3340	push-button complete	1
5	270-W1-373	panel	1	39	270-W-3300	bracket push-button	1
6	270-W1-378	base	1	40	001-E-5	screw	4
7	T 11-22	anchoring	1	41	270-W-3310	cover	1
8	T 11-30	cable terminal	1	42	270-W-3700	plug 4-pin	1
9	270-W1-3721	grommet	2	43	270-W-3340	push-button	1
10	270-W1-363	fuse holder	1	44	270-W-6400/3	bracket slide guide	1
11	T 11-16/3	resistor	1	45	008-A-12	screw	1
12	T 11-33/3	fuse	1	46	270-716	screw	1
13	T 11-21	condenser electronic	1	47	122-T-37	guide cable	2
14	270-W-3680	socket push-button	1	48	G.270-W-3220/1	lever complete	1
15	T 11-14	rectifier	1	49	270-W-3220	lever chain cutting	1
16	270-W1-379	relay	1	50	PM.270-W-0760/1	lever, presserfoot holder	1
17	C.001-E-30	screw	3	51	270-W-3280	washer	1
18	053-D-4	nut	3	52	270-W-3250	screw for spring	1
19	063-L-4	washer	6	53	270-W-3240	spring knife return	1
20	T 11-13	transformer	1	54	G.270-W1-210/3	work plate	1
21	270-W1-369	socket	1	55	270-W-3540	washer	4
22	270-W1-372	plug with earth	2	56	633-710/1	washer	2
23	C.001-C-14	screw	2	57	122-T-215	board terminal	1
24	064-L-5	washer	3	58	001-E-8	screw	4
25	270-W-3550	screw	3	59	065-C-6	washer	2
26	270-W1-355	washer star	12	60	280-253 TC 30	gasket for slide guide	1
27	001-E-12	screw	2	61	G.270-W-6400/3	bracket slide guide	1
28	T 11-126	plug with earth	1	62	TT 20 x 25	screw wood	4
29	270-W1-346	spring	1	63	270-W1-328	holder cable	2
30	270-W1-345	sleeve	1	64	270-459	nail for cable guide	30
31	270-W1-349	contact point	1	65	546	guide single cable	10
32	C.001-C-7	screw	3	66	547	guide double cable	5
33	270-W1-351	solenoid	1	67	T 11-355	washer star	3
34	PM.270-W1-332	bracket	1	68	270-W1-327	grommet	1



DETAILS OF SOLENOID ATTACHMENT 100 (W1)





Ref. No.	Drawing No.	Denomination	Quant	FOR USE WITH
1	272-B2W1-184	shoe	1	
2	272-B-183	plate	1	
3	004-L-8	screw	1	
4	270-196	locator	1	228-00-02-100
5	272-B-191	tongue	1	
6	001-A-4	screw	1	
7	275-W-185	plate	1	




	G.270-W.181	1	270-184	shoe	1	
		2	270-183	block	1	
		3	270-989	screw	1	
		4	270-191	tongue	1	228-00-01-100
		5	004-L-7	screw	1	
		6	270-196	locator	1	228 00-05-100
		7	001-A-3,2	screw	1	
		8	270-W-185	plate	1	



6.27.21-CW-181/2		DESCRIPTION	DESCRIPTION	QUANTITY	REMARKS
1	278-W-184/C 2	shoe		1	
2	270-183	block		1	
3	270-989	screw		1	
4	2721-C-191/2	tongue		1	
5	004-L-7	screw		1	
6	270-196	locator		1	
7	001-A-3,2	screw		1	
8	270-W-185	plate		1	



	G.27.54-W1-210/3	G.275-B W1-210/3
FOR USE WITH	FOR USE WITH	
228-10-06	228-10-02 - 228-10-03	







	G.27.53-W1-210	
	FOR USE WITH	
	228-10-05 - 228-10-07	



PARTS SUPPLIED ON REQUEST ONLY

BLIND UPPER LOOPER	270-D-074/1 FOR USE WITH	UPPER LOOPER WITH EYE	27.277-0745 FOR USE WITH	27.277-074 FOR USE WITH	FIXED GUIDE FOR NON-CUTTING	270-401 FOR USE WITH																																																																													
	228-00-01 228-00-05		228-00-01 228-28-02	228-00-04 228-01-02 228-10-01 228-00-05		228-00-05																																																																													
LOWER LOOPER	270-075 FOR USE WITH	270-075/2	SUBSIDIARY FEED DOG	2800-B7-0511 FOR USE WITH	282-B-0511 228-00-02	285-0511 228-10-01																																																																													
	228-00-01 228-28-01 228-28-02		228-00-04 228-00-05 228-01-02 228-10-01	228-00-04 228-01-02	228-00-01	228-00-01																																																																													
MAIN FEED DOG	272-B-0501 FOR USE WITH	PRESSERFOOT PRESSURE SPRING	272-092 FOR USE WITH	KNIFE SHARPENING BLOCK	272-BK-675 FOR USE WITH	270-675/1 228-00-03																																																																													
	228-00-02		228-00-08 228-00-02			228-00-01																																																																													
		<table> <tr> <td>1</td><td>G.2721-C-181</td><td>presserfoot complete</td><td>1</td><td>FOR USE WITH</td></tr> <tr> <td>2</td><td>270-183</td><td>block</td><td>1</td><td></td></tr> <tr> <td>3</td><td>2721-C-191</td><td>tongue</td><td>1</td><td></td></tr> <tr> <td>4</td><td>270-989</td><td>screw block fixing</td><td>1</td><td></td></tr> <tr> <td>5</td><td>2700-1834</td><td>plate</td><td>1</td><td>228-00-06</td></tr> <tr> <td>6</td><td>004-L-8</td><td>screw plate fixing</td><td>1</td><td></td></tr> <tr> <td>7</td><td>270-196</td><td>locator</td><td>1</td><td></td></tr> <tr> <td>8</td><td>2721-C-184</td><td>shoe</td><td>1</td><td></td></tr> </table> <table> <tr> <td>1</td><td>G.2721-C-181/1</td><td>presserfoot complete</td><td>1</td><td>FOR USE WITH</td></tr> <tr> <td>2</td><td>270-183</td><td>block</td><td>1</td><td></td></tr> <tr> <td>3</td><td>2721-C-191/1</td><td>tongue</td><td>1</td><td></td></tr> <tr> <td>4</td><td>270-989</td><td>screw block fixing</td><td>1</td><td></td></tr> <tr> <td>5</td><td>2721-C-183/1</td><td>plate</td><td>1</td><td>228-00-06</td></tr> <tr> <td>6</td><td>004-L-8</td><td>screw plate fixing</td><td>1</td><td></td></tr> <tr> <td>7</td><td>270-196</td><td>locator</td><td>1</td><td></td></tr> <tr> <td>8</td><td>2721-C-184/1</td><td>shoe</td><td>1</td><td></td></tr> </table>	1	G.2721-C-181	presserfoot complete	1	FOR USE WITH	2	270-183	block	1		3	2721-C-191	tongue	1		4	270-989	screw block fixing	1		5	2700-1834	plate	1	228-00-06	6	004-L-8	screw plate fixing	1		7	270-196	locator	1		8	2721-C-184	shoe	1		1	G.2721-C-181/1	presserfoot complete	1	FOR USE WITH	2	270-183	block	1		3	2721-C-191/1	tongue	1		4	270-989	screw block fixing	1		5	2721-C-183/1	plate	1	228-00-06	6	004-L-8	screw plate fixing	1		7	270-196	locator	1		8	2721-C-184/1	shoe	1		
1	G.2721-C-181	presserfoot complete	1	FOR USE WITH																																																																															
2	270-183	block	1																																																																																
3	2721-C-191	tongue	1																																																																																
4	270-989	screw block fixing	1																																																																																
5	2700-1834	plate	1	228-00-06																																																																															
6	004-L-8	screw plate fixing	1																																																																																
7	270-196	locator	1																																																																																
8	2721-C-184	shoe	1																																																																																
1	G.2721-C-181/1	presserfoot complete	1	FOR USE WITH																																																																															
2	270-183	block	1																																																																																
3	2721-C-191/1	tongue	1																																																																																
4	270-989	screw block fixing	1																																																																																
5	2721-C-183/1	plate	1	228-00-06																																																																															
6	004-L-8	screw plate fixing	1																																																																																
7	270-196	locator	1																																																																																
8	2721-C-184/1	shoe	1																																																																																
NEEDLE PLATE	270-1142 FOR USE WITH	270-1143 228-00-01	270-114 228-00-01	272-B-114 228-00-02	275-1141 228-10-01																																																																														
	272-BK-114/1 FOR USE WITH	272-BK-1141 228-00-03	27.21-1143 228-00-03	27.77-1142 228-00-08	PM.2721-C-114 228-00-04																																																																														
1	G.270-1812 presserfoot complete	1	1	G.274-401 guide complete	1	1																																																																													
2	270-191 tongue	1	2	PM.274-417 bracket	1	2																																																																													
3	270-183 block	1	3	PM.274-402 guide	1	3																																																																													
4	270-989 screw block fixing	1	4	003-A-4,5 screw	1	4																																																																													
5	004-L-7 screw tongue fixing	1	5	001-D-7 screw	1	028-A-3,5 screw																																																																													
6	270-196 locator																																																																																		
7	270-184 shoe																																																																																		
8	PM.270-1882 device thread cutting																																																																																		
FOR USE WITH		FOR USE WITH		FOR USE WITH																																																																															
228-00-01	10-00-005	HTIW 38U ROR	228-00-01	228-00-05	10-00-005	228-10-01																																																																													

PARTS SUPPLIED ON REQUEST ONLY

BLIND UPPER LOOPER	270-D-074/1 FOR USE WITH	UPPER LOOPER WITH EYE	27.277-0745 FOR USE WITH	27.277-074 FOR USE WITH	FIXED GUIDE FOR NON-CUTTING	270-401 FOR USE WITH																																																																															
	 228-00-01 228-00-05	 228-00-01 228-28-02 228-00-04 228-01-02 228-10-01 228-00-05			 228-00-05																																																																																
LOWER LOOPER	270-075 FOR USE WITH	270-075/2	SUBSIDIARY FEED DOG	2800-B7-0511 FOR USE WITH	282-B-0511 228-00-02 228-10-01	285-0511 228-00-01																																																																															
	 228-00-01 228-28-01 228-28-02 228-10-01		 228-00-04 228-01-02																																																																																		
MAIN FEED DOG	272-B-0501 FOR USE WITH	PRESSERFOOT PRESSURE SPRING	272-092 FOR USE WITH	KNIFE SHARPENING BLOCK	272-BK-675 FOR USE WITH	270-675/1 228-00-03 228-00-01																																																																															
	 228-00-02	 228-00-08 228-00-02		 228-00-03																																																																																	
		<table> <tr><td>1</td><td>G.2721-C-181!</td><td>presserfoot complete</td><td>1</td><td>FOR USE WITH</td></tr> <tr><td>2</td><td>270-183</td><td>block</td><td>1</td><td></td></tr> <tr><td>3</td><td>2721-C-191</td><td>tongue</td><td>1</td><td></td></tr> <tr><td>4</td><td>270-989</td><td>screw block fixing</td><td>1</td><td></td></tr> <tr><td>5</td><td>2700-1834</td><td>plate</td><td>1</td><td>228-00-06</td></tr> <tr><td>6</td><td>004-L-8</td><td>screw plate fixing</td><td>1</td><td></td></tr> <tr><td>7</td><td>270-196</td><td>locator</td><td>1</td><td></td></tr> <tr><td>8</td><td>2721-C-184</td><td>shoe</td><td>1</td><td></td></tr> </table> <table> <tr><td>1</td><td>G.2721-C-181/1</td><td>presserfoot complete</td><td>1</td><td>FOR USE WITH</td></tr> <tr><td>2</td><td>270-183</td><td>block</td><td>1</td><td></td></tr> <tr><td>3</td><td>2721-C-191/1</td><td>tongue</td><td>1</td><td></td></tr> <tr><td>4</td><td>270-989</td><td>screw block fixing</td><td>1</td><td></td></tr> <tr><td>5</td><td>2721-C-183/1</td><td>plate</td><td>1</td><td>228-00-06</td></tr> <tr><td>6</td><td>004-L-8</td><td>screw plate fixing</td><td>1</td><td></td></tr> <tr><td>7</td><td>270-196</td><td>locator</td><td>1</td><td></td></tr> <tr><td>8</td><td>2721-C-184/1</td><td>shoe</td><td>1</td><td></td></tr> </table>	1	G.2721-C-181!	presserfoot complete	1	FOR USE WITH	2	270-183	block	1		3	2721-C-191	tongue	1		4	270-989	screw block fixing	1		5	2700-1834	plate	1	228-00-06	6	004-L-8	screw plate fixing	1		7	270-196	locator	1		8	2721-C-184	shoe	1		1	G.2721-C-181/1	presserfoot complete	1	FOR USE WITH	2	270-183	block	1		3	2721-C-191/1	tongue	1		4	270-989	screw block fixing	1		5	2721-C-183/1	plate	1	228-00-06	6	004-L-8	screw plate fixing	1		7	270-196	locator	1		8	2721-C-184/1	shoe	1				
1	G.2721-C-181!	presserfoot complete	1	FOR USE WITH																																																																																	
2	270-183	block	1																																																																																		
3	2721-C-191	tongue	1																																																																																		
4	270-989	screw block fixing	1																																																																																		
5	2700-1834	plate	1	228-00-06																																																																																	
6	004-L-8	screw plate fixing	1																																																																																		
7	270-196	locator	1																																																																																		
8	2721-C-184	shoe	1																																																																																		
1	G.2721-C-181/1	presserfoot complete	1	FOR USE WITH																																																																																	
2	270-183	block	1																																																																																		
3	2721-C-191/1	tongue	1																																																																																		
4	270-989	screw block fixing	1																																																																																		
5	2721-C-183/1	plate	1	228-00-06																																																																																	
6	004-L-8	screw plate fixing	1																																																																																		
7	270-196	locator	1																																																																																		
8	2721-C-184/1	shoe	1																																																																																		
NEEDLE PLATE	270-1142 FOR USE WITH	270-1143 228-00-01	270-114 228-00-01	272-B-114 228-00-02	275-1141 228-10-01																																																																																
	 228-00-01																																																																																				
	272-BK-114/1 FOR USE WITH	272-BK-1141 228-00-03	27.21-1143 228-00-03	27.77-1142 228-00-08	PM.2721-C-114 228-00-04																																																																																
						228-00-06																																																																															
		GUIDE FOR NON-CUTTING	 3 2 4 5	THREAD CUTTING DEVICE	 3 4 2 1																																																																																
1 G.270-1812 2 270-191 3 270-183 4 270-989 5 004-L-7 6 270-196 7 270-184 8 PM.270-1882	presserfoot complete tongue block screw block fixing screw tongue fixing locator shoe device thread cutting	1 G.274-401 2 PM.274-417 3 PM.274-402 4 003-A-4,5 5 001-D-7	guide complete bracket guide screw screw	1 PM.270-1882 2 270-1872 3 270-1882 4 028-A-3,5	device complete blade blade screw	1 1 1 1 1																																																																															
					FOR USE WITH 228-00-01	228-00-05																																																																															
					1 PM.275-1882 2 275-1872 3 270-1882 4 028-A-3,5	device complete blade blade screw																																																																															
	FOR USE WITH 228-00-01	FOR USE WITH 228-00-01	FOR USE WITH 228-00-05		FOR USE WITH 228-10-01	FOR USE WITH 228-10-01																																																																															

PARTS SUPPLIED ON REQUEST ONLY

			FOR USE WITH
		1 AS.275-B-413/1 2 001-D-6 3 PM.275-B-417 4 G.275-B-413/1 5 275-B-407/B 6 275-B-411/1 7 275-B-409 8 275-404 9 275-B-410 10 275-B-430 11 275-B-403 12 275-B-406 13 275-B-425 14 275-B-408 15 275-B-418 16 005-D-5 17 004-R-5	1 guide hemming screw support guide plate hemming guide block screw pin threaded spring leaf screw stop shoe screw adjustment body guide locator screw screw
			228-10-02
		1 AS.275-BS-4132/1 2 G.275-BS-4132/1 3 004-R-5 4 001-D-6 5 PM.275-BS-4172 6 PM.275-BS-4082 7 004-A-3,2 8 275-BS-4142 9 275-BS-4082 10 275-BS-4062 11 275-BS-4152 12 275-BS-6412 13 275-BS-4252 14 275-B-410 15 275-B-430 16 275-B-403 17 275-B-409 18 275-404 19 275-B-407/B 20 275-B-411/1	1 guide hemming guide screw support body guide screw guide body shoe spring pin threaded screw adjustment pin threaded spring leaf screw stop block screw plate hemming guide
			228-10-03
CHAIN CUTTER	270-188	UPPER KNIFE	270-113/2
	FOR USE WITH 228-00-01		FOR USE WITH 228-00-01 207-000-200
LOWER KNIFE	270-112/2		
	FOR USE WITH 228-00-01 2850-115		

270-112  
carbide

207-018-200  
ng top