THIRD EDITION





# CATALOG NO. 87L

**STYLES** 

60000 C

60000 D

MACHINES FOR CLOSING PAPER BAGS
TAPE BOUND SEAM

Catalog No. 87 L

LIST OF PARTS

FOR

STYLES

60000 C

60000 D

Third Edition

Copyright 1945 by Union Special Machine Co. Rights Reserved in All Countries



Printed in U.S.A.

### **FOREWORD**

It is our constant aim to furnish carefully prepared information that will enable the customer to secure all possible economies and advantages from the use of Union Specials. On the pages which follow will be found illustrations and descriptions of the parts for Styles 60000 C and 60000 D.

Additional catalogs, containing information relative to these machines, and which will be furnished upon request, are listed below.

Catalog No. 45 N Catalog No. 87 A

Needle Manual Instructions for

Adjusting Style 60000 D

In all manufacturing centers will be found Union Special representatives, who will cooperate with those who desire in planning and estimating their requirements.

Union Special MACHINE COMPANY

Engineering Department

#### IDENTIFICATION OF MACHINES

Each Union Special carries a Style number which is stamped in the name plate on the machine. Style numbers are classified as standard and special. Those which are standard have one or more letters suffixed, but never contain the letter "Z". Example: "60000 C". Style numbers containing the letter "Z" are special. When only minor changes are made in a standard machine a "Z" is merely suffixed to the respective standard style number. Example: "60000 CZ".

Styles of machines similar in construction are grouped under a class number which differs from the style number in that it contains no letters. Example: "60000".

#### APPLICATION OF CATALOG

This catalog applies only to the standard styles of machines as listed herein. It can also be applied with discretion to special machines in Class 60000.

#### DESCRIPTION OF MACHINES

- 60000 C Flat Bed, Single Needle, Chain Stitch Type 101, Rotary Hook, for closing small filled paper bags on Styles 20100 P and 21800 N, with two paper reinforcing tapes, one guided next to presser foot, the other guided next to feed dog, seam Type SSa-1, round belt drive, trimming mechanism for top of bag, automatic cutter for severing tape between bags, stitch range 8 to 5 per inch, standard length 5 per inch.
- 60000 D Flat Bed, Single Needle, Chain Stitch Type 101, Rotary Hook, for closing small filled paper bags on Styles 20100 P and 21800 N, with two paper reinforcing tapes, one guided next to presser foot, the other guided next to feed dog, seam Type SSa-1, round belt drive, trimming mechanism for top of bag, improved automatic cutter for severing tape between bags, stitch range 8 to 5 per inch, standard length 5 per inch.
- 60000 Z A special Style, similar to the standard Style in Class 60000, but differing in one or more of its component parts.

#### **NEEDLES**

#### TYPE NUMBERS AND SIZES

Each needle has a type number and size number. The former denotes the kind of shank, point, length, groove, finish, and other details. The latter denotes the largest diameter of the blade, measured in thousandths of an inch midway between the shank and eye, and is stamped in the needle shank. Collectively, the type number and size number is the complete symbol.

To have orders promptly and accurately filled, the empty package, a sample needle, or the type and size number should be given. Use description on label. A complete order would read: "100 Needles, Type 924, Size 080".

#### NEEDLES (Continued)

The type number of the needle most commonly used in the styles of machines covered by this catalog is listed below. Opposite the type number is the description of the needle and sizes available.

Type No.

Description

924

Round shank, spear point, short, double groove, spotted, plain finish - Sizes 042, 049, 054, 067, 073, 080

#### ORDERING REPAIR PARTS

#### PLATES

Illustrations of parts are arranged according to scale and whenever possible, parts similar in appearance or function are grouped together.

When a given design of part is made in two or more sizes, only one illustration is usually shown. In ordering these pieces, it is necessary that the additional information be furnished as requested under these illustrations.

#### LIST OF PARTS

Turning from the plates to the list of parts, the description of each part and its principal uses will be found. Always check the symbol against its description before ordering. It is not necessary to furnish the plate number.

When a part is used, or can be used, in all machines covered by this catalog, no specific use is mentioned in the description.

For convenience in ordering, minor parts such as screws, nuts and similar articles are repeated after each major part.

- (-) A dash in the "plate number" column of the list of parts indicates the absence of an illustration.
- (‡) A double dagger in the "symbol to order by" column indicates that the component parts cannot be furnished separately.

#### IDENTIFYING PARTS

When the construction permits, each part is stamped with its part number. Some of the smaller parts are stamped with an identification letter to distinguish them from parts similar in appearance.

All part numbers represent the same part, regardless of the catalog in which they appear.

#### **SUPPLIES**

All supplies, including taps, reamers, belting, belt hooks, belt fasteners, screw drivers, wrenches and powdered oil stone will be promptly furnished.

# ORDERING REPAIR PARTS (Continued)


# USE GENUINE NEEDLES AND REPAIR PARTS


Success in the operation of these machines can be secured only by the use of genuine Union Special Needles and Repair Parts as furnished by the Union Special Machine Company, its subsidiaries and authorized distributors. They are designed according to the most approved scientific principles, and are made with the utmost precision. The maximum efficiency and durability are assured.

Genuine needles are packaged with labels marked Union Special. Genuine repair parts are stamped with the Union Special trade mark. Each trade mark is your guarantee of the highest quality in materials and workmanship.

#### TERMS


Prices are net cash and subject to change without notice. All shipments are forwarded f.o.b. shipping point. Parcel Post shipments are insured, unless otherwise directed. A charge is made to cover postage and insurance.



























# Plate 10 - One-Half Size






# Plate 12 - One-Half Size





One-Fourth Size, above line
Plate 14 One-Eight Size, below line



	LIST OF PARTS	
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering.	Plate No.
WA 15 20	Stop Watch	7
20	Washer, for tape cutter upper knife screw on Style 60000 D	1 ,
HS24 C	Screw, for tape cutter upper knife pawl extension	4
	on Style 60000 D	3
25 S	Screw, for tape cutter upper knife actuating lever	
50 D	extension on Style 60000 D	3
TA54	Needle Bar	11
TA55	Hand Tachometer, 2000 to 8000 R.P.M.	12
56	Needle Clamp Nut	4
77	Screw, for bag trimming upper knife	3
80	Screw, for pulley rim	4
81	Set Screw, for tape cutter bracket shaft on Style	
82	Adjusting Screw, for tape cutter upper knife bar	3
<b>5</b>	(lock nut No. 41071 G)	3
HS82	Feed Dog Adjusting Screw	4
- 88	Set Screw, for hook shaft collar; also for Nos.	-
00	2538, 21113 B, 60040 B, 61242	3
89 90	Set Screw, for feed bar	3
90	Screw, for tape cutter upper knife actuating shoe; also for No. 60078 Y	ا ،
91 A	Screw, for upper knife actuating trip dog spring	3
•	and holder, on Style 60000 D	3
93	Screw, for tape cutter upper knife actuating shoe	_
02.4	bracket on Style 60000 C; also for No. 23453 A	3
93 A 95	Set Screw, for feed driving shaft collar	3
. 33	Set Screw, for feed drive eccentric; also for Nos. 60076, 61259	3
96	Spot Screw, for feed drive eccentric; also for Nos.	ľ
	60021 A, 60076, 60093	3
96 A	Spot Screw, for hook shaft bushing	3
98	Set Screw, for pulley hub	3
109 116	Tension Disc Wrench, for needle clamp nut	4
110	wrench, for needle clamp nut	12
136	Screw, for feed rocker shaft bracket	3
357	Screw, for tape cutter upper knife actuating shoe	
0.50	stop	3
376 413	Screw, for throat plateOil Can	3
531	Oil CanSet Screw, for feed driving shaft collar	13
605 A	Screw, for auxiliary presser foot arm spring on	3
	Style 60000 C	3
652-20	Washer, for tape cutter bracket	4
660-142	Cotter Pin, for tape cutter upper knife actuating	-
000 11	lever stud; also for No. 60079 M on Style 60000 C	8
666-11	Oil Cup, for intermediate gear shaft	2
666-24 666-37	Oil Cup, for upper main shaft bearingFelt Wick, for needle bar link	2 8
666-59	Washer, cork, for plug screw	8 4
666-83	Oil Cup, for lower main shaft bearing	2
-		

Symbol	The figures in the last column refer only to the	
То	plates illustrating the parts and are not to be used	D1-4
Order By	in ordering.	Plate No.
		No.
668-1	Steel Incont for tension the state of the	
668-14	Steel Insert Fermila, for tension thread eyelet	4
719	Steel Insert Ferrule, for tension thread eyelet	4
1066	Screw, for feed rocker shaft	3
	pin, on Style 60000 D	_
1346	Tension Post	6
1740	Tape Cutter Upper Knife Actuating Lever Pin,	8
•	for Style 60000 D	
2538	Presser Spring Collar (screw No. 88)	8 6
9663	Regulating Screw, for tape cutter upper knife bar	0
	on Style 60000 C	3
9846	Screw, for tape cutter upper knife operating cam	"
	dog on Style 60000 D (nut No. 12934 A)	3
9937	Nut, for tape cutter upper knife operating pawl	"
	on Style 60000 C	4
12538	Nut, for feed lift link screw; also for No.	1 -
10004 4	22517 D	4
12934 A	Nut, for upper knife operating cam dog bracket	_
	screw on Style 60000 D: also for Nos. 9846	
10025 4	22560 A, 22799 M	4
12935 A	Screw, for adjusting presser foot bottom on Style	_
19057 T	60000 D (nut No. 51430 F)	3
12957 E	Washer, for tape cutter upper knife screw on	
21104 B-11	Style 60000 C	4
21104 B-11 21104 D	Thread Stand Rod	13
21104 D 21104 E	Thread Stand Spool Seat	14
21104 E 21104 F	Thread Stand Spool Pin Connection	12
21104 F 21104 G	Thread Stand Spool Seat Pad	14
21104 U 21104 H	Thread Stand Spool Pin	14
21104 K	Thread Stand Spool Nut Thread Stand Thread Wire	4
21105 J	Thread Stand Thread Guide	14
21113 A	Thread Stand Thread Wire Extension	8
21113 B	Thread Stand Thread Wire Coupling (screw No. 88)	11
21145	Cone, wood, for thread stand	5
21201	Screwdriver 9/64 inch round blade longth averall	12
	Screwdriver, 9/64 inch round blade, length overall 7 5/8 inches	1 4
21202	Screwdriver, 7/32 inch round blade, length overall	14
	11 1/4 inches	14
21203	Screwdriver, 13/64 inch round blade, length overall	14
	15 1/2 inches	14
21204	Screwdriver, 9/32 inch round blade, length overall	1.4
	15 inches	14
21205 A	Screwdriver, 3/8 inch round blade, length overall	* *
	14 inches	14
21207	Screwdriver, 7/64 inch round blade, length overall	
01000	2 1/2 inches	12
21236	Belt Plier, for 3/8 inch and smaller round	
01000	belting	13
21260	Emery Cord, 3/64 inch diameter, grade No.	
21260 4	120, fifty yard spool	
21260 A	Emery Cord, 3/64 inch diameter, grade No.	
;	50, fifty yard spool	

		DIST OF FARTS	
	Symbol	The Cinner of the Control of the Con	
	To	The figures in the last column refer only to the	
		plates illustrating the parts and are not to be used	Plate
	Order By	in ordering.	No.
			<del> </del>
	21260 B	Emery Cord, 1/32 inch diameter, grade No.	
	21260 C	180, Ility yard spool	]
	21200 C	Emery Cord, .025 inch diameter, grade No.	İ
	21260 D	200, fifty yard spool	
	-1200 B	Emery Tape, 3/32 inch wide, grade No. 180, fifty yard spool	
	21260 E	Emery Cord, .018 inch diameter, grade No.	
	040=4	200, fifty yard spool	
	21351	Belt Hook, wire, for 9/32 inch round belt	8
	21351 A	Belt Hook, wire, for 3/8 inch round belt	8
	21388 AG	Wrench, offset, for stitch regulating stud	12
	21394	Utility Grinder, including emery wheel. 5 inches	
		diameter, 1/4 inch face, round belt drive.	ł
	04004.00	recommended speed 3000 R. P. M	
	21394 G	Emery Wheel, 5 inches diameter, 1/4 inch face.	ļ
		3/8 inch hole, grade "M" emery 60	
	21394 H	Emery Wheel, 5 inches diameter, 1/2 inch face.	ĺ
		3/8 inch hole, grade "M" emery 60	
	21 <b>3</b> 94 K	Utility Grinder, including emery wheel, 5 inches	ļ
		diameter, 1/2 inch face, round belt drive.	İ
		recommended speed 3000 R.P.M	
	21718	Spring, for tape cutter upper knife pawl lever	
		adjusting block	8
	22516 A	Screw, for needle bar thread eyelet and holder	3
	22517 B	Screw, for attaching lower tape cutter knife	3
	22517 D	Screw, for tape cutter upper knife bar on Style	
		60000 C (nut No. 12538)	4
	22528	Screw, for upper tape guide; also for Nos. 60005 A,	_
		60026 A, 60036 N, 60064, 60079 C, 60026 D	3
e e	22539 C	Plug Screw, for hook shaft hole	4
	22539 D	Plug Screw, for feed driving shaft hole	$\overline{4}$
	22539 E	Plug Screw, for intermediate gear shaft hole	<u> </u>
	22542	Screw, for needle thread take-up eyelet	4 3
	22548	Screw, for edge guide	3
	22559 A	Screw, front, for tape cutter driving eccentric	,
		connecting rod	3
	22559 B	Screw, rear, for tape cutter driving eccentric	
		connecting rod	3
	22560 A	Screw, for hook shaft driven gear; also for	
		No. 60078 U	3
	22560 B	Screw, for intermittent needle thread nipper	
		operating plunger sleeve holder	3
	22562	Set Screw, for hook	3
	22562 A	Screw, for bag trimming knife bar driving stud;	
		also for No. 61255	3
	22569	Screw, for bag trimming knife bar bracket	3
	22570 A	Screw, for feed driving shaft gear case cover;	=
		also for Nos. 60091 G, 60096	3
	22571 A	Plug Screw, for arm of machine	3
	22588 A	Screw, for lower tape guide	3 3
	22595	Screw, for bag trimming knife holder	3
	22596	Screw, for upper knife operating cam dog bracket	
		on Style 60000 D (nut No. 12934 A)	3
		V	

		7
Cl1	TT1 - 01	
Symbol	The figures in the last column refer only to the	
To Order By	plates illustrating the parts and are not to be used	Plate
Order by	in ordering.	No.
22597	Spot Screw, for main shaft crank and upper bag	
	trimming knife eccentric	3
22597 A	Set Screw, for main shaft crank and upper hag	ľ
00004	trimming knife eccentric; also for No. 60062	3
22604	Screw, for tape cutter bracket	11
22617 P-48	Plug Screw, for plugging hole in bottom of frame	4
22738 A	Stop Screw, for upper knife cam dog spring	3
22738 D	Screw for K62210	7
22747	Screw, for tape cutter driving eccentric connecting	1
22764	rod ball stud fork	3
22764	Spot Screw, for hook shaft coupling	3
22775	Screw, for supporting lower knife; also for Nos.	
22795	60020 A, 60020 D	3
22193	Adjusting Screw, for tape cutter upper knife	
22799 D	actuating shoe support on Style 60000 C	3
22133 D	Stop Screw, upper, for tape cutter upper knife	
22799 H	operating cam dog	4
22133 11	Hinge Screw, for auxiliary presser foot on Style	
22799 M	60000 C; also for Nos. 60020 D, 60079 S	4
221,99 W	Screw, for hand lifter; also stop screw, lower,	
	for tape cutter upper knife operating cam dog on Style 60000 D	
22812	Sarrow for tone outton and a laif	3
22012	Screw, for tape cutter upper knife actuating trip	_
22837	dog (nut No. 43443 Q)	3
22839	Screw, for tape cutter bracket shaft on Style	4
	60000 D	
22839 B	Set Screw, for feed driving shaft gear	3
22839 C	Set Screw, for main shaft gear; also for No.	3
	60032 G	
22845 D	Screw, for feed lift link (nut No. 12538)	3
22874	Adjusting Screw, for tape cutter upper knife	4
	operating pawl, on Style 60000 C (nut No. 9937)	3
22881	Screw, for feed eccentric connecting rod bearing	J
	sleeve (nut No. 60038 N, washer No. 60038 K)	3
22882	Screw, for tape cutter upper knife (washer No.	J
	12957 E on Style 60000 C, No. 20 on Style	
	60000 D)	3
23452	Upper Tape Guide (screw No. 22528)	13
23453	Lower Tape Guide (screw No. 22588 A)	13
23453 A	Lower Tape Guide Bracket (screw No. 93)	10
29126 AS	Feed Driving Eccentric Assembly: one each Nos	
	60037, 60038, 60038 G, lapped together	11
29132 P	Main Shaft Crank and Upper Bag Trimming Knife	
· ·	Eccentric Assembly, on Style 60000 C: one	
	each Nos. 60072, 60091, lapped together	11
29132 Q	Tape Cutter Upper Knife Driving Eccentric	
	Assembly; one each Nos. 39144 N. 60076	
00100 =	60076 G, lapped together	11
29132 T	Main Shaft Crank and Upper Bag Trimming Knife	
j	Eccentric Assembly, on Style 60000 D: one	
22174 D	each Nos. K61096, 60072, lapped together	11
33174 B	Screw, for tape cutter upper knife lever	
ŧ	actuating stud	3

Symbol	The figures in the last of	
To	The figures in the last column refer only to the	1
	plates illustrating the parts and are not to be used	Plate
Order By	in ordering.	No.
0.5550.11		
$35772~\mathrm{H}$	Washer, for tape cutter upper knife actuating	i
	shoe pracket on Style 60000 C: also for No	1
	00013 C	4
39544 H	Tape Cutter Driving Eccentric Connecting Rod	) <del>*</del>
	Ball Stud	
41071 G	Lock Nut, for tape cutter upper knife bar	6
	adjusting screw	
41255 B	Tape Cutter Driving Eccentric Connecting Rod	4
	Ball Stud Fork (general No. 20045)	
43443 Q	Ball Stud Fork (screw No. 22747)	7
70 110 Q	Nut, for tape cutter upper knife actuating trip	
51192 G	dog screw	4
31192 G	Tension Thread Eyelet (steel insert No. 668-1,	
E1000 T	Insert ierrule No. 668-14)	4
51280 J	Feed Rocker Shaft Bracket Dowel Pin	8
51292 A	Tension Post Ferrule	4
51292 B	Tension Spring Ferrule	4
51292 C	Tension Regulating Nut	4
51292 F-4	Tension Spring, .031 inch diameter wire	8
$51430~\mathrm{F}$	Nut, for presser foot bottom adjusting screw on	O
	Style 60000 D	
60003	Edge Guide, for top of bag (screw No. 22548)	4
60005 A	Feed Dog (screw No. 22520)	9
60008 A	Feed Dog (screw No. 22528)	1
60020 A	Thread Hook (screw No. 22562)	2
9002011	Presser Foot Assembly, on Style 60000 C; one	
	each Nos. 60030, 60030 A, 61330 B-35 (screw	
60020 D	No. 22775)	1
00020 D	Presser Foot Assembly, on Style 60000 D; one	
	each Nos. 12935 A, 22799 H, 51430 F, 60030 B,	
C0001 A	1 50030 C (screw No. 22775) 1	1
60021 A	Pulley Hub (spot screw No. 96, set screw No.	_
	98)	12
60022	Main Shaft	13
60024 A	Throat Plate, for Style 60000 C (screw No. 376)	9
60024 D	Throat Plate, on Style 60000 D (screw No. 376)	9
60026 A	Auxiliary Feed Dog, on Style 60000 C (screw No.	9
	22528) (serew No.	_
60026 D	Auxiliary Feed Dog, on Style 60000 D (screw No.	1
	22528)	
60027 A	·/	1
	Auxiliary Presser Foot, on Style 60000 C (hinge screw No. 22799 H)	
60030	Program Front Cl. 1	1
00000	Presser Foot Shank, on Style 60000 C (screw No.	
60020 4	22775)	1
60030 A	Presser Foot Bottom, on Style 60000 C (hinge pin	_
20000 -	No. 61330 B-35)	1
60030 B	Presser Foot Shank, on Style 60000 D	$\dot{\hat{2}}$
60030 C	Presser Foot Bottom, on Style 60000 D (adjusting	4
	screw No. 12935 A, hinge screw No. 22799 H)	1
60032	Feed Driving Shaft	1
60032 C	Feed Driving Shaft Collar (set screw, headless,	13
	No. 531 set screw fillictor band No. 684	_
60032 G	No. 531, set screw, fillister head, No. 93 A)	5
	Feed Driving Shaft Gear (set screw, fillister head,	
	7/32 inch long, No. 22839 B, set screw, fillister	
•	head, 5/16 inch long, No. 22839 C)	12


		T T
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering.	Plate No.
60032 N	Feed Driving Shaft Bushing, lower	_
60032 U	Feed Driving Shaft Bushing, middle	5 6
60032 W	Feed Driving Shaft Bushing, upper	5
60034	Feed Bar (set screw No. 89)	10
60035	Feed Bar Shaft	6
60036	Feed Rocker	10
60036 G	Feed Rocker Shaft (set screw No. 719)	11
60036 N	Feed Rocker Shaft Bracket (screw, upper, No. 22528, screw, lower, No. 136, washer No. 80557)	
60036 U	Feed Rocker Shaft Bushing, upper	10
60036 W	Feed Rocker Shaft Bushing, lower	5 6
60037	Feed Drive Eccentric (spot screw No. 96, set screw No. 95)	6
60038	Feed Drive Eccentric Connecting Rod	11
60038 G	Feed Drive Eccentric Connecting Rod Bearing	7.1
	Sleeve (screw No. 22881)	6
60038 K	Feed Drive Eccentric Connecting Rod Bearing	
	Sleeve Thrust Washer	4
60038 N	Feed Drive Eccentric Connecting Rod Bearing	
	Sleeve Screw Nut	4
60040 A	Hook Shaft, upper section	2
60040 B	Hook Shaft Coupling (spot screw No. 22764, set	
00040 0	screw No. 88)	5
60040 C	Hook Shaft, lower section	13
60041	Hook Shaft Bushing, lower (screw No. 96 A)	5
60041 A	Hook Shaft Bushing, upper	5
60042 60043	Hook Shaft Collar (screw No. 88)	6
60044	Hook Shaft Driven Gear (screw No. 22560 A)	6
60051	Needle Thread Take-up Eyelet (screw No. 22542)	6
60058	Needle Bar Thread Eyelet, on Style 60000 C	4
	(screw No. 22516 A)	4
60058 A	Needle Bar Thread Eyelet, on Style 60000 D	-
	(screw No. 22516 A)	4
60058 G	Needle Bar Thread Eyelet Holder (screw No.	-
	Needle Bar Thread Eyelet Holder (screw No. 22516 A)	6
60062	Intermediate Gear Shaft (screw No. 22597 A,	_
	oil cup No. 666-11)	11
60064	Intermediate Gear Shaft Collar (screw No.	
	22528)	5
60065	Auxiliary Presser Foot Arm, on Style 60000 C	7
60065 G	Auxiliary Presser Foot Arm Spring, on Style	
60070	60000 C (screw No. 605 A)	8
60070	Bag Trimming Knife, upper (screw No. 77)	2
60071 60072	Bag Trimming Knife Holder (screw No. 22595)	1
60072 G	Bag Trimming Knife Eccentric Connecting Rod	11
00012 G	Bag Trimming Knife Eccentric Connecting Rod	-
60073	Thrust WasherBag Trimming Knife Bar	7
60073 G	Bag Trimming Knife Bar Bracket (screw No.	2
	22569)	10
		TO


Symbol	The figures in the last column refer only to the	
To Order By	plates illustrating the parts and are not to be used	Plate
- Cruer By	in ordering.	No.
60073 N	Bag Trimming Knife Bar Driving Stud (screw No.	
÷ 60075	Tape Cutter Knife, upper, on Style 60000 C	2
#P	(screw No. 22882, washer No. 12957 E)	2
60075 G	Tape Cutter Knife, lower (attaching screw No.	-
60075 K	22517 B, supporting screw No. 22775)	2
	Tape Cutter Upper Knife Bar Spring (support pin No. 61267 G)	8
60075 L	Tape Cutter Upper Knife Bar on Style 60000 C	°
	(adjusting screw No. 82, regulating screw No.	
	9663, adjusting screw lock nut No. 41071 G, stop screw No. 22517 D, stop screw lock nut	
00050	No. 12538)	10
60076	Tape Cutter Driving Eccentric (spot screw No.	
60076 G	96, set screw No. 95)	6
	(screw, front, No. 22559 A, screw, rear. No.	
60077	22559 B)	11
00011	Tape Cutter Bracket, on Style 60000 C (screw No. 22604, washer No. 652-20, dowel pin No.	
	60077 K)	9
60077 G	Tape Cutter Bracket Shaft, on Style 60000 C	Ü
60077 H	(set screw No. 81) Tape Cutter Bracket Shaft, on Style 60000 D	6
	(set screw No. 22839)	6
60077 Ј	Spacing Collar, for tape cutter upper knife bar	Ü
60077 K	on Style 60000 D	6
60078 A	Tape Cutter Upper Knife Operating Cam. on	6
60070 D	Style 60000 C	9
60078 B	Tape Cutter Upper Knife Operating Cam Dog, on Style 60000 C	_
60078 D	Tape Cutter Upper Knife Operating Cam Dog	7
60078 E	Spring, on Style 60000 C	8
00010 E	Tape Cutter Upper Knife Operating Cam Bushing, on Style 60000 C	_
60078 H	Tape Cutter Upper Knife Operating Ratchet Lever	5 10
60078 K	Tape Cutter Upper Knife Operating Pawl on	10
İ	Style 60000 C (adjusting screw No. 22874, adjusting screw nut No. 9937)	4.0
60078 M	Tape Cutter Upper Knife Operating Pawl Pin	10
Ī	(cotter pin No. 660-142 on Style 60000 C. collar	
60078 P	No. 1066 on Style 60000 D)	8
	on Style 60000 C	8
60078 S	Tape Cutter Upper Knife Operating Cam Dog	Ū
	Bracket, on Style 60000 D (attaching and adjusting screw No. 22596, nut No. 12934 A)	_
60078 T	Tape Cutter Upper Knife Cam Dog Spring, on	7
60070 77	Style 60000 D (stop screw No. 22738 A)	8
60078 U	Tape Cutter Upper Knife Operating Driving Pawl	
!	on Style 60000 D (screw No. 22560 A, nut No. 12934 A)	9
	,	ð

Symbol	The figures in the last column refer only to the	
To	plates illustrating the parts and are not to be used	Plate
Order By	in ordering.	No.
60078 V	Tape Cutter Upper Knife Pawl Operating Spring,	
	on Style 60000 D	8
60078 W	Tape Čutter Upper Knife Pawl Lever, on Style	
00000 37	60000 D	7
60078 X	Tape Cutter Upper Knife Pawl Lever Extension,	_
60078 Y	on Style 60000 D (screw No. HS24 C) Tape Cutter Upper Knife Pawl Lever Adjusting	7
00010 1	Block, on Style 60000 D (screw No. 90, spring	
	No. 21718)	7
60078 Z	Nut for 22738 D	7
60079	Tape Cutter Upper Knife Actuating Shoe, on	
60079 A	Style 60000 C (screw No. 90) Tape Cutter Upper Knife Actuating Shoe Stop, on	9
00019 A	Style 60000 C (screw No. 357)	2
60079 B	Tape Cutter Upper Knife Actuating Shoe Bracket,	2
	on Style 60000 C (screw No. 93, washer No.	
	35772 H)	2
60079 C	Tape Cutter Upper Knife Actuating Shoe Support,	
·	on Style 60000 C (attaching screw No. 22528, adjusting screw No. 22795)	-
60079 D	Tape Cutter Upper Knife Actuating Lever, on	7
	Style 60000 C	10
60079 F	Tape Cutter Upper Knife Actuating Lever Stud	5
60079 H	Tape Cutter Upper Knife Actuating Lever Spring,	
60070 12	on Style 60000 C	8
60079 K	Tape Cutter Upper Knife Actuating Lever Link, on Style 60000 C	7
60079 M	Tape Cutter Upper Knife Actuating Lever Link	•
	Pin, on Style 60000 C (cotter pin No. 660-142)	6
60079 N	Tape Cutter Upper Knife Actuating Shoe, on	
60050 D	Style 60000 D (screw No. 90)	9
60079 P	Tape Cutter Upper Knife Actuating Lever, on Style 60000 D (pin No. 1740)	0
60079 Q	Tape Cutter Upper Knife Actuating Lever Extension,	9
	on Style 60000 D (screw No. 25 S)	10
60079 R	Tape Cutter Upper Knife Actuating Lever Spring,	
	on Style 60000 D	8
60079 S	Tape Cutter Upper Knife Actuating Trip Dog, on	
	Style 60000 D (screws Nos. 22799 H, 22812, nut No. 43443 Q)	7
60079 U	Upper Knife Actuating Trip Dog Spring and	,
	Holder, complete, on Style 60000 D (spring	
·	attaching screw No. 91 A)	7
60082 G	Feed Driving Shaft Gear Case Cover (screw No.	
60082 H	Feed Driving Shaft Gear Case Cover Gasket	13
‡60090	Main Shaft Bushing Housing	13 11
60090 G	Main Shaft Bushing, lower	5
60090 H	Main Shaft Bushing, upper	5
60091	Main Shaft Crank and Upper Bag Trimming	
	Knife Eccentric, on Style 60000 C (spot screw	
	No. 22597, set screw No. 22597 A, crank pin screw No. 22570 A	10
60091 G	Main Shaft Crank Pin (screw No. 22570 A)	12 5
<u> </u>		

Symbol	The figures in the last relumn of	
To	The figures in the last column refer only to the	
Order By	plates illustrating the parts and are not to be used in ordering.	Plate
Order by	m ordering.	No.
60092 F-14	Needle Thread Tension Spring, .047 inch	
· · · ·	diameter wire	8
60093	Intermediate Needle Thread Nipper Eccentric	
**(2)	(spot screw No. 96)	5
60093 C	Intermittent Needle Thread Nipper Operating	Ū
	Plunger	8
60093 G	Intermittent Needle Thread Nipper Operating	
**************************************	Plunger Sleeve	5
60093 K	Intermittent Needle Thread Nipper Operating	_
60093 P	Plunger Sleeve Holder (screw No. 22560 B)	5
60093 T	Intermittent Needle Thread Nipper Releasing Pin	8
60096	Intermittent Needle Thread Nipper Tension Post Bed Mounting Shim (screw No. 22570 A)	8
K60901	Pulley Rim working diameter 4 1/4 inches	12
1100001	Pulley Rim, working diameter 4 1/4 inches, grooved for No. 2 "V" belt (screw No. 80)	13
K61096	Main Shaft Crank and Upper Bag Trimming Knife	13
	Eccentric on Style 60000 D (spot screw No.	
	22597, set screw No. 22597 A. crank pin screw	
	No. 22570 A) REPLACED BY No. 60091 A	11
61233 N	Feed Lift Link (screw No. 22845 D, nut No.	
	12538)	2
61242	Collar, for tape cutter upper knife actuating	
	lever stud (screw No. 88)	6
61254	Needle Bar Bushing, front	5
61254 A 61255	Needle Bar Bushing, rear	6
61255 G	Needle Bar Connection (screw No. 22562 A)	2
61256 G	Needle Bar Link (felt wick No. 666-37)	2
61257	Presser Bar	4 11
61257 G	Presser Bar Bushing, front, and Presser	11
inger	Spring Regulator	5
61259	Presser Bar Connection (set screw No. 95)	7
61260	Main Shaft Gear (screw No. 22839 C)	12
61261	Feed Driving Shaft Intermediate Gear	12
61263	Feed Driving Shaft Intermediate Gear Bushing	5
61265	Hand Lifter (screw No. 22799 M)	10
61267 G	Tape Cutter Upper Knife Bar Spring Pin	6
61282 B	Face Plate (screw No. 22837)	13
61282 C 61292 H	Face Plate Pin	8
61293 N	Tension Release Washer	4
01255 N	Plug, .814 inch diameter, for lower section of arm	_
61330 B-35	Hinge Pin, for presser foot bottom on Style	5
2200 2 00	60000 C	6
61356	Presser Spring	11
K62206	Tape Cutter Upper Knife Bar, on Style 60000 D	11
i	(adjusting screw, No. 82, regulating screw,	
	No. 9663, adjusting screw lock nut. No.	
	41071 G) REPLACED BY No. 60075 L	10
K62208	Tape Cutter Bracket, on Style 60000 D (screw	
	No. 22604, washer No. 652-20, dowel pin No.	
i	60077 K) REPLACED BY No. 60077	9

Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering.	Plate
K62210	Tape Cutter Upper Knife Operating Cam Dog, on Style 60000 D (screw No. 9846, nut No. 12934 A, stop screw, upper, No. 22799 D, stop screw, lower, No. 22799 M) REPLACED	
K62216	BY No. 60078 Q, 60078 R	7
80557 B80621 B	Washer, for feed rocker shaft bracket	2 4
D00021 B	Pulley Rim, working diameter 4 1/4 inches, grooved for round belt (screw No. 80)	13





#### **WORLDWIDE SALES AND SERVICE**

Union Special Corporation maintains sales and service facilities throughout the world. These offices will aid you in the selection of the right sewing equipment for your particular operation. Union Special Corporation representatives and service technicians are factory trained and are able to serve your needs promptly and efficiently. Whatever your location, there is a qualified representative to serve you.

Brussels, Belgium Charlotte, N.C. El Paso, TX Hong Kong, China Huntley, IL Leicester, England Lille, France Miami, FL Milan, Italy Möglingen, Germany Montreal, Quebec Osaka, Japan Santa Fe Springs, CA

Other Representatives throughout all parts of the world.



