



293

Unterklassen-Ausstattung
Subclass parts
Composition des sous-classes
Composición de las subclases











Unterklassen-Ausstattung
Subclass organizations

Equipement des sous-classes
Dotación de las subclases

Unterklasse Subclass Sous-classe Subclase	Ausführung Model Version Tipo de máquina	Nadelstange Needle bar Barre à aiguille Barra de aguja	Stoffschieber ⁴ Feed dog Griffe Transportador inferior	Stichplatte ⁴ Needle plate Plaque à aiguille Placa de aguja	Nähfuß ⁴ Presser foot Pied presseur Pie prensateelas	Fingerschutz Finger guard Protège-digits Salvadedos
-750/01-4/01	BN	91-009 678-91	91-046 440-04	91-045 600-04	91-141 232-13	91-012 658-91
-750/01-4/01-900/56	BN	91-009 678-91	91-059 186-04	91-158 225-04	91-141 232-13	91-012 658-91
-944/01	BN	91-009 678-91	91-046 440-04	91-045 600-04	91-051 255-93	91-157 813-91
-944/01-900/56	BN	91-009 678-91	91-059 186-04	91-158 225-04	91-051 255-93	91-157 813-91

⁴ = Ausführung angeben
 = indicate model
 = Préciser la version
 = Indíquese el tipo de máquina

Unterklassen-Übersicht/ Table of subclasses/ Table des sous-classes/ Tabla de subclases

<p>91-009 678-91</p> 	<p>91-046 440-04 ⁴</p> 	<p>91-059 186-04 ⁴</p> 	<p>91-045 600-04 ⁴</p> 
<p>-750/01-4/01 -944/01</p>	<p>-750/01-4/01-900/56 -944/01-900/56</p>	<p>-750/01-4/01-900/56 -944/01-900/56</p>	<p>-750/01-4/01 -944/01</p>
<p>-750/01-4/01 -750/01-4/01-900/56 -944/01 -944/01-900/56</p>	<p>91-158 225-04 ⁴</p> 	<p>91-051 255-93 ⁴</p> 	<p>91-141 232-13</p> 
<p>-750/01-4/01 -750/01-4/01-900/56 -944/01 -944/01-900/56</p>	<p>91-012 658-91</p> 	<p>11-108 222-15</p> 	<p>91-157 813-91</p> 
<p>-750/01-4/01 -750/01-4/01-900/56</p>	<p>-750/01-4/01 -750/01-4/01-900/56</p>	<p>-944/01 -944/01-900/56</p>	<p>-944/01 -944/01-900/56</p>

Pfaff, D 6750 Kaiserslautern, Postfach 3020/3040, Telefon (0631) 200-0, Telex: 45753, Telefax (0631) 17202