



ILLUSTRATED PARTS LIST FOR



SINGER Machine

107G235


THE SINGER COMPANY



107 G 235 - 10 (0671)

160-850	ARM COVER (TOP) SCREW (2)
160-850	FACE PLATE SCREW
1186-850	ARM COVER (TOP) SCREW (2)
1186-850	FACE PLATE SCREW
1654-850	THREAD RETAINER NUT
51220-833	THREAD GUIDE (UPPER) SCREW
200582-850	THREAD GUIDE (LOWER) SCREW

202412	THREAD GUIDE (ON TOP OF ARM)
210593	THREAD GUIDE (LOWER)
502667	THREAD RETAINER
508153	ARM COVER (TOP)
508154	FACE PLATE
508166	THREAD GUIDE (UPPER)



107 G 235 - 20 (0671)


238-650	BED SLIDE SPRING SCREW (2)
141567-633	MACHINE PULLEY POSITION SCREW
200577-633	MACHINE PULLEY SET SCREW
200577-633	BED PLATE SCREW (2)
210505-633	BED PLATE (BACK) SCREW (2)
210505	BED PLATE (BACK)
210616	BED SLIDE (FRONT) CPL. NOS. 508506 AND TWO EACH 238
224485	THROAT PLATE

272142	ARM SHAFT BALL (BACK)
500196-850	MACHINE GROUNDING WIRE SCREW
500350-850	TAKE-UP LEVER GUARD SCREW (2)
508150	MACHINE PULLEY CPL. NOS. 141566, 141567 AND 272142
508167	ARM SHAFT BUSHING (FRONT) OIL PACKING PLUG
508168	NEEDLE BAR FRAME CAP
508216	TAKE-UP LEVER GUARD
508506	BED SLIDE SPRING
512008	MACHINE GROUNDING WIRE LOCK WASHER
603291	MACHINE GROUNDING WIRE SYMBOL

PART NO. DESCRIPTION

PART NO. DESCRIPTION


NEEDLE BAR AND TAKE-UP MECHANISM



200132-850	TAKE-UP (AUXILIARY) SCREW
200335-850	NEEDLE BAR CRANK SET SCREW
200341-850	ARM SHAFT BUSHING (FRONT) SET SCREW
200374-850	NEEDLE BAR CONNECTING LINK STUD SET SCREW
200383-850	TAKE-UP LEVER HINGE STUD SET SCREW
200387-850	NEEDLE BAR CONNECTING LINK STUD SET SCREW
200388-850	NEEDLE BAR SET SCREW
200389-850	NEEDLE BAR CRANK LOCK SCREW
200390-850	NEEDLE BAR CRANK POSITION SCREW
200391-850	ARM SHAFT BUSHING (FRONT) PACKING (WICK)
200392-850	ARM SHAFT WITH 204392
200393-850	NEEDLE BAR CONNECTING LINK STUD OIL PACKING (WICK)
200394-850	NEEDLE BAR CONNECTING LINK STUD OIL PACKING (WICK)
200395-850	NEEDLE BAR CONNECTING LINK STUD WITH 202299
200396-850	TAKE-UP LEVER DRIVING STUD WITH 244071
200397-850	TAKE-UP LEVER HINGE STUD WITH 202423
200398-850	TAKE-UP LEVER HINGE STUD OIL PACKING (WICK)
200399-850	NEEDLE BAR CRANK FRICTION WASHER

207080	ARM SHAFT BUSHING (FRONT) WITH 202244
210543	NEEDLE BAR CONNECTING LINK
210544	NEEDLE BAR CONNECTING STUD WITH 202299
210585	NEEDLE BAR CONNECTING STUD CPL. NOS. 210544 AND 210582
210591	TAKE-UP (AUXILIARY)
210725	NEEDLE BAR CRANK CPL. NOS. 200335, 200374, 200383, 200432 AND 202333
210852	NEEDLE BAR CONNECTING STUD SWIVEL WITH 200387
210883	NEEDLE BAR CRANK CPL. NOS. 202399, 202400, 210543, 210585, 210725 AND 244059
224392	ARM SHAFT OIL PACKING (WICK)
244059	TAKE-UP LEVER
244071	TAKE-UP LEVER DRIVING STUD OIL PACKING (WICK)
396535	NEEDLE BAR CRANK WITH TAKE-UP (AUXILIARY) CPL. NOS. 200132, 210591 AND 210883


107 G 235 - 30 (0671)



107 G 235 - 40 (0671)

1901-16-1	NEEDLE
200070-650	NEEDLE BAR FRAME PITMAN ECCENTRIC STUD SET SCREW
200125-633	NEEDLE SET SCREW
200172-650	THREAD GUIDE SCREW
200175-650	NEEDLE THREAD GUIDE SCREW
200334-633	NEEDLE BAR FRAME HINGE
210542-633	GUIDE STUD SET SCREW
210542	NEEDLE BAR FRAME CPL. NOS. 210546 AND 224317
210546	NEEDLE BAR FRAME WITH 200070

210547	NEEDLE BAR FRAME GUIDE STUD
210557	NEEDLE BAR FRAME PITMAN ECCENTRIC STUD
224317	NEEDLE BAR CPL. NOS. 200125, 200175 AND 249270
224387	THREAD GUIDE
249270	NEEDLE BAR THREAD GUIDE
396536	NEEDLE BAR FRAME CPL. NOS. 200172, 210542 AND 224387
508163	NEEDLE BAR FRAME HINGE STUD



107 G 235 - 50 (0671)


200074-850	PRESSER FOOT SCREW
200086-833	PRESSER BAR POSITION GUIDE LEVER PINCH SCREW
200132-850	TAKE-UP LEVER OILING FELT SCREW
200260-850	PRESSER BAR LIFTING/RELEASING LEVER BRACKET
	GUIDE SCREW
200352-833	PRESSER BAR POSITION GUIDE SET SCREW
200352-833	PRESSER BAR BUSHING SET SCREW
200475-850	PRESSER BAR BUSHING (UPPER) THUMB SET SCREW
200653-850	PRESSER BAR LIFTER HINGE SCREW
201497-850	PRESSER BAR THUMB SCREW (PRESSURE REGULATING)
202401	TAKE-UP LEVER OILING FELT
202335	PRESSER BAR CPL. NOIS. 200074 AND 244033
202337	PRESSER BAR POSITION GUIDE
202338	PRESSER BAR POSITION GUIDE LEVER WITH 200086
206608	PRESSER BAR LIFTING/RELEASING LEVER BRACKET
	SPRING

207072	PRESSER BAR BUSHING
210758	PRESSER BAR SPRING (LIGHT)
224478	PRESSER BAR BUSHING (UPPER)
224479	PRESSER FOOT
236106	PRESSER BAR SPRING STOP ROD
244033	PRESSER BAR (HOLLOW)
244084	PRESSER BAR BUSHING (UPPER) THUMB SET SCREW
	PACKING FIBRE
508157	PRESSER BAR LIFTING/RELEASING LEVER BRACKET
508215	PRESSER BAR LIFTER
508219	PRESSER BAR WASHER

PART NO. DESCRIPTION

PART NO. DESCRIPTION


THREAD TENSION, TENSION RELEASING DEVICE



107 G 235 - 60 (0671)



50305-850	THREAD STUD SET SCREW
140321-850	THREAD CONTROLLER SPRING REGULATOR SET SCREW
200397-633	THREAD RETAINER STUD SET SCREW
200582-850	THREAD GUIDE SCREW
202410	THREAD CONTROLLER SPRING
210956	THREAD RETAINER BRACKET WITH 200397
210957	THREAD RETAINER STUD
210958	THREAD RETAINER STUD COLLAR
210992	THREAD RETAINER SPRING
210993	THREAD RETAINER SLEEVE
223438	TENSION SPRING
244048	TENSION DISC (BACK)
244049	TENSION DISC (FRONT)
263547	TENSION RELEASE WASHER

263548	TENSION RELEASING PIN
263550	TENSION STUD WASHER
263552	THREAD CONTROLLER SPRING REGULATOR WITH 50305
350613-806	TENSION STUD WITH 263550
500795	TENSION THUMB NUT
508179	TENSION CPL. NOS. 202410, 223438, 244048, 244049, 263547, 263548, 263552, 350613, 500795 AND 508180
508180	TENSION SPRING WASHER
508182	TENSION RELEASE PLUNGER
508196	THREAD RETAINER BRACKET CPL. NOS. 210957, 210958, 210992, 210993 AND 210956



200354-850	NEEDLE BAR FRAME PITMAN PINCH SCREW
200356-850	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET HINGE AND STOP SCREW 2
200376-650	NEEDLE VIBRATING GEAR SHAFT COLLAR SET SCREW (2)
200380-650	NEEDLE VIBRATING GEAR SET SCREW 2
200383-650	NEEDLE VIBRATING REGULATING SCREW CHECK SCREW
200393-650	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET FLANGE SCREW 2
200429-650	NEEDLE VIBRATING REGULATING SCREW
200467-650	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET FLINGER SPRING STOP SCREW
201526-850	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET HINGE AND STOP SCREW NUT 2
202277	NEEDLE BAR FRAME PITMAN OIL PACKING (WICK)
202300	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET
202301	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET PLUNGER


203172	NEEDLE VIBRATING GEAR FRICTION WASHER
210550	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET CPL. NOS. 202300, 210552 AND TWO EACH 200256 AND 201525
210552	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET FLANGE WITH TWO 200383
210556	NEEDLE BAR FRAME PITMAN CPL. NOS. 200054 AND 202277
210559	NEEDLE VIBRATING GEAR SHAFT COLLAR WITH TWO 200378
210699	NEEDLE VIBRATING GEAR (SPIRAL) WITH TWO 200382
508164	NEEDLE VIBRATING GEAR SHAFT
508211	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET PLUNGER SPRING



107 G 235 - 80 (0671)

200566-650 NEEDLE VIBRATING GEAR SHAFT FLANGE SCREW (3)
 500345-650 NEEDLE VIBRATING GEAR SHAFT FLANGE COVER SCREW (3)
 508170 NEEDLE VIBRATING GEAR SHAFT FLANGE
 508171 NEEDLE VIBRATING REGULATION ADJUSTING UNIT CPL.
 NOS. 508172 TO 508174

508172 NEEDLE VIBRATING GEAR SHAFT FLANGE COVER
 508173 BIGHT AMPLITUDE ADJUSTING KNOB
 508174 BIGHT AMPLITUDE ADJUSTING KNOB RETAINER




107 G 235 - 100 (0671)

200106-850 FEED DOG SCREW (2)
 200383-850 FEED DRIVING ROCK SHAFT STOP COLLAR SET SCREW (4)
 200641-800 FEED BAR HINGE SCREW (DRIVING)
 201522-800 FEED HINGE SCREW (DRIVING) NUT
 202625 FEED DRIVING ROCK SHAFT

202625 FEED DRIVING ROCK SHAFT STOP COLLAR (2) WITH
 FOUR 200383
 210512 FEED BAR
 210513 FEED BAR CPL. NOS. 200641, 201522, 202623 AND 210512
 210516 FEED DOG

PART NO. DESCRIPTION


PART NO. DESCRIPTION



107 G 235 - 110 (0671)

1518-B50	PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW NUT
1620-B50	PULLER FEED CLUTCH DRIVING CONNECTION HINGE SCREW NUT
200035-B50	PULLER FEED CLUTCH DRIVING CRANK PINCH SCREW
200039-B50	PULLER FEED ROLL (LOWER) SHAFT BRACKET SCREW (4)
200337-B50	PULLER FEED CLUTCH CAP RETAINING SCREW STUD SCREW
200374-B33	PULLER FEED ROLL (LOWER) SET SCREW
200386-B33	PULLER FEED ROLL (LOWER) SHAFT COLLAR SET SCREW (2)
200396-B33	PULLER FEED ROLL (LOWER) POSITION SCREW
201201-B50	PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW
201531-B50	PULLER FEED CLUTCH CAP RETAINING SCREW STUD SCREW NUT


205797	PULLER FEED ROLL (LOWER) SHAFT COLLAR WITH 200386
224480	PULLER FEED CLUTCH DRIVING CONNECTION
224498	PULLER FEED ROLL (LOWER) SHAFT
225585	PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW WASHER
237007	PULLER FEED CLUTCH DRIVING CRANK WITH 200035
237077	PULLER FEED ROLL (LOWER) RUBBER FACED CPL. NOS. 200374 AND 200396
237019	PULLER FEED ROLL (LOWER) SHAFT BRACKET (2)
500378-B50	PULLER FEED CLUTCH DRIVING CONNECTION HINGE SCREW



107 G 235 - 120 (0671)

1036-830 PULLER FEED CLUTCH (DRIVE) CONNECTION SET SCREW
 50375-806 PULLER FEED CLUTCH SLEEVE SET SCREW (2)
 68152 PULLER FEED CLUTCH ROLLER PLUNGER (6)
 131717 PULLER FEED CLUTCH ROLLER (6)
 131725 PULLER FEED CLUTCH WASHER
 200106-833 PULLER FEED CLUTCH CAP SCREW (3)
 200570-850 PULLER FEED COVER PLATE SCREW (2)
 201457-850 PULLER FEED CLUTCH CAP RETAINING SCREW STUD
 224488 PULLER FEED CLUTCH (BRAKE) CPL. NOS. 224488 AND 263574
 224490 PULLER FEED CLUTCH CAP
 224491 PULLER FEED CLUTCH (DRIVE)


224492 PULLER FEED CLUTCH (DRIVE) CPL. NOS. 224491 AND 263574
 224494 PULLER FEED CLUTCH ROLLER SPRING (6)
 224495 PULLER FEED CLUTCH SLEEVE WITH TWO 50375
 224496 PULLER FEED CLUTCH CPL. NOS. 131725, 201457, 224489,
 224490, 224492, 224495, 268442 WITH THREE 200106 AND
 SIX EACH 68152, 131717 AND 224494
 237016 PULLER FEED COVER PLATE
 263574 PULLER FEED CLUTCH ROLLER WEAR PLATE (6)
 268442 PULLER FEED CLUTCH (DRIVE) CONNECTION CPL. NOS.
 1036 AND 350636
 350636-833 PULLER FEED CLUTCH (DRIVE) CONNECTION FINCH SCREW



107 G 235 - 130 (0671)

200038-ES0	FEED DRIVING CONNECTION CRANK PINCH SCREW
200050-ES0	FEED LIFTING CONNECTION CRANK PINCH SCREW
200054-ES0	FEED DRIVING CONNECTION PINCH SCREW
200054-ES0	FEED LIFTING CONNECTION PINCH SCREW
200378-ES0	FEED LIFTING CONNECTION CRANK SET SCREW
200382-ES0	FEED LIFTING CONNECTION ECCENTRIC SET SCREW
200382-ES0	FEED LIFTING CONNECTION ECCENTRIC POSITION SCREW
200437-ES0	FEED DRIVING CONNECTION HINGE SCREW
200545-ES0	FEED LIFTING CONNECTION HINGE SCREW
201518-ES0	FEED DRIVING CONNECTION HINGE SCREW NUT
201518-ES0	FEED LIFTING CONNECTION HINGE SCREW NUT
202297	FEED DRIVING CONNECTION CPL. NOS. 200054 AND 203101
202306	FEED LIFTING CONNECTION CPL. NOS. 200054 AND 203101


202624	FEED DRIVING CONNECTION CRANK WITH 200038
203101	FEED LIFTING CONNECTION OIL PACKING WICK
203101	FEED DRIVING CONNECTION OIL PACKING WICK
210589	FEED LIFTING CONNECTION CRANK CPL. NOS. 200050, 200378 AND 210645
210645	FEED LIFTING CONNECTION CRANK
210700	NEEDLE VIBRATING PINION (SPIRAL) WITH TWO 200382
266053	FEED LIFTING CONNECTION ECCENTRIC CPL. NOS. 200382 AND 200437
396530	FEED LIFTING CONNECTION CPL. NOS. 200545, 201518, 210589 AND 210645
396533	FEED DRIVING CONNECTION CPL. NOS. 200545, 201518, 210589 AND 210645



107 G 235 - 140 (0671)

200327-833	ARM SHAFT CONNECTION BELT PULLEY SET SCREW
200383-850	FEED DRIVING ECCENTRIC REGULATING SCREW CHECK SCREW
200429-850	FEED DRIVING ECCENTRIC REGULATING SCREW
200602-850	ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW
200607-850	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER SPRING STOP SCREW
201014-850	FEED DRIVING ECCENTRIC REGULATING BRACKET STOP AND HINGE SCREW (2)
201525-850	FEED DRIVING ECCENTRIC REGULATING BRACKET STOP SCREW AND HINGE SCREW (2)
202253	ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)


202300	FEED DRIVING ECCENTRIC REGULATING BRACKET
202301	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER
202635	ARM SHAFT CONNECTION BELT PULLEY CPL. NOS. 200327, 200602 AND TWO 202253
203098	FEED DRIVING ECCENTRIC REGULATING BRACKET CPL. NOS. 202300, 202635 AND TWO EACH 201014 AND 201525
224400	ARM SHAFT CONNECTION BELT (REINFORCED NITRILE) SPRING
237523	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER SPRING
508155	FEED REGULATING SPINDLE INSERT



107 G 235 - 150 (0671)

200253-E50	FEED BAR SLIDE BLOCK CRANK PINCH SCREW
2002276-E50	FEED BAR SLIDE BLOCK CRANK PINCH SCREW
200035-E50	HOOK SHAFT BUSHING SET SCREW
202276-E50	HOOK DRIVING LEVEL PINION SHAFT BELT PULLEY SET SCREW (2)
202625-E50	HOOK DRIVING LEVEL PINION SHAFT BELT PULLEY SET SCREW (2)
210514-E50	FEED BAR SLIDE BLOCK CRANK WITH 200035
210531-E50	FEED BAR SLIDE BLOCK CRANK WITH 200035
210535-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
210614-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
210615-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
200335-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
244084-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
200363-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
200335-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
244084-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
200363-E50	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)


210514	FEED BAR SLIDE BLOCK CRANK WITH 200035
210515	FEED BAR SLIDE BLOCK CRANK WITH 200035
210531	FEED BAR SLIDE BLOCK CRANK WITH 200035
210535	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
210614	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
210615	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
200335	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
244084	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
200363	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
200335	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
244084	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)
200363	FEED LIFTING HOOK SHAFT STOP COLLAR SET SCREW (2)



107 G 235 - 160 (0671)

200076-850	BOBBIN CASE STOP SCREW
200145-850	HOOK WASHER NEEDLE GUARD SCREW
200592-850	BOBBIN CASE TENSION SPRING SCREW
200964-850	HOOK GIB SCREW (3)
210735-850	BOBBIN CASE LATCH STOP SCREW
210736-850	BOBBIN CASE TENSION SPRING REGULATING SCREW
210541	HOOK GIB
210536	HOOK WASHER NEEDLE GUARD
210734	BOBBIN CASE LATCH LEVER
210735	BOBBIN CASE LATCH FULCRUM PIN
210736	BOBBIN CASE LATCH SPRING
210764	BOBBIN CASE STOP
210914	BOBBIN CASE CAP


210913	BOBBIN CASE LATCH
210914	BOBBIN CASE LATCH CPL. NOS. 210734, 210735 AND 210913
224432	HOOK (SEWING)
224433	HOOK CPL. NOS. 200145, 210536, 210541, 224432 WITH THREE 200596
224440	BOBBIN CASE CAP CPL. NOS. 200592, 201016 AND 508530
224441	BOBBIN CASE CAP CPL. NOS. 200964, 210736, 210914 AND 224440
224442	BOBBIN CASE CPL. NOS. 210846 AND 224441
224443	HOOK AND BOBBIN CASE CPL. NOS. 224433 AND 224442
233028	BOBBIN
508530	BOBBIN CASE TENSION SPRING



107 G 235 - 170 (0671)

200082	FOOT LIFTER LEVER EXTENSION SCREW (2)
200242	FOOT LIFTER LIFTING LEVER HINGE SCREW
200273	FOOT LIFTER LIFTING LEVER SPRING SCREW
224475	FOOT LIFTER LIFTING LEVER
224476	FOOT LIFTER LIFTING LEVER EXTENSION





224486	FOOT LIFTER LIFTING LEVER ROD
232131	FOOT LIFTER LIFTING LEVER WASHER
233390	FOOT LIFTER LIFTING LEVER WASHER
508195	FOOT LIFTER LIFTING LEVER SPRING







107 G 235 - 190 (0671)

001405-E50 ATTACHMENT SCREW
 228391 DOWEL WITH FOUR 511599
 511599-005 DOWEL WOOD SCREW (4)


512021 GROUNDING WIRE WASHER
 603271 GROUNDING WIRE



107 G 235 - 200 (0671)




107 G 235 + 210 (0671)



107 G 235 - 220 (0671)

200530-650 FOOT LIFTER LIFTING LEVER ROD COUPLING
SCREW
203058 FOOT LIFTER LIFTING LEVER ROD COUPLING WITH
200530

228430 FOOT LIFTER LIFTING LEVER CHAIN
228440 FOOT LIFTER LIFTING LEVER CPL. NOS. 228430 AND
TWO 511591
511591-625 FOOT LIFTER LIFTING LEVER MOUNTING WOOD SCREW (2)



107 G 235 - 230 (0671)

500416-805	PULLEY SET SCREW
500417-819	STOP LATCH TRIP LEVER HINGE SCREW
500418-819	STOP LATCH SCREW
500419-819	BRAKE CLAMP SCREW
500420-819	TENSION BRACKET SCREW
500602-819	TENSION STUD THUMB NUT
503780	UNIVERSAL BOBBIN WINDER FOR 1/4" BELT DRIVES CPL. NOS. 500417, 500418, 500419, 502903, 502904, 503906, 503907, 503908, 503909, 503910, 502911, 502912, 503912, 502913, 503914, 503915, 502916 AND 503772
503903	BOBBIN WINDER AND TENSION BRACKET BASE
503904	FRAME WITH 503905
503905	FRAME OIL CUP (PLASTIC)
503906	FRAME HINGE PIN
502907	FRAME SPRING FLUNGER
503908	FRAME SPRING
503909	SPINDLE

503910	PULLEY WITH 500416
503911	STOP LATCH THUMB LEVER
503912	STOP LATCH TRIP LEVER
503913	STOP LATCH THUMB LEVER HINGE JOINT STUD
503914	STOP LATCH
503915	BRACKET (RUBBER)
503916	BRAKE CLAMP
503917	TENSION BRACKET WITH 503918
503918	TENSION STUD
503919	TENSION DISC
503920	TENSION SPRING
503921	TENSION BRACKET SCREW WASHER
503922	TENSION BRACKET CPL. NOS. 500420, 500802, 503917, 503920, 503921 AND TWO 503919
511604-805	BOBBIN WINDER MOUNTING WOOD SCREW (2)