

**SINGER**  
**111W106**

Form 2676w

( 940 )


Printed in U. S. A.

# SINGER

III w 106




**THE SINGER MANUFACTURING COMPANY**



Copyright, U. S. A., 1934, 1939 and 1940  
by The Singer Manufacturing Co.  
All Rights Reserved for all Countries

13067 - 1/2

120342



225498



225497



41400




225554



16245 - 1/2


223651

224051




16247

237204




224115




16248 - 2/3


237193




224023




16609 - 1/2




16615 - 1/2




16643 - 3/8




16644 - 1/3




16645 - 3/8




16646 - 3/8




16647 - 3/8




16648 - 1/2




16649 - 1/2




16650 - 2/3



16651 - 2/3



16652 - 3/8



16653 - 3/4

