

SINGER
111W107

Form 3152w
(857)
Printed In U.S.A.

LIST OF PARTS
SINGER** SEWING MACHINE

111w107

THE SINGER MANUFACTURING COMPANY

**A Trademark of THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the PART number in the FIRST column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above case) must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

AL	Heat Treated for Toughness.
ALX	Heat Treated for Toughness and Black Oxide.
C	Hardened only.
D	Polished only.
E	Soft, Not polished.
F	Hardened and Polished.
X	Black Oxide, for Iron and Steel.

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series:

1 to 1500, 200001 to 201500 and 350001 to 351500 are Screw Numbers.
1501 to 1800, 201501 to 201800 and 351501 to 351800 are Nut Numbers.
1801 to 2000, 201801 to 202000 and 351801 to 352000 are Roller Numbers.
2001 to 50000 and 202001 to 350000 are Numbers of Machine Parts.

The figures in the second column refer only to the plate in which the illustration of the part is shown and are NOT TO BE USED in ordering. These Plates are in Form 20500, Illustrations of Parts.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE
FOR
MACHINE NO. 111w107
LOCK STITCH. BELT DRIVEN.
VERTICAL HOOK. VERTICAL TRIMMER.
COMPOUND FEED.
MAXIMUM STITCH 7 TO THE INCH.
FOR TRIMMING AND BINDING SHEEP-
SKIN, CLOTH AND SIMILAR MATERIAL.

No.	Plate	Name
*240301	-----	Arm with 202135
224002	16654	Arm Cap
200278X	16654	Arm Cap Screw
202248	16654	Arm Cap Screw Washer
204235	16613	Arm Position Pin (2)
200004E	16613	Arm Screw (3)
202005	16613	Arm Screw Washer (3)
224102	13241	Arm Shaft with 224392 and 350431E
240802	16654	Arm Shaft Bushing (back) with 202244
202244	16654	Arm Shaft Bushing (back) Oil Packing (wick)
200338C	16654	Arm Shaft Bushing (back) Set Screw
207080	16654	Arm Shaft Bushing (front) with 202244
202244	16654	Arm Shaft Bushing (front) Oil Packing (wick)
200502X	16654	Arm Shaft Bushing (front) Oil Packing Thumb Screw
200341C	16654	Arm Shaft Bushing (front) Set Screw
224195	16604	Arm Shaft Connection Belt (reinforced neoprene)
224104	16655	Arm Shaft Connection Belt Pulley with 200327C, 200602E and two 202253
200602E	16655	Arm Shaft Connection Belt Pulley Position Screw
200327C	16655	Arm Shaft Connection Belt Pulley Set Screw
202253	16655	Arm Shaft Connection Belt Pulley Spring Flange
241113	16659	Arm Shaft Connection Belt Timing Collar with 200113F
200113F	16659	Arm Shaft Connection Belt Timing Collar Set Screw
240359	16677	Arm Shaft Connection Belt Timing Plate
200164X	16659	Arm Shaft Connection Belt Timing Plate Screw (2)
224392	16654	Arm Shaft Oil Packing (wick)
350431E	16654	Arm Shaft Oil Packing Stop Screw
*240302	-----	Bed
54897	16659	Bed Oil Cup
240303	16682	Bed Plate
200577XC	16682	Bed Plate Screw

PARTS FOR MACHINE NO.111w107

No.	Plate	Name
240304	16682	Bed Slide (back)
200462X	17071	Bed Slide (back) Locking Thumb Screw
264642	16116	Bed Slide (back) Stop with 200462X
200056E	17072	Bed Slide (back) Stop Screw (2)
240254	16652	Bed Slide (front)
259203	16682	Binder and Folder for strips of various widths Furnish sample of binding and material to be bound.
200507X	16682	Binder and Folder Screw
259204	16682	Binder and Folder complete, Nos.240304,240352, 259203,two each 200139E and 200507X
203470	16247	Bobbin
*233764	-----	Bobbin Case
203648	17072	Bobbin Case Latch
*202056	-----	Bobbin Case Latch Pin
203473	17072	Bobbin Case Latch Plunger
203474	17072	Bobbin Case Latch Spring
241674	17072	Bobbin Case Oiling Felt
241675	16247	Bobbin Case Oiling Felt Retainer
350405C	16687	Bobbin Case Oiling Felt Retainer Screw
224004	16249	Bobbin Case Opener
224005	16249	Bobbin Case Opener Lever with 201349C,201542C and 203101
201349C	16249	Bobbin Case Opener Lever Driving Screw Stud
201542C	16249	Bobbin Case Opener Lever Driving Screw Stud Nut
203101	16249	Bobbin Case Opener Lever Driving Screw Stud Oil Packing (wick)
265088	16274	Bobbin Case Opener Lever Hinge Stud with 202277
202277	16688	Bobbin Case Opener Lever Hinge Stud Oil Packing (wick)
200364C	16249	Bobbin Case Opener Lever Hinge Stud Set Screw
223623	16249	Bobbin Case Opener Lever Link
200118D	16249	Bobbin Case Opener Screw
203214	17072	Bobbin Case Tension Spring
200984C	17072	Bobbin Case Tension Spring Regulating Screw
200594E	17072	Bobbin Case Tension Spring Screw
203216	16247	Bobbin Case Washer (cloth)
233765	16167	Bobbin Case complete, Nos.200594E,200984C, 202056,203214,203216,203473,203474,203648, 233764,241674,241675 and two 350405C
237804	14186	Face Plate
202135	16613	Face Plate Position Pin
200473X	16613	Face Plate Thumb Screw
240305	16678	Feed Bar with 200336E and 201535E
240306	16678	Feed Bar 240305 with 200040AL,224052 and 225837
350393C	16656	Feed Bar Hinge Screw (driving)
201518E	16656	Feed Bar Hinge Screw Nut

PARTS FOR MACHINE NO.111w107

No.	Plate	Name
240307	16683	Feed Dog, 46 needle hole, for needle sizes 16 and 18, for 240338
200106E	16656	Feed Dog Screw (2)
200336E	16261	Feed Dog Support Screw
201535E	16678	Feed Dog Support Screw Nut
237565	14076	Feed Driving Connection with 200049D and 202330
201171C	16243	Feed Driving Connection Hinge Screw
201517E	16655	Feed Driving Connection Hinge Screw Nut
202277	16243	Feed Driving Connection Hinge Screw Oil Packing (wick)
202330	16243	Feed Driving Connection Oil Packing (wick)
200049D	16655	Feed Driving Connection Pinch Screw
237521	14072	Feed Driving Eccentric Regulating Bracket
237043	16124	Feed Driving Eccentric Regulating Bracket 237521 with 224108, two each 200256C and 201525E
224108	16655	Feed Driving Eccentric Regulating Bracket Flange with 200383C and 200437C
200437C	16655	Feed Driving Eccentric Regulating Bracket Flange Position Screw
200383C	16655	Feed Driving Eccentric Regulating Bracket Flange Set Screw
200256C	16655	Feed Driving Eccentric Regulating Bracket Hinge Screw
201525E	16655	Feed Driving Eccentric Regulating Bracket Hinge Screw Nut
202301	16655	Feed Driving Eccentric Regulating Bracket Plunger
237523	14072	Feed Driving Eccentric Regulating Bracket Plunger Spring
200607C	16655	Feed Driving Eccentric Regulating Bracket Plunger Spring Stop Screw
200256C	16655	Feed Driving Eccentric Regulating Bracket Stop Screw
201525E	16655	Feed Driving Eccentric Regulating Bracket Stop Screw Nut
200429F	16655	Feed Driving Eccentric Regulating Screw
200383C	16655	Feed Driving Eccentric Regulating Screw Check Screw
223650	16656	Feed Driving Rock Shaft
240311	16678	Feed Driving Rock Shaft 223650 with 201518E, 240306 and 350393C
223652	13204	Feed Driving Rock Shaft Crank with 200019E
200019E	16656	Feed Driving Rock Shaft Crank Pinch Screw
202625	16656	Feed Driving Rock Shaft Stop Collar with two 200383C (2)
200383C	16656	Feed Driving Rock Shaft Stop Collar Set Screw
240312	16677	Feed Lifting Cam with 201220C
224052	16261	Feed Lifting Cam Fork with 200173D and 223655
200040AL	16261	Feed Lifting Cam Fork Screw
225837	16656	Feed Lifting Cam Fork Screw Washer
223655	16656	Feed Lifting Cam Oiling Felt

PARTS FOR MACHINE NO.111w107

No.	Plate	Name
200173D	16656	Feed Lifting Cam Oiling Felt Screw
201220C	16659	Feed Lifting Cam Set Screw
224122	16654	Feed Regulating Spindle with 202311, 202443 and 202619
*202311	-----	Feed Regulating Spindle Head
202443	16654	Feed Regulating Spindle Head Pin
202619	16654	Feed Regulating Spindle Head Position Pin
*224016	16247	Hook (sewing)
224017	19111	Hook 224016 with 203525, 224025, two each 200590X and 201253F
240357	16663	Hook and Bobbin Case complete, Nos. 224017 and 233765
224019	16249	Hook Bushing (lower) (bronze)
200364C	16249	Hook Bushing (lower) Set Screw
224020	16249	Hook Bushing (upper) (bronze)
200446C	16249	Hook Bushing (upper) Position Screw
223867	16659	Hook Driving Gear (spiral) with 200362C and 201222C
201222C	16659	Hook Driving Gear Position Screw
200362C	16659	Hook Driving Gear Set Screw
224021	16249	Hook Driving Pinion (spiral) with two 200382ALX
200382ALX	16249	Hook Driving Pinion Set Screw
224022	16249	Hook Driving Pinion Thrust Washer
224110	13241	Hook Driving Shaft
224111	16659	Hook Driving Shaft Bushing (back) with 202244
202244	16659	Hook Driving Shaft Bushing (back) Oil Packing (wick)
200327C	16659	Hook Driving Shaft Bushing (back) Set Screw
223681	19110	Hook Driving Shaft Bushing (center)
200335C	16677	Hook Driving Shaft Bushing (center) Set Screw
224112	16659	Hook Driving Shaft Connection Belt Pulley with 202253 and two 201254C
201254C	16659	Hook Driving Shaft Connection Belt Pulley Set Screw
202253	16659	Hook Driving Shaft Connection Belt Pulley Spring Flange
203525	19111	Hook Gib
201253F	16247	Hook Gib Screw
248151	16654	Hook Saddle with 200009E, 200446C, 224019, 224020 and two 200364C
223680	13213	Hook Saddle Bearing
200327C	16659	Hook Saddle Bearing Set Screw
200009E	16649	Hook Saddle Pinch Screw
200006E	16649	Hook Saddle Screw
225585	16649	Hook Saddle Screw Washer
240315	16664	Hook Saddle complete, Nos. 200118D, 223623, 224004, 224005, 224021, 224022, 240357, 248151 and 265088
224025	16247	Hook Washer
200590X	16247	Hook Washer Screw
240067	14347	Knee Lifter Connection Lever

PARTS FOR MACHINE NO.111w107

No.	Plate	Name
200262X	14357	Knee Lifter Connection Lever Hinge Screw
223684	14359	Knee Lifter Connection Lever Lifting Rod with 202302
202302	16613	Knee Lifter Connection Lever Lifting Rod Cotter Pin
206628	16613	Knee Lifter Connection Lever Lifting Rod Spring
227227	16613	Knee Lifter Connection Lever Lifting Rod Spring Collar with 200113F
200113F	16613	Knee Lifter Connection Lever Lifting Rod Spring Collar Set Screw
240175	14471	Knee Lifter Lifting Lever
200262X	19105	Knee Lifter Lifting Lever Hinge Screw
240316	16679	Knife
240317	16679	Knife Arm with 200994F, 201531E, 350266C and two 200076D
207063	16679	Knife Arm Base Plate with two 200061D
240318	16679	Knife Arm Base Plate 207063 with 240317 and two 207065
206939	10951	Knife Arm Base Plate Position Plate
200574E	16679	Knife Arm Base Plate Position Plate Screw (2)
200540E	16679	Knife Arm Base Plate Screw
202622	16679	Knife Arm Base Plate Screw Washer
207065	16679	Knife Arm Center
200061ALX	16679	Knife Arm Center Set Screw
240319	16679	Knife Arm Spring
247760	16679	Knife Arm Spring Plunger
350266C	16679	Knife Arm Stop Screw
201531E	16679	Knife Arm Stop Screw Nut
240320	16679	Knife Driving Bar
240321	16679	Knife Driving Bar complete, Nos. 200942F, 240320, 240324, 247762, 247763, two each 200075E and 213940
224624	11691	Knife Driving Bar Slide Block
240322	16679	Knife Driving Bar Slide Block Plate
200577AL	16679	Knife Driving Bar Slide Block Plate Screw (3)
247762	16679	Knife Driving Link
200942F	16679	Knife Driving Link Hinge Screw
200994F	16679	Knife Driving Link Screw Stud
247763	16679	Knife Driving Slide
247764	16679	Knife Driving Slide Locking Plunger
240323	16679	Knife Driving Slide Locking Plunger Bracket
240324	16679	Knife Driving Slide Locking Plunger Bracket 240323 with 247764, 247768, 247769 and 247787
210983	16679	Knife Driving Slide Locking Plunger Bracket Pin
200075E	16679	Knife Driving Slide Locking Plunger Bracket Screw
213940	16679	Knife Driving Slide Locking Plunger Bracket Screw Washer
247768	16679	Knife Driving Slide Locking Plunger Head
247787	16679	Knife Driving Slide Locking Plunger Head Pin
247769	16679	Knife Driving Slide Locking Plunger Spring

PARTS FOR MACHINE NO.111w107

No.	Plate	Name
200076D	16679	Knife Screw
240325	16679	Knife Throw-out Lever
200229D	16679	Knife Throw-out Lever Hinge Screw
241561	11593	Machine Pulley (disc) (belt groove 2-3/4 in.diam.) with 200328C and 200335C
200328C	16654	Machine Pulley Position Screw
200335C	16654	Machine Pulley Set Screw
240326	16680	Needle Bar with 200141F
238251	16680	Needle Bar Connecting Link
264718	16657	Needle Bar Connecting Link Oil Guard
201183D	16680	Needle Bar Connecting Link Oil Guard Screw
240327	16680	Needle Bar Connecting Link Stud with 202254
202254	16818	Needle Bar Connecting Link Stud Oil Packing (wick)
200374AL	16680	Needle Bar Connecting Link Stud Set Screw
200383C	16818	Needle Bar Connecting Link Stud Set Screw
*206891	-----	Needle Bar Connecting Stud with 200086C
202329	16263	Needle Bar Connecting Stud 206891 with 202330
202330	16763	Needle Bar Connecting Stud Oil Packing (wick)
200086C	16263	Needle Bar Connecting Stud Pinch Screw
240328	16680	Needle Bar Crank with 200335C, 200374AL, 200383C, 200428C and 240327
203172	16657	Needle Bar Crank Friction Washer
200428C	16657	Needle Bar Crank Position Screw
200335C	16657	Needle Bar Crank Set Screw
237813	16680	Needle Bar Rock Frame
240329	16680	Needle Bar Rock Frame 237813 with 240326
210910	16657	Needle Bar Rock Frame Hinge Stud with 202277
202277	16657	Needle Bar Rock Frame Hinge Stud Oil Packing (wick)
200347AL	16657	Needle Bar Rock Frame Hinge Stud Set Screw
202666	16657	Needle Bar Rock Frame Position Bracket
200098F	16657	Needle Bar Rock Frame Position Bracket Screw (2)
223690	16609	Needle Bar Rock Frame Rock Shaft
223691	16609	Needle Bar Rock Frame Rock Shaft 223690 with 200387C and 210920
223692	16604	Needle Bar Rock Frame Rock Shaft Crank with 200029E
223693	16655	Needle Bar Rock Frame Rock Shaft Crank Con- nection with 202277
200833C	16655	Needle Bar Rock Frame Rock Shaft Crank Con- nection Hinge Screw
201522E	16655	Needle Bar Rock Frame Rock Shaft Crank Con- nection Hinge Screw Nut
202277	16655	Needle Bar Rock Frame Rock Shaft Crank Con- nection Oil Packing (wick)
200029E	16609	Needle Bar Rock Frame Rock Shaft Crank Pinch Screw
202668	16609	Needle Bar Rock Frame Slide Block

PARTS FOR MACHINE NO.111w107

No.	Plate	Name
210920	16609	Needle Bar Rock Frame Slide Block 202668 with 201141C
201141C	16609	Needle Bar Rock Frame Slide Block Screw Stud
200387C	16609	Needle Bar Rock Frame Slide Block Screw Stud Set Screw
200141F	16609	Needle Set Screw
208566	15842	Presser Bar with 200074F
207072	15842	Presser Bar Bushing (2)
200352AL	15842	Presser Bar Bushing Set Screw (2)
202671	15842	Presser Bar Lifter
200653C	15842	Presser Bar Lifter Hinge Screw
207963	15842	Presser Bar Lifting Releasing Lever Bracket
200975F	15842	Presser Bar Lifting Releasing Lever Bracket Guide Screw
206608	15842	Presser Bar Lifting Releasing Lever Bracket Spring
202337	16278	Presser Bar Position Guide
202338	15842	Presser Bar Position Guide Lever with 200086C
200086C	15842	Presser Bar Position Guide Lever Pinch Screw
200352AL	16278	Presser Bar Position Guide Set Screw
237836	16682	Presser Bar Spring (flat)
210949	15842	Presser Bar Spring Bracket with 200086C
200086C	15842	Presser Bar Spring Bracket Pinch Screw
200538C	16613	Presser Bar Spring Regulating Screw
200948F	16613	Presser Bar Spring Support Screw
240330	16683	Presser Foot
200074F	15842	Presser Foot Screw
241518	16680	Take-up Lever
202399	16657	Take-up Lever Driving Stud with 244071
244071	16657	Take-up Lever Driving Stud Oil Packing (wick)
202400	16657	Take-up Lever Hinge Stud with 202423
202423	16657	Take-up Lever Hinge Stud Oil Packing (wick)
200363AL	16657	Take-up Lever Hinge Stud Set Screw
202401	15842	Take-up Lever Oiling Felt
200132E	15842	Take-up Lever Oiling Felt Screw
244048	17074	Tension Disc (back)
244049	17074	Tension Disc (front)
235072	16889	Tension Release Plunger
244061	18912	Tension Release Washer
223438	16578	Tension Spring
263106	17074	Tension Spring Washer
200625F	17074	Tension Stud with 204925
200032E	16681	Tension Stud Set Screw
204925	17074	Tension Stud Washer
201572X	17074	Tension Thumb Nut
240358	16681	Tension complete, Nos. 200625F, 201572X, 202410, 223438, 244048, 244049, 244061 and 263106
202410	16681	Thread Controller Spring
241443	17054	Thread Controller Spring Stop

PARTS FOR MACHINE NO.111w107

No.	Plate	Name
200132E	16612	Thread Controller Spring Stop Screw
202412	16654	Thread Guide
210954	16614	Thread Guide (lower)
210955	16612	Thread Guide (upper)
200582X	16612	Thread Guide Screw (3)
240034	16612	Thread Retainer
200366X	17706	Thread Retainer Set Screw
240336	16683	Throat Plate Body with 240346
240337	16683	Throat Plate Knife Cutting Plate, for 5/16 in. trimming margin
240346	16683	Throat Plate Knife Cutting Plate Position Pin
240338	16683	Throat Plate complete, 5/16 in. trimming margin, Nos. 240336 and 240337, for 240307
200161D	17708	Throat Plate Clamping Screw
691F	16613	Throat Plate Screw
240351	16677	Trimming Chute
200062X	16677	Trimming Chute Screw
240352	16682	Trimming Guard
200139E	16682	Trimming Guard Screw (2)
240353	16679	Trimming Guard (upper)
200174X	16679	Trimming Guard (upper) Screw (2)

ACCESSORIES

No.	Plate	Name
202258	16260	Bed Hinge Connection (2)
200570E	16260	Bed Hinge Connection Screw (4)
203470	16247	Bobbin (2)
228392	16685	Drip Pan, 20 in. long, with four 3/4 in. wire nails
240316	16679	Knife
41400	17620	Machine Rest Pin (wood)
126x9	-----	Needles, six, size 20
120342	17620	Oiler (copper plated) with 120343
120343	17620	Oiler Spout (3-1/2 in. long)
225498	17620	Screw Driver (7-1/4 in. long)
228476	17010	Screw Driver (Bobbin Case)
240337	16683	Throat Plate Knife Cutting Plate
225554	17620	Wrench

KNEE LIFTER (Roller Bracket)

200113F	16817	Knee Lifter Connection Lever Lifting Rod Roller Bracket Set Screw
200270X	16817	Knee Lifter Connection Lever Lifting Rod Roller Hinge Screw
224412	16817	Knee Lifter Connection Lever Lifting Rod Roller Bracket with 200113F
224411	16817	Knee Lifter Connection Lever Lifting Rod Roller
224413	16817	Knee Lifter Connection Lever Lifting Rod Roller Bracket complete, Nos. 200270X, 224411 and 224412

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

FOR 5/16 INCH ROUND BELT DRIVE

259428	16615	Bobbin Winder Brake (leather)
259429	16615	Bobbin Winder Brake Clamp
200113F	16615	Bobbin Winder Brake Clamp Screw
225453	16615	Bobbin Winder Frame with 202277 and 259660
225454	16615	Bobbin Winder Frame Hinge Pin
202277	16615	Bobbin Winder Frame Oil Packing (wick)
259660	16615	Bobbin Winder Frame Oil Well Washer
225455	16615	Bobbin Winder Frame Spring
225456	16615	Bobbin Winder Frame Spring Plunger

ACCESSORIES

No.	Plate	Name
225368	16615	Bobbin Winder Pulley with 200380C
200380C	16615	Bobbin Winder Pulley Set Screw
225381	16615	Bobbin Winder Spindle
225444	16615	Bobbin Winder Stop Latch
200056E	16615	Bobbin Winder Stop Latch Screw
225458	16615	Bobbin Winder Stop Latch Thumb Lever
225459	16615	Bobbin Winder Stop Latch Thumb Lever Hinge Stud
225459	16615	Bobbin Winder Stop Latch Thumb Lever Joint Stud
202478	16615	Bobbin Winder Stop Latch Trip Lever
200299X	16615	Bobbin Winder Stop Latch Trip Lever Hinge Screw
225461	16615	Bobbin Winder Tension Bracket with 201499X
200082D	16615	Bobbin Winder Tension Bracket Screw
228026	16615	Bobbin Winder Tension Bracket Screw Washer
2102	16615	Bobbin Winder Tension Disc
13710	16615	Bobbin Winder Tension Spring
201499X	16615	Bobbin Winder Tension Stud
201572X	16615	Bobbin Winder Tension Stud Thumb Nut
225462	16615	Bobbin Winder Tension Bracket complete, Nos. 13710, 201572X, 225461 and two 2102
259430	16615	Bobbin Winder and Tension Bracket Base
259431	16615	Universal Bobbin Winder complete, Nos. 200056E, 200082D, 200113F, 200299X, 202478, 225368, 225381, 225444, 225453 to 225456, 225458, 225462, 228026, 259428 to 259430, two each 225459 and wood screws 3/4 in., No. 12, R. H. B.

Note: Bobbin Winder 259431 is furnished with this Machine unless Bobbin Winder 259462 is specified on order.

KNEE LIFTER

228713	18580	Knee Lifter Rock Lever with two 350231C
228707	18580	Knee Lifter Rock Lever Bracket with 200347AL and three wood screws 7/8 in., No. 12
228709	18580	Knee Lifter Rock Lever Bracket 228707 with 228363, 228367, 228386, 228455 and 228713
228370	18580	Knee Lifter Rock Lever Extension with 200530C
350231C	18580	Knee Lifter Rock Lever Extension Set Screw
228363	18580	Knee Lifter Rock Lever Hinge Pin
228364	18580	Knee Lifter Rock Lever Knee Plate with 350231C
228388	18580	Knee Lifter Rock Lever Knee Plate Arm
350231C	18580	Knee Lifter Rock Lever Knee Plate Arm Set Screw
350231C	18580	Knee Lifter Rock Lever Knee Plate Set Screw
228455	18580	Knee Lifter Rock Lever Position Spring
228365	18580	Knee Lifter Rock Lever Rod
200530C	18580	Knee Lifter Rock Lever Rod Set Screw
228386	18580	Knee Lifter Rock Lever Spring

ACCESSORIES

No.	Plate	Name
228367	18580	Knee Lifter Rock Lever Stop Stud
200347AL	18580	Knee Lifter Rock Lever Stop Stud Set Screw
228710	18580	Knee Lifter Rock Lever complete, Nos. 228364, 228365, 228370, 228388 and 228709

(Other Knee Lifter parts are listed with parts of Machine Head.)