SINGER 118W4

Form 1790w-Rev. (1050) Printed in U.S.A.

1

LIST of PARTS



MACHINE No. 118w4

** A TRADE MARK OF

THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR OILING

To ensure easy running and prevent unnecessary wear of the parts which are in movable contact, the machine requires oiling and when in continuous use, "TYPE B" or "TYPE D" OIL, sold only by Singer Sewing Machine Company, should be applied at least twice each day to all oil holes marked "OIL", as instructed in Form 1789w.

"TYPE D" OIL is stainless.

Copyright, U. S. A., 1921, 1940 and 1951
by The Singer Manufacturing Co.
All Rights Reserved for all Countries

INDEX

ACCESSORIES		 	 	-	PAGE 14
BOBBIN WINDER					14
EDGE FOLDER		 	 -		15
HEMMERS					16
KNEE LIFTER		 -			15
MACHINE No. 118w4			 		5
NUMERICAL LIST OF PARTS					23
PIERCERS	***	 Post	 		21
PRESSER FEET					21

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the PART number in the FIRST column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above case), must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished, Nickel Plated and Buffed.
- B. Polished, Nickel Plated and Buffed.
- C. Hardened only.
- D. Polished only.
- E. Soft, not polished.
- F. Hardened and Polished.
- H. Blued.
- J. Nickel Plated only.
- R. Merlized.
- X. Black Oxide, for Iron and Steel.
- XC. Hardened and Black Oxide, for Iron or Steel.
- Y. Black Nickel Plated only.

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series

1 to 1500, 200001 to 201500 and 350001 to 351500 are Screw Numbers. 1501 to 1800, 201501 to 201800 and 351501 to 351800 are Nut Numbers. 1801 to 2000, 201801 to 202000 and 351801 to 352000 are Roller Numbers. 2001 to 50000 and 202001 to 350000 are Numbers of Machine Parts.


The figures in the second column refer only to the plate in which the illustration of the part is shown and are NOT TO BE USED in ordering.

Two or more numbers over a cut indicate that the difference between such parts is not visible in an illustration.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE

FOR



MACHINE No. 118w4

HAS RETURN FEED, PENDULUM NEEDLE VIBRATING
MECHANISM AND PIERCER ATTACHED TO
NEEDLE AND PIERCER HOLDER BRACKET
FOR HEMSTITCHING HANDKERCHIEFS, SHIRT WAISTS,

NECKTIES, INFANTS' WEAR ETC.

No.	Plate	Name
*235701		Arm
235656	13645	" Oil Tube, for oiling 202400, 235519,
		235522, 235546 and 235759 (5)
235742	13648	Arm Oil Tube with 29599, for oiling 235659
		and 235694 (2)
29599	13648	Arm Oil Tube Packing (felt)
204235	13650	" Position Pin (2)
123E	13650	" Screw (back) (2)
202005	13650	" " Washer (2)
201305E	13650	" " (front) (2)
52004	13645	" Shaft
52078	13645	" " Bushing (front)
443C	13645	" " Set Screw
235502	13645	" Connection Belt

No.	Plate	Name
235503	13645	Arm Shaft Connection Belt Pulley with
633303	13043	1285AL, 201346C and two 214206
1285 A L	13645	Arm Shaft Connection Belt Pulley Position Screw
201346C	13645	Arm Shaft Connection Belt Pulley Set Screw
214206	13645	n n spring
		Flange
43921	13645	Arm Shaft Flanged Bushing (back)
443C	13645	" " Set Screw
202299	13645	" Oiling Wick (back)
224392	13645	" " " (front)
200949H	13645	" " " Thumb Screw
144D	13645	" " Screw
235585	13648	" Side Cap
235587	13648	" " 235585 with 235586
219F	13648	" " Screw
235505	13646	" " Cover
732D	13646	" " Thumb Screw
20991	13645	Balance Wheel,"V" belt groove (outside
		diam. of belt groove 2.9 in.) with
24207	12/45	two 435AL
24297	13645	Balance Wheel Oil Cover
210D 435AL	13645	" Set Screw
*235506	13043	Bed
202258	13650	" Hinge Connection (2)
202236 200570E	13650	" " Screw (4)
2003102	13650	" Slide (back)
235507	13650	" (front)
233939	13642	Bobbin
235769	13642	Case Base with 202056, 203211 to
233.07		203213 and 203216
203211	13642	Bobbin Case Base Latch
*202056		u u u u Pin
203212	13642	" Plunger
203213	13642	n n n Spring
241676	13642	" Cap with 200594C, 200984C,
		235771, 241674, 241675 and two 350405C
247623	13642	Bobbin Case Lever
*235791		" " Eccentric
204243	13642	" Position Pin
247625	13643	" " Fulcrum
200066D	13643	" " Screw
203478	13643	" " Stud
241674	13642	" Oiling Felt
241675	13642	Tee salah s
350405C	13642	
235771	13642	Tension Spring
200984C	13642	Regulating Service
200594C	13642	
203216	13642	waster (cross)
241677	13642	Bobbin Case complete, Nos. 235769 and
2257/1	12646	241676
235761	13646 13647	Cam Timing Finger Face Plate
235670	13647	race Plate
190D	1304/	DCICM

No.	Plate	Name
732D	13647	Face Plate Thumb Screw
235671	13647	Face Plate complete, Nos. 210959, 235670
		and two 200582H
235697	13644	Feed Bar with 201535E, 204189 and 350219E
200641C	13644	" Hinge Screw
201522E	13644	" " Nut
202276	13644	" " Slide Block
202298	13644	" " Crank with 200038C
203124	13644	" " 202298 with
		200205F, 201518E and 202276
200038C	13644	Feed Bar Slide Block Crank Pinch Screw
200205F	13644	" " " Hinge Screw
201518E	13644	n n n n n Nut
204443	13644	" " Spring
204189	13644	" " Hook
203060	13644	" " Hook
235795	13641	" Dog, for 235793
200106E	13641	" " Screw (2)
350219E	13644	" " Support Screw
201535E	13644	n n n Nut
235760	13646	" Driving Cam with two 200347C
200347C	13646	" " Set Screw
235512	13646	" " Connection
235513	13646	" " Bearing
202298	13644	" Crank with 200038C
200038C	13644	" " Pinch Screw
201306C	13644	" " Hinge Screw
201518E	13644	" " Nut
235514	13644	" Rock Shaft
235698	13644	" " 235514 with 200641C,
		201522E and 235697
235619	13644	Feed Driving Rock Shaft Center (2)
200346C	13644	" " " " Set Screw (2)
235516	13646	" Segment Lever with 201311C,
		201531E and 201871
201871	13646	Feed Driving Segment Lever Roller
201311C	13646	" " Screw
		Stud
201531E	13646	Feed Driving Segment Lever Roller Screw
		Stud Nut
235601	13646	Feed Driving Segment Lever Shaft Bushing
		(2)
200362C	13646	Feed Driving Segment Lever Shaft Bushing
		Set Screw (long)
200382C	13646	Feed Driving Segment Lever Shaft Bushing
		Set Screw (short)
202574	13646	Feed Driving Segment Lever Shaft Collar
		with 200380C
200380C	13646	Feed Driving Segment Lever Shaft Collar
		Set Screw
235759	13646	Feed Lifting Cam and Gear, 54 teeth
235519	13645	" " Driving Pinion,
2002		18 teeth, with two 200388C
200388C	13645	Feed Lifting Cam and Gear Driving Pinion
		Set Screw

No.	Plate	Name
235520	13646	Feed Lifting Cam and Gear Shaft (hollow) with 204110 and two 204111
204110	13646	Feed Lifting Cam and Gear Shaft Oiling Leather
204111	13646	Feed Lifting Cam and Gear Shaft Oiling Leather Pin (leather)
200363AL	13646	Feed Lifting Cam and Gear Shaft Set Screw (2)
235521	13646	Feed Lifting Connection with 201303C, 201525E and 201871
201306C	13644	Feed Lifting Connection Hinge Screw
201518E	13644	" " Nut
201871	13646	u u Roller
201303C	13646	" Screw Stud
201525E	13646	n n n n Stud
		Nut
235522	13646	Feed Lifting Connection Slide Block
350419H	13646	n n n Cap
235606	13646	Screw Feed Lifting Connection Slide Block Friction
233606	13040	Washer
235523	13646	Feed Lifting Connection Slide Block Spring
235667	13644	" " Rock Shaft
235619	13644	" " Center (2)
200346C	13644	11 11 11 11 11 Set Screw (2)
201309E	13646	" Regulating Screw Slide
201652E	13646	n n n Nut
235524	13646	u u u Washer
*203522		Hook (sewing)
235779	13642	" 203522 with 224100 and two 201253F
235797	13642	Hook and Bobbin Case complete, Nos. 235779
		and 241677
235786	13643	Hook Bevel Gear Socket, 13 teeth
235527	13643	" " " Bushing (lower)
200362C	13643	(brass) Hook Bevel Gear Socket Bushing (lower) Set Screw
235756	13643	Hook Bevel Gear Socket Bushing (upper)
233130	15015	(brass)
449C	13643	Hook Bevel Gear Socket Bushing (upper) Set Screw
20055511	12/43	Hook Bevel Gear Socket Screw
200555H	13642	" " Thrust Washer
235635	13643	" Driving Bevel Gear with two 350089C
235787	13643	" " Set Screw
350089C	13643	
235530	13643	"
202321	13643	n n n n n n n Set Screw
200346C	13643	
235531	13643	(front)
2003 4 7C	13643	
235532	13643	with 214206 and two 201421C
201421C	13643	Hook Driving Shaft Connection Belt Pulley Set Screw
214206	13643	Hook Driving Shaft Connection Belt Pulley
		Spring Flange

No.	Plate	Name
224100	13642	Hook Gib
201253F	13642	" " Screw
235675	13643	" Saddle with 449C, 200347C, 200362C,
233013		235527 and 235756
235534	13643	Hook Saddle Oil Cover
235535	13643	" " Oiling Felt
202260	13643	" " Wick
235649	13643	" " Cover
200169H	13643	" " Screw
201308E	13643	" " Screw (2)
203637	13643	u u Washer (2)
235792	13642	Washer with 235791 and three 204243
235788		Hook Saddle complete, Nos. 200066D,
		200169H, 200555H, 202260, 203478, 235635,
		235649, 235675, 235786, 235792, 235797,
		247623 and 247625
247663	13650	Knee Lifter Bell Crank
247664	13650	" " " Bracket " 247664 with
247665	13650	
		5601 and 247663
178F	13650	Knee Lifter Bell Crank Bracket Screw (2)
5601	13650	" " Spring
5735	13650 13650	Knee Lifter Bell Crank complete, Nos.
235789	13050	5735 and 247665
235612	13650	Knee Lifter Lifting Lever with 448AL
235613	13650	" Connecting Rod
12416	13650	u u u u u Rod
		Joint Compating Red
76C	13650	Knee Lifter Lifting Lever Connecting Rod
15315	13/50	Joint Hinge Screw Knee Lifter Lifting Lever Connecting Rod
1521E	13650	Lock Nut
802D	13650	Knee Lifter Lifting Lever Hinge Screw
12240	13650	" " Pin
	13650	" Set Screw
235707	13648	Needle Bar with 235706
235708	13648	" " Bushing (lower)
235709	13648	" " (upper)
200387C	13648	11 11 Set Screw (2)
235659	13648	" " Connecting Link
235538	13648	" Oiling Felt
235710	13648	" " Stud with 200072C
		and 222598
222598	13648	Needle Bar Connecting Stud Oil Packing
		(wick)
200072C	13648	Needle Bar Connecting Stud Pinch Screw
235632	13648	Jilde Block
235658	13648	" " Cover " " Screw
200161H	13648	" Crank with 858AL, 1036AL,
235661	13648	1037AL and 1065AL
10/641	. 13648	Needle Bar Crank Position Screw
	13648 L. 13648	" " Set Screw
235706	13648	" Oil Packing (wick) (6 in. long)
235711	13648	" Holder with 200141F
633111	1,5040	*******

No. Plate Name Needle Holder Bracket with 200125F, 200393C and 203101 Needle Holder Bracket Cap Screw Needle Holder and Piercer Holder Bracket with 201206F Needle Holder and Piercer Holder Bracket Screw Needle Holder and Piercer Holder Bracket Screw Needle Holder Screw Needle Vibrating Cam with two 200382C Needle Vibrating Lever Bushing Needle Vibrating Cam with two 200382C Needle Vibrating Lever Pitman Connection Screw Washer Needle Vibrating Lever Pitman Connection Screw Washer Needle Vibrating Lever Pitman Connection Screw Washer Needle Vibrating Lever Pitman Connection Swivel with 200110B Needle Vibrating Lever Pitman Connection Swivel with 200110B Needle Vibrating Lever Pitman Connection Swivel Set Screw Needle Vibrating Lever Pitman Guard with 200347C Needle Vibrating Lever Pitman Guard with 200347C Needle Vibrating Lever Pitman Guard Set Screw Needle Vibrating Lever Pitman Guard Set Screw Needle Vibrating Lever Pitman Guard Set Screw Needle Vibrating Lever Pitman Swivel Cap N			
200122H	No.	Plate	Name
200122H 13648 Needle Holder Bracket Cap Screw 203101 13648 " " " " " " " " Stop Screw 235712 13648 " " " " " " " Stop Screw Needle Holder and Piercer Holder Bracket with 201206F Needle Holder and Piercer Holder Bracket 235712 with 200083F, 200122H, 201122D, 235711, 235733, 235778 and two 213940 Needle Holder and Piercer Holder Bracket Screw Needle Vibrating Cam with two 200382C Needle Vibrating Cam with two 200382C Needle Vibrating Cam with two 200382C Needle Vibrating Lever Bushing Needle Vibrating Lever Bushing Needle Vibrating Lever Pitman Connection Screw Needle Vibrating Lever Pitman Connection Screw Washer Needle Vibrating Lever Pitman Guard with 200347C Needle Vibrating Lever Pitman Guard with 200347C Needle Vibrating Lever Pitman Guard with 200347C Needle Vibrating Lever Pitman Guard Set Screw Needle Vibrating Lever Pitman Set Screw Needle Vibrating Lever Pitman Set Screw Needle Vibrating Lever Pitman Set Screw Needle Vibrating Lever Pitman Swivel (arge) with 200277 Needle Vibrating Lever Pitman Swivel Cap Screw (2) Needle Vibrating Lever Pitman Swivel Cap Screw (2) Needle Vibrating Lever Pitman Swivel Cap Screw (2) Needle Vibrating Lever Pitman Swivel Cap Needle Vibrating Lever Pitman Swivel Cap Needle Vibrating Lever Pitman	235733	13648	
203101			
200393C			
Screw Stop Screw Stop Screw Stop Screw Stop Screw With 201206F Screw With 201206F Seedle Holder and Piercer Holder Bracket 235713 235713 235718 and two 213940 Needle Holder and Piercer Holder Bracket 235712 with 200083F, 200122H, 201122D, 235711, 235733, 235778 and two 213940 Needle Holder and Piercer Holder Bracket Screw Screw Needle Holder Screw Screw Needle Holder Screw Screw Seedle Holder Screw Seedle Holder Screw Seedle Vibrating Carn with two 200382C 200382C 13646 " " " Set Screw Seedle Vibrating Carn with two 200382C 235716 13648 " " " Connection Screw Seedle Vibrating Lever with 201141C and 200122H 13648 " " " " Set Screw Seedle Vibrating Lever Bushing 200394C 13646 " " " " Set Screw 201888 Screw Seedle Vibrating Lever Bushing Seedle Vibrating Lever Bushing Screw Seedle Vibrating Lever Pitman Connection Screw Washer Screw Washer Screw Screw Washer Screw Screw Washer Screw			" On Packing (wick)
235712	200393C	13648	эсор
With 201206F Needle Holder and Piercer Holder Bracket 235712 with 200083F, 200122H, 201122D, 235711, 235733, 235778 and two 213940 Needle Holder and Piercer Holder Bracket Screw Needle Holder and Piercer Holder Bracket Screw Needle Holder Screw Washer Washer Washer Washer Set Screw Washer Set Screw Set	335313		
	235/12	13648	
235712 with 200083F, 200122H, 201122D, 235711, 235733, 235778 and two 213940	225724	12/40	
235711, 235733, 235778 and two 213940 Needle Holder and Piercer Holder Bracket Screw 13648 Needle Holder Screw Needle Vibrating Cam with two 200382C 13646 Needle Vibrating Cam with two 200382C Needle Vibrating Cam with 201141C and 201888 Needle Vibrating Cam with 201141C and 201888 Needle Vibrating Cam with 201141C and 20184 Needle Vibrating Cam with 20114C Needle Vibrating Cam with 20114C Needle Vibrating Cam Pitman Connection Swivel Set Screw Needle Vibrating Cam Pitman Connection Swivel Set Screw Needle Vibrating Cam Pitman Cam	435734	13648	
Needle Holder and Piercer Holder Bracket Screw			
Screw 201122D 13648 Needle Holder Screw 213940 13648 " " " Washer 200141F 13648 " Set Screw 235679 13646 Needle Vibrating Cam with two 200382C 200382C 13646 " " Set Screw 235781 13648 " " Gonnection Connection Screw 235716 13648 " " " Rod 200125F 13648 " " " Rod 200125F 13648 " " " Set Screw 235716 13646 " " Lever with 201141C and 201888 235547 13646 " " Lever with 201141C and 201888 235547 13646 " " " Cap Screw 235782 13646 " " " Cap Screw 235782 13646 " " " " Cap Screw 235782 13646 " " " " " Connection Screw 228026 13646 " " " " " Connection Screw 228026 13646 " " " " " Connection Screw 228026 13646 " " " " " Connection Screw 235720 13646 " " " " " Connection Screw 235720 13646 " " " " " Connection Screw Swivel with 200110B Needle Vibrating Lever Pitman Connection Swivel with 200110B Needle Vibrating Lever Pitman Guard Adjusting Screw Needle Vibrating Lever Pitman Set Screw (1arge) with 202277 235784 13648 Needle Vibrating Lever Pitman Swivel (2mall) with 200988F Needle Vibrating Lever Pitman Swivel Cap (1arge) with 202277 13648 Needle Vibrating Lever Pitman Swivel Cap Cap Screw (2) Needle Vibrating Lever Pitman Swivel Cap Cap Screw (2) Needle Vibrating Lever Pitman Swivel Cap Cap Screw (2) Needle Vibrating Lever Pitman Swivel Oil Packing (wick) Needle	20120617	13640	The state of the s
201122D	2012001	13040	
213940	201122D	13648	
Set Screw Needle Vibrating Cam with two 200382C			
235679	•		
200382C			
235781			
200122H	235781	13648	
235716	200122H	13648	
13648	235716	13648	•
235717	200125F	13648	
201888 20394C 13646 Needle Vibrating Lever Bushing	235717	13648	
201888	235546	13646	" Lever with 201141C and
200394C	•		
200996C	235547	13646	Needle Vibrating Lever Bushing
235782	200394C	13646	" Set Screw
235719	200996C	13646	"
200064F 13646 "	235782	13646	1 Itilian
Screw	235719	13646	Contection
228026 13646 Needle Vibrating Lever Pitman Connection Screw Washer Needle Vibrating Lever Pitman Connection- Swivel with 200110B 200110B 13646 Needle Vibrating Lever Pitman Connection Swivel Set Screw 235643 13646 Needle Vibrating Lever Pitman Guard with 200347C and 200363AL 200363AL 13646 Needle Vibrating Lever Pitman Guard Adjusting Screw 200347C 13646 Needle Vibrating Lever Pitman Guard Set Screw 200988F 13648 Needle Vibrating Lever Pitman Set Screw 235783 13648 " " " " Swivel (large) with 202277 235784 13648 Needle Vibrating Lever Pitman Swivel (small) with 200988F Needle Vibrating Lever Pitman Swivel Cap (small) with 200988F Needle Vibrating Lever Pitman Swivel Cap Screw (2) 202277 13648 Needle Vibrating Lever Pitman Swivel Oil Packing (wick) Needle Vibrating Lever Pitman Swivel Oil Packing (wick)	200064F	13646	" " " Connection
Screw Washer 235720 13646 Needle Vibrating Lever Pitman Connection Swivel with 200110B 200110B 13646 Needle Vibrating Lever Pitman Connection Swivel Set Screw 235643 13646 Needle Vibrating Lever Pitman Guard with 200347C and 200363AL 200347C 13646 Needle Vibrating Lever Pitman Guard Adjusting Screw Needle Vibrating Lever Pitman Guard Set Screw Needle Vibrating Lever Pitman Set Screw Needle Vibrating Lever Pitman Set Screw Screw Swivel (large) with 202277 Swivel (small) with 200988F Needle Vibrating Lever Pitman Swivel (small) with 200988F Needle Vibrating Lever Pitman Swivel Cap Screw (2) Needle Vibrating Lever Pitman Swivel Cap Screw (2) Needle Vibrating Lever Pitman Swivel Oil Packing (wick) Needle Vibrating Lever Roller			
235720	228026	13646	· · · · · · · · · · · · · · · · · · ·
Swivel with 200110B			
200110B 13646 Needle Vibrating Lever Pitman Connection Swivel Set Screw 235643 13646 Needle Vibrating Lever Pitman Guard with 200347C and 200363AL. 200363AL 13646 Needle Vibrating Lever Pitman Guard Adjusting Screw 200347C 13646 Needle Vibrating Lever Pitman Guard Set Screw 200988F 13648 Needle Vibrating Lever Pitman Set Screw 235783 13648 " " " Swivel (large) with 202277 235784 13648 Needle Vibrating Lever Pitman Swivel (small) with 200988F 20582H 13648 Needle Vibrating Lever Pitman Swivel Cap Screw (2) 202277 13648 Needle Vibrating Lever Pitman Swivel Oil Packing (wick) 201888 13646 Needle Vibrating Lever Pitman Swivel Oil	235720	13646	
Swivel Set Screw	300110D	12646	
235643 13646 Needle Vibrating Lever Pitman Guard with 200347C and 200363AL	20011015	13040	
200347C and 200363AL	235643	13646	
200363AL I3646 Needle Vibrating Lever Pitman Guard Adjusting Screw	233043	1 3040	
Adjusting Screw 200347C 13646 Needle Vibrating Lever Pitman Guard Set Screw 200988F 13648 Needle Vibrating Lever Pitman Set Screw 235783 13648 " " " " Swivel (large) with 202277 235784 13648 Needle Vibrating Lever Pitman Swivel (small) with 200988F 235785 13648 Needle Vibrating Lever Pitman Swivel Cap 200582H 13648 " " " " Cap Screw (2) 202277 13648 Needle Vibrating Lever Pitman Swivel Oil Packing (wick) 201888 13646 Needle Vibrating Lever Roller	200363A1	13646	
200347C 13646 Needle Vibrating Lever Pitman Guard Set Screw	200303AL	13040	
Screw Scre	200347C	13646	
200988F 13648 Needle Vibrating Lever Pitman Set Screw 235783 13648 " " " " Swivel (large) with 202277 235784 13648 Needle Vibrating Lever Pitman Swivel (small) with 200988F 235785 13648 Needle Vibrating Lever Pitman Swivel Cap 200582H 13648 " " " " Cap Screw (2) Screw (2) Needle Vibrating Lever Pitman Swivel Oil Packing (wick) Packing (wick) Packing (wick) Packing Lever Roller Packing Lever Roller	2003110	13010	~
235783 13648 " " " " Swivel (large) with 202277	200988F	13648	
(large) with 202277 235784 13648 Needle Vibrating Lever Pitman Swivel (small) with 200988F 235785 13648 Needle Vibrating Lever Pitman Swivel Cap 200582H 13648 " " " " Cap Screw (2) 202277 13648 Needle Vibrating Lever Pitman Swivel Oil Packing (wick) 201888 13646 Needle Vibrating Lever Roller			9
235784			
(small) with 200988F 235785	235784	13648	
235785 13648 Needle Vibrating Lever Pitman Swivel Cap 200582H 13648 " " " " " Cap Screw (2)			
200582H 13648 " " " " Cap Screw (2) 202277 13648 Needle Vibrating Lever Pitman Swivel Oil Packing (wick) 201888 13646 Needle Vibrating Lever Roller	235785	13648	
Screw (2) 202277 13648 Needle Vibrating Lever Pitman Swivel Oil Packing (wick) 201888 13646 Needle Vibrating Lever Roller		13648	
202277 13648 Needle Vibrating Lever Pitman Swivel Oil Packing (wick) 201888 13646 Needle Vibrating Lever Roller			
Packing (wick) 201888 13646 Needle Vibrating Lever Roller	202277	13648	
The state of the s			
201141C 13646 " " " Screw Stud	201888	13646	
	201141C	13646	" " " Screw Stud

No.	Plate	Name
213821	13648	Piercer
235778	13648	Holder with two 200125F
200083F	13648	" Screw
213940	13648	" Washer
200125F	13648	" Set Screw
235561	13649	Presser Bar (hollow) with 200074F
235562	13649	" " Bushing (lower)
235616	13649	" " (upper)
200387C	13649	n n Set Screw (2)
235563	13649	" Guide Bracket with 453AL
	13649	" Set Screw
29141	13649	" Lifter
689C	13649	" " Hinge Screw
12327	13649	" " Lifting Bracket
235790	13650	" " Spring (flat)
201339F	13650	" " Regulating Thumb Screw
200948F	13650	" " Support Screw
235608	13641	" Foot Bracket
235629	13641	" 235608 with 202084
233027		and 235609
235609	13641	Presser Foot Connection Lever
202084	13641	u u u Washer
223775	13641	" Guide with 200125F
200125F	13641	" " Set Screw
208127	13641	" " Hinge Pin
235746	13641	" Plate (left)
235747	13641	" " (right)
200074F	13649	" Screw
235683	13641	" Shank
235684	13641	" " (left) 235683 with
		208127 and 235746
235685	13641	Presser Foot Shank (right) 235683 with
	/	208127 and 235747
235610	13641	Presser Foot (hinged) (compensating) complete, Nos. 235629, 235684, 235685
		and two 223775
225501	13647	Spool Pin
235591 2102	13647	Tension Disc
235696	13649	" Release Arm
766D	13649	" " Hinge Screw
32572	13647	" Disc
235593	13649	" Lever
200439C	13649	" " Hinge Screw Stud
235576	13649	" " Rod
235576	13649	" Spring
200678C	13649	" Stop Screw
202075	13647	" Plunger
13710	13647	" Spring
201393C	13647	" Stud
235596	13647	" Socket
200397H	13647	" Set Screw
1560B	13647	" Thumb Nut
241099	13647	Tension complete, Nos. 1560B, 13710, 32572, 201393C, 202075 and two 2102
223706	13647	Thread Controller Disc
200978H	13647	" " Screw
20071011		

No.	Plate	Name
237174	13647	Thread Controller Spring
241443	13647	" " Stop
200132E	13647	" " " Screw
201199F	13647	" Stud with 204925
200337C	13647	" " Set Screw
235687	13647	" " Socket
200386C	13647	" " " Set Screw
204925	13647	" " Washer
201572H	13647	" " Thumb Nut
235688	13647	Thread Controller complete, Nos. 200132E,
		200978H, 201199F, 201572H, 223706,
		235687, 237174 and 241443
29642	13647	Thread Guide
235741	13647	" Guide
200582H	13647	" " Screw
200368H	13647	" Set Screw
235689	13643	" Loop Guard
235690	13643	" " Driving Eccentric with
		200373C and 200380C
235691	13643	Thread Loop Guard Driving Eccentric Link
350090C	13643	" " " " Link
,		Hinge Screw
200373C	13643	Thread Loop Guard Driving Eccentric
		Position Screw
200380C	13643	Thread Loop Guard Driving Eccentric Set
2003000	13013	Screw
210557	13643	Thread Loop Guard Hinge Stud (eccentric)
235692	13643	" " " " Bracket
237072	13043	with 200098F
200574E	13643	Thread Loop Guard Hinge Stud Bracket
2003141	13043	Screw (2)
200098F	13643	Thread Loop Guard Hinge Stud Set Screw
210956	13647	" Retainer Bracket with 200397H
200582H	13647	" " Screw
210993	13647	" Sleeve
223844	13647	" " Spring
210957	13647	" Stud
210958	13647	" " Collar
200397H	13647	" " Set Screw
210959	13647	oct belew
210737	13047	Thread Retainer complete, Nos. 210956 to
226777	12640	210958, 210993 and 223844
235777	13648	Thread Take-up Crank with 202277 and
202277	12/10	203101
202277	13648	Thread Take-up Crank Oil Packing (wick)
203101	13648	(wick)
1036AL		" Position Screw
1037AL		" Set Screw
235694	13648	" Lever
235640	13648	" " Driving Swivel
202400	13648	" " Hinge Stud with 202423
202423	13648	" " " Oil Packing
		(wick)
448AL	13648	Thread Take-up Lever Hinge Stud Set Screw
235586	13648	" " " Oiling Felt
235793	13641	Throat Plate, for 235795
200161D	13641	" " Clamp Screw
		•

No.	Plate			Name
203376	13641	Throat	Plate	Position Pin
200577AL	13641	11	11	Screw

singer Needles should be used in SINGER Machines.
These Needles and their Containers are marked with the
Company's Trade Mark "SIMANCO. **" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2

ACCESSORIES

ACCESSORIES

No.	Plate	Name
233939	13642	Bobbin (5)
213820	13640	Piercer
213822	13640	Piercer
228476	13640	Screw Driver (Bobbin Case)
234702	13640	Tweezers
128X15		Needles, three each, sizes 12 and 14
235600	13639	Drip Pan, 17 in. long, with four 3/4 in. wire
		nails
41400	13640	Machine Rest Pin (wood)
120342	13640	Oiler (copper plated) with 120343
120343	13640	" Spout (3-1/2 in. long)
225498	13640	Screw Driver (7-1/4 in. long)
10875	13640	Wrench

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

FOR $\frac{5}{16}$ INCH ROUND BELT DRIVE

259428	16615	Brake (leather)
259429	16615	" Clamp
200113F	16615	" " Screw
225453	16615	Frame with 202277 and 259660
225454	16615	" Hinge Pin
202277	16615	" Oil Packing (wick)
259660	16615	" Well Washer
225455	16615	" Spring
225456	16615	" Plunger
225368	16615	Pulley with 200380C
200380C	16615	" Set Screw
225381	16615	Spindle
225444	16615	Stop Latch
200056E	16615	" " Screw
225458	16615	" " Thumb Lever
225459	16615	" " " " Hinge Stud
225459	16615	" " " Joint Stud
202478	16615	" " Trip Lever
200299H	16615	" " " Hinge Screw
225461	16615	Tension Bracket with 201499H
200082D	16615	" Screw
228026	16615	" " Washer
2102	16615	" Disc
13710	16615	" Spring
201499H	16615	" Stud
201572H	16615	" Thumb Nut

No.	Plate	Name
225462	16615	Bobbin Winder Tension Bracket complete,
		Nos. 13710, 201572H, 225461 and two
		2102
259430	16615	Bobbin Winder and Tension Bracket Base
259431	16615	Universal Bobbin Winder complete, Nos.
		200056E, 20008ZD, 200113F, 200299H,
		202478, 225368, 225381, 225444, 225453
		to 225456, 225458, 225462, 228026, 259428
		to 259430, two each 225459 and wood
		screws 3/4 in. No. 12, R. H. B.

KNEE LIFTER

2763	13639	Rock	Shaft				
237561	13639	11	'']	Hange	r w	ith two	wood screws
		1	in. , N	n. 10			
2765	13639	Rock	Shaft	Knee	Arr	n	
2768	13639	11	11		- 11	2765	with 2766 and
		27	67				
2766	13639	Rock	Shaft	Knee	Arr	n Hub	with 356C
356C	13639	11	11	11	11	11	Set Screw
2767	13639	**		11	Pla	te wit	h 356C
356C	13639	11	17	11	11	Set	Screw
6337	13639	11	11	Liftin	ıg B	racke	t with two 356C
2778	13639	11	11	**	.,	11	Hook
356C	13639	**	11	11		*1	" Set Screw
356C	13639	11	11	11		**	Set Screw
2770	13639	11	*1	Stop	Dog	with 1	140219C
140219C	13639	***	11		11	Set S	crew
228277	13639	Knee	Lifter	r Roc	k Sh	aft co	mplete, Nos. 2763,
		27	68, 27	78,63	37, t	wo ea	ch 2770 and
		23	7561				
	(Other	Knee L	ifter p	parts	are	listed	with parts of

EDGE FOLDER

230185	13638	Edge Folder on Shank
Note:	Furnish	sample and state fold required.
200157B	13638	Edge Folder Screw

Machine Head)

HEMMERS

No. Plate Name 230192 13638 Hemmer on Shank, for hems 1/8 to 1/2 inch Note: State width required on order. 200157B 13638 Hemmer Screw

HEMMER (Reverse)

230190 13638 Hemmer on Shank, for hems 1/8 to 5/8 inch Note: State width required on order

HEMMER

(RIGHT HAND)

Folds 5/16 in. Hem

230940	13443	Base Plate with 225706
225706	13443	" " Position Pin
350472H	13443	" " Screw
201525E	13443	" " Nut
225708	13443	" " Spring
230713	13443	Folder on Shank
200187B	13443	" " Screw
230484	13443	" " " Washer
230714	13443	Tongue with two 200133B
200133B	13443	" Screw
230711	13443	Hemmer complete, Nos. 201525E, 225708,
		230484, 230713, 230714, 230940, 350472H
		and two 200187B

HEMMER

(RIGHT HAND)

Folds 3/8 in. Hem

No.	Plate	Name
230940	13444	Base Plate with 225706
225706	13444	" Position Pin
350472H	13444	" Screw
201525E	13444	" " Nut
225708	13444	" " Spring
230715	13444	Folder on Shank
200187B	13444	" " Screw
230484	13444	u u u Washer
230716	13444	Tongue with two 200103D
200103D	13444	" Screw
230712	13444	Hemmer complete, Nos. 201525E, 225708,
		230484, 230715, 230716, 230940, 350472H
		and two 200187B

HEMMER

(RIGHT HAND) (SMALL OPENING)

Folds 5/32, 3/16 and 1/4 in. Hems

(Note. State width of hem required)

230940	13443	Base Plate with 225706
225706	13443	" Position Pin
350472H	13443	" " Screw
201525E	13443	n n Nut
225708	13443	" " Spring
230532	13443	Folder on Shank
200187B	13443	" " Screw
230484	13443	" " " Washer
230533	13443	Tongue with two 200133B
200133B	13443	" Screw
230535	13443	Hemmer complete, Nos. 201525E, 225708,
		230484, 230532, 230533, 230940, 350472H
		and two 200187B

HEMMER

(RIGHT HAND)

Folds Hems from 7/16 to 2-1/2 in., in steps of 1/16 inch

(Note: State width of hem required)

No.	Plate	Name
230940	13445	Base Plate with 225706
225706	13445	" " Position Pin
350472H	13445	" " Screw
201525E	13445	" " Nut
225708	13445	" " Spring
230540	13445	Folder on Shank
200187B	13445	" " Screw
230484	13445	" " Washer
230539	13445	Tongue with two 200103D
200103D	13445	" Screw
230542	13445	Hemmer complete, Nos. 201525E, 225708,
4		230484, 230539, 230540, 230940, 350472H
		and two 200187B

HEMMER (Reverse)

(RIGHT HAND)

Folds Hems from 1/4 to 2-3/4 in., in steps of 1/16 inch

(Note: State width of hem required)

230756	13444	Base Plate with 225706
225706	13444	" " Position Pin
350472H	13444	" " Screw
201525E	13444	" " Nut
225708	13444	" " Spring
230537	13444	Folder on Shank
200187B	13444	" " " Screw
230484	13444	" " " Washer
230536	13444	Tongue with two 200103D
200103D	13444	" Screw
230538	13444	Hemmer (reverse) complete, Nos. 201525E,
		225708, 230484, 230536, 230537, 230756,
		350472H and two 200187B

HEMMER (Adjustable)

(RIGHT HAND)

Folds Hems from 1/2 to 2-1/4 inches

No.	Plate	Name
230940	13445	Base Plate with 225706
225706	13445	" Position Pin
35047211	13445	" Screw
201525E	13445	" " Nut
225708	13445	" " Spring
230519	13445	Bracket (lower) with two 200078B
200158H	13445	" Screw
230484	13445	" Washer
230521	13445	" (upper) with 200462H and two
		200160B
200078B	13445	Bracket (upper) Screw
230518	13445	Folder Arm and Guard (left)
200160B	13445	" " Screw
230520	13445	" and Arm (right)
200462H	13445	" " " Adjustable Thumb
		Screw
226163	13445	Folder and Arm (right) Adjustable Thumb
		Screw Washer
230523	13445	Tongue (left) with two 200164B
200164B	13445	" Screw
230522	13445	" (right) with two 200164B
200164B	13445	" Screw
230525	13445	Hemmer (adjustable) complete, Nos. 201525E,
		225708, 226163, 230484, 230518 to 230523,
		230940, 350472H and two 200158H

HEMMER (Reverse) (Adjustable)

(RIGHT HAND)

Folds Hems from 1/2 to 2-1/2 inches

230529	13446	Base Plate with 225706
225706	13446	" " Position Pin
350472H	13446	" Screw
201525E	13446	" " Nut
225708	13446	" Spring
230528	13446	Folder Arm and Guard (left) with two
		200155F
200187B	13446	Folder Arm and Guard (left) Screw
230484	13446	u u u u u Washer
230526	13446	" and Arm (right) with two 200155F

No.	Plate	Name
200469H	13446	Folder and Arm (right) Adjustable Thumb
		Screw
226163	13446	Folder and Arm (right) Adjustable Thumb
		Screw Washer
230530	13446	Tongue (left)
230527	13446	" (right)
200155F	13446	" Screw
230531	13446	Hemmer (reverse) (adjustable) complete,
		Nos. 200469H, 201525E, 225708, 226163,
		230484, 230526 to 230530, 350472H and
		two 200187B

HEMMER (Adjustable)

(LEFT HAND)

Folds Hems from 1/2 to 2-1/4 inches

231371	13637	Base Plate with 225706
225706	13637	" Position Pin
350472H	13637	" " Screw
201525E	13637	" " Nut
225708	13637	" " Spring
230515	13637	Bracket (lower) with two 200078B
200158H	13637	" Screw
230484	13637	" Washer
230514	13637	" (upper) with 200462H and two
		200160B
200078B	13637	Bracket (upper) Screw
230510	13637	Folder Arm and Guard (right)
200160B	13637	" " Screw
230511	13637	" and Arm (left)
200462H	13637	" " " Adjustable Thumb
		Screw
226163	13637	Folder and Arm (left) Adjustable Thumb
		Screw Washer
230512	13637	Tongue (left) with two 200164B
200164B	13637	" " Screw
230513	13637	" (right) with two 200164B
200164B	13637	" " Screw
230517	13637	Hemmer (adjustable) (left hand) complete,
		Nos. 201525E, 225708, 226163, 230484,
		230510 to 230515, 231371, 350472H and
		two 200158H

PIERCERS

No.	Plate		Name
213819	13648	Piercer	
213820	13648	Piercer	
213821	13648	Piercer	
213822	13648	Piercer	
213823	13648	Piercer	
213824	13648	Piercer	
213845	13648	Piercer	

PRESSER FEET

	235608	13641	Presser Foot Bracket	
	235629	13641	" " 235608 with 202084	
			and 235609	
	235609	13641	Presser Foot Connection Lever	
	202084	13641	" " Washer	
	223775	13641	" " Guide with 200125F	
	200125F	13641	" " Set Screw	
	208127	13641	" " Hinge Pin	
	235746	13641	" " Plate (left)	
	235747	13641	" (right)	
	235582	13641	" " (right)	
	200074F	13649	" " Screw	
	235683	13641	" " Shank	
	235684	13641	" " (left) 235683 with 208127	
and 235746				
	235685	13641	Presser Foot Shank (right) 235683 with	
			208127 and 235747	
	235583	13641	Presser Foot Shank (right) 235683 with	
			208127 and 235582	
	235610	13641	Presser Foot (hinged) (compensating)	
			complete, Nos. 235629, 235684, 235685 and	
			two 223775	
	235611	13641	Presser Foot (hinged) (compensating)	
			complete, Nos. 235583, 235629, 235684 and	
			two 223775	

SINGER Needles should be used in SINGER Machines.
These Needles and their Containers are marked with the
Company's Trade Mark "SIMANCO." 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2

