Form 2421w (Rev. 853) Printed in U.S.A.

DO NOT REMOVE

LIST of PARTS



SINGER"

MACHINE No. 136w105

THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR OILING

To ensure easy running and prevent unnecessary wear of the parts which are in movable contact, the machine requires oiling, and when in continuous use, "TYPE B" or "TYPE D" OIL, sold by Singer Sewing Machine Company, should be applied at least twice each day to all oil holes marked "OIL", as instructed in Form 2236w.

"TYPE D" OIL should be used when an oil is desired which will produce a minimum of stain on fabrics, even after a long period of storage.

The small felt pad on the side of the bobbin case should be kept wet with oil to lubricate the hook race.

Occasionally check the grease in gear cases on the underside of the bed of the machine and fill gear cases, when necessary, with GEAR LUBRICANT, sold by Singer Sewing Machine Company.

INDEX

	Page
Accessories	. 17
Bobbin Winder	. 17
Feed Gears	. 19
Knee Lifter	. 18
Knife Honing Device	. 20
Machine No.136w105	. 5
Numerical List of Parts	. 23
Throat Plates	. 21
Wood Base	. 22

Copyright, U. S. A., 1938, 1939, 1940, 1941 and 1954 by The Singer Manufacturing Company All Rights Reserved for All Countries

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the PART number in the FIRST column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above case), must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed.

AL-Heat Treated for Toughness.

ALX—Heat Treated for Toughness and Black Oxide.

B-Polished, Nickel Plated and Buffed.

C-Hardened only.

D-Polished only.

E-Soft, Not polished.

F-Hardened and Polished.

J-Nickel Plated only.

R-Merlized.

X-Black Oxide, for Iron and Steel.

XC-Hardened and Black Oxide, for Iron and Steel.

Y-Black Nickel Plated only.

Z-Chromium Plated.

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series

1 to 1500, 200001 to 201500 and 350001 to 351500 are Screw Numbers.

1501 to 1800, 201501 to 201800 and 351501 to 351800 are Nut Numbers.

1801 to 2000, 201801 to 202000 and 351801 to 352000 are Roller Numbers.


2001 to 50000 and 202001 to 350000 are Numbers of Machine Parts.

The figures in the second column refer only to the plate in which the illustration of the part is shown and are NOT TO BE USED in ordering.

Two or more numbers over a cut indicate that the difference between such parts is not visible in an illustration.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE



MACHINE No. 136w105

VERTICAL HOOK. POST BED.

CONTINUOUS WHEEL FEED.

BALL BEARING ROLLER PRESSER.

Horizontal Undertrimmer attached to Hook Post.

For Simultaneously stitching the edges and undertrimming the linings of Shoes, Sandals, Slippers, etc.

No.	Plate	Name
*249069		Arm with 202135
249001		" Base
204235	17330	" Position Pin (2)
200004E	17330	" " Screw (3)
202005	17330	" " Washer (3)
203091	17325	" Cap
200278X	17325	" "Screw
202248	17325	" " Washer
203089	17325	" " Spool Holder Base
203090	17325	" " 203089 with
		200079X and 204296

6	P	ARTS FOR MACHINE No. 136w105
NT-	F31 .	
No.	Plate	Name
200585X	17325	Arm Cap Spool Holder Base Screw
204296	17325	" " " Wire
200079X	17325	" " " Hinge Screw
203092	17325	Arm Cap and Spool Holder complete,
		Nos. 203090, 203091 and two 200585X
204235	17330	Arm Position Pin (2)
200004E	17330	" Screw (3)
202005	17330	" " Washer (3)
237702	17325	" Shaft with 224392 and 350431E
237748	17325	" Bushing (back) with 202260
202260	17325	" " " Oil Packing
300000		(wick)
200071E	17325	Arm Shaft Bushing (back) Screw (3)
207080	17325	" " (front) with 202244
202244	17325	" " " Oil Packing
		(wick)
200502X	17325	Arm Shaft Bushing (front) Oil Packing
		Thumb Screw
350532E	17325	Arm Shaft Bushing (front) Set Screw
201522E	17325	" " " Lock
		Nut
224392	17325	Arm Shaft Oil Packing (wick)
350431E	17325	" " " Stop Screw
202632	15745	" Side Plate
200462X	15745	" " Thumb Screw
*249276		Bed
202258	17330	" Hinge Connection (2)
200570E	17330	" " Screw (4)
233939	17313	Bobbin
238304	17313	" Case Base with 202056, 203211 to
202211		203213 and 203216
203211	17313	Bobbin Case Base Latch
*202056		" " Pin
203212	17313	" " " Plunger
203213	17313	" " " Spring
238312	17313	" Cap with 200984C, 203214,
•		203215, 241674, 241675, two each
		200594C and 350405C
234079	17326	Bobbin Case Lever
234065	17326	" " Driving Block
200076D	17326	" " " " Screw
		(2)
201272C	17326	Bobbin Case Lever Hinge Screw
241674	17313	" " Oiling Felt
241675	17313	" " Retainer
350405C	17313	" " Screw
203214	17313	" Tension Spring
200984C	17313	" " Regulating
		Screw
200594C	17313	Bobbin Case Tension Spring Screw
203215	17313	" " Thread Guide
200594C	17313	" " Screw

	No.	Plate	Name
	203216	17313	Bobbin Case Washer (cloth)
	238313	17313	Bobbin Case complete, Nos. 238304 and 238312
	237793	17325	
	2311,3	11323	Driving Wheel (aluminum alloy casting) for "V" belt (outside diam. of belt
			groups 2.0 in \ mith 2505 loc
			groove 2.9 in.) with 350540C and 350541C
	3504193	17325	Driving Wheel Adjusting Screw
	3505400		" Position Screw
	3505410		" Set Screw
	241732	17328	Set Screw
	241733	17328	Edge Guide
	200934X		Diacket
	2003347		Hinge Screw
	241764		" Set Screw
	241104	17328	
	21,1601,	17220	Packing (fibre)
	241684	17328	Edge Guide Locking Pin
	249272 201537E	17328	Releasing Handle
	201537E	17328	
	350488C	17330	Lock Nut
	249273	17328	Edge Guide Locking Pin Screw Bushing
	249273	17328	Spring
	247214	17328	Edge Guide Locking Device complete,
			Nos. 241684, 249272, 249273, 350488C
	2001727	12220	and two 201537E
	200173X	17328	Edge Guide Screw (2)
	237777	15745	Face Plate with 201650X and 350432XC
	202135	15745	" Position Pin
	200473X	15745	" " Thumb Screw
	249088	17327	Feed Post with 200362C, 200383C and
	21.0260	17337	two 201052C
	249268	17327	Feed Post 249088 with 249007, 249013,
			249014, 249019, 249077, 249078,
	31000=		249092, 249266 and four 200137X
	249005	17326	Feed Post Cover (back)
	249278	17326	" " (front)
•	200159F	17326	" " (back or front) Clamp
			Screw (2)
	200583X	17326	Feed Post Cover (back or front) Screw
			(6)
į	249007	17327	Feed Post Cover (side)
	200137X	17327	" " Screw
	200036E	17327	" " Screw (2)
	249065	17327	" Wheel (coarse knurl)
	249267	17327	" 249065 with 249062 and three
			229D
	249092	17327	Feed Wheel Adjusting Stud (eccentric)
	201052C	17327	" " Set Screw
	249061	17327	" Ball Bearing
	249097	17327	" Bearing
	200585X	17327	" " Screw
	249062	17327	" Bevel Gear
:			

No.	Plate	Name
249012	17327	Feed Wheel Bevel Gear Driving Pinion with two 201052C
350395C	17327	Feed Wheel Bevel Gear Driving Pinion
		Screw Stud
201052C	17327	Feed Wheel Bevel Gear Driving Pinion Set Screw
249013	17327	Feed Wheel Bevel Gear Driving Pinion
249014	17227	Shaft (lower)
247014	17327	Feed Wheel Bevel Gear Driving Pinion Shaft (lower) Bushing
200383C	17327	Feed Wheel Bevel Gear Driving Pinion Shaft (lower) Bushing Set Screw
249077	17327	Feed Wheel Bevel Gear Driving Pinion
-1/0//	11321	Shaft (lower) Collar with two 200393C
200393C	17327	Feed Wheel Bevel Gear Driving Pinion Shaft (lower) Collar Set Screw
248810	17327	Feed Wheel Bevel Gear Driving Pinion
210010	11361	
249077	17327	Shaft (upper)
247011	11361	Feed Wheel Bevel Gear Driving Pinion
2002026	17777	Shaft (upper) Collar with two 200393C
200393C	17327	Feed Wheel Bevel Gear Driving Pinion
31.0070		Shaft (upper) Collar Set Screw
249078	17327	Feed Wheel Bevel Gear Driving Pinion
		Shaft Connection
249073	17327	Feed Wheel Bevel Gear Driving Pinion
		Thrust Washer
229D	17327	Feed Wheel Bevel Gear Screw
249096	17327	" " Spacing Washer
249079	17327	" " Bracket
249266	17327	" 249079 with 248810,
		249012, 249061, 249073, 249077,
		249096, 249097, 249267, 350395C,
		350514AL and three 200585X
249019	17327	Feed Wheel Bracket Friction Plug
201052C	17327	" " " " Set
		Screw
	17327	Feed Wheel Bracket Set Screw
350514AL	. 17327	" Cap Screw
249023	15739	" " Driving Gear (for 15
		stitches)
249024	15739	Feed Wheel Driving Gear (for 16
-		stitches)
249026	15739	Feed Wheel Driving Gear (for 18
/	23.07	stitches)
238613	15739	
238614	15739	Feed Wheel Driving Gear Key """ Shifting
		Collar with 201464C
201464C	15739	Feed Wheel Driving Gear Key Shifting
		Screw Stud
238615	15739	Feed Wheel Driving Gear Key Spring
201202D		" " " " " " "
	-3.0,	Screw

No.	Plate	Name
238616	15739	Feed Wheel Driving Gear Key Stop Pin
249075	15739	" " " Separating
		Washer (2)
249030	15739	Feed Wheel Driving Gear Shaft with 238616
249032	15739	Feed Wheel Driving Gear Shaft Bracket with 202299, 238630 and two 200346C
202299	15739	Feed Wheel Driving Gear Shaft Bracket Oil Packing (wick)
249033	15739	Feed Wheel Driving Gear Shaft Bracket Plate with two 210983
210983	15739	Feed Wheel Driving Gear Shaft Bracket Plate Position Pin
200158X	15739	Feed Wheel Driving Gear Shaft Bracket Plate Screw (2)
201082E	15739	Feed Wheel Driving Gear Shaft Bracket Screw (long)
225532	15739	Feed Wheel Driving Gear Shaft Bracket
22332	13.37	Screw (long) Washer
201308E	15739	Feed Wheel Driving Gear Shaft Bracket
		Screw (short)
203637	15739	Feed Wheel Driving Gear Shaft Bracket Screw (short) Washer
238630	15739	Feed Wheel Driving Gear Shaft Bushing
249031	15739	" " Collar
		with 200397X
200397X	15739	Feed Wheel Driving Gear Shaft Collar Set Screw
249037	15740	Feed Wheel Driving Pinion (for 15 stitches)
249038	15740	Feed Wheel Driving Pinion (for 16 stitches)
249040	15740	Feed Wheel Driving Pinion (for 18 stitches)
231433	15740	Feed Wheel Driving Pinion Key
249044	15740	" " Shaft
249045	15740	" " " Bushing (back)
200362C	15739	11 11 11 11 11
		Set Screw
249046	15740	Feed Wheel Driving Shaft Bushing (front)
200346C	15739	Feed Wheel Driving Shaft Bushing (front) Set Screw
249047	15740	Feed Wheel Driving Shaft Collar with two 201052C
201052C	15740	Feed Wheel Driving Shaft Collar Set Screw
237724	15740	Feed Wheel Driving Shaft Gear with 200378C and 201220C
201220C	15740	Feed Wheel Driving Shaft Gear Position Screw
200378C	15740	Feed Wheel Driving Shaft Gear Set Screw

11

Knife Driving Lever (lower) Pinch

Knife Driving Lever (lower) Shaft

Screw

200362C 15739

200338C 15740

15740

249053

No.	Plate	Name
201666E	15740	Feed Wheel Driving Shaft Nut
203411	15740	" " Washer
*203482		Hook (sewing)
233853	17313	" 203482 with 201253F, 201376C and
		241604
238315	17313	Hook and Bobbin Case complete, Nos.
		233853 and 238313
249049	17326	Hook Bevel Gear Socket, 14 teeth
234024	17326	" " Friction Washer
200555X	17313	" " Screw
241551	15740	" Pinion, 28 teeth, with two
		200378C
201318E	15740	Hook Bevel Pinion Guard Oil Stop Screw
201082E	15740	" " Screw
*249050		" " " Section (back)
*249051		" " " " (front)
249052	15740	Hook Bevel Pinion Guard complete, Nos.
		201082E, 201318E, 249050 and 249051
200378C	15740	Hook Bevel Pinion Set Screw
237728	15740	" Driving Shaft
235857	15740	" " Bevel Gear with
		200374C and 200396C
237729	15739	Hook Driving Shaft Bevel Gear Housing
		with 200346C and three 200362C
237730	15739	Hook Driving Shaft Bevel Gear Housing
		Cap (bottom)
237731	15739	Hook Driving Shaft Bevel Gear Housing
		Cap (bottom) Gasket
237732	15739	Hook Driving Shaft Bevel Gear Housing
		Cap (side)
237733	15739	Hook Driving Shaft Bevel Gear Housing
_		Cap (side) Gasket
200053C	15739	Hook Driving Shaft Bevel Gear Housing
		Cap Screw (4)
5 01085E	15739	Hook Driving Shaft Bevel Gear Housing
		Screw (long)
225532	15739	Hook Driving Shaft Bevel Gear Housing
		Screw (long) Washer
201308E	15739	Hook Driving Shaft Bevel Gear Housing
		Screw (short)
203637	15739	Hook Driving Shaft Bevel Gear Housing
		Screw (short) Washer
S00396C	15740	Hook Driving Shaft Bevel Gear Position
		Screw
200374C	15740	Hook Driving Shaft Bevel Gear Set
		Screw
237734	15740	Hook Driving Shaft Bushing (back)

Screw

Screw

Hook Driving Shaft Bushing (front)

No.	Plate	Name
221743	15740	Hook Driving Shaft Collar with two
		200380C
200380C	15740	Hook Driving Shaft Collar Set Screw
241604	17313	" Gib
201376C	17313	" " Hinge Screw
201253F	17313	" " Screw
249280	17326	" Post
249072	17326	" " Oil Packing (wick)
200959D	17326	" " " " " Screw (2)
200017C	17326	" " Screw (2)
203637	17326	" " Washer (2)
221215	17326	" " Slide
221222	17313	" Washer
249100	17330	Knee Lifter Lifting Lever
200242X	17330	" " " Hinge Screw
227561	17330	" " " Spring
241683	17330	" " " Stop Finger
233390	17330	u u u Washer
238508	17328	Knife
238530	15740	" Driving Eccentric with two 200386C
238510	15740	" " Oil Pan
201058E	15740	" " " " Screw (2)
240019	15740	" " Oiling Felt
200386C	15740	" " Set Screw
238512	15740	" " Fork Lever
249281	15740	" " 238512 with
		200243D, 201531X and 249282
238513	15740	Knife Driving Fork Lever Bracket with
		200378C
202126	15740	Knife Driving Fork Lever Bracket Posi-
		tion Pin (2)
201058E	15740	Knife Driving Fork Lever Bracket Screw
		(2)
210910	15740	Knife Driving Fork Lever Hinge Stud
<i>y</i> = -		with 202277
202277	15740	Knife Driving Fork Lever Hinge Stud
		Oil Packing (wick)
200378C	15740	Knife Driving Fork Lever Hinge Stud Set
		Screw
249282	15740	Knife Driving Fork Lever Slide Block
200243D	15740	H H H H H
		Hinge Screw
201531X	15740	Knife Driving Fork Lever Slide Block
#01331A	23.10	Hinge Screw Nut
241736	17328	Knife Driving Lever (lower) with
541120	11300	200048C and 241752
241737	17326	Knife Driving Lever (lower) Guard
200158X	17326	" " Screw
LOUISON	1.520	(2)
		\ - /

200048C

241738

17328

17328

No.	Plate	Name
241739	17328	
		Nos. 104D, 24173 and 241736
241740	17328	Knife Driving Lever (upper) with
		200048C
241720	17328	_
		Plunger Locking
241721	17328	
		Plunger Spring
2017251	17328	Knife Driving Lever (upper) Locking
		Plunger Spring Thumb Nut with
		200389C
200389C	17328	Knife Driving Lever (upper) Locking
		Plunger Spring Thumb Nut Set Screw
200048C	17328	Knife Driving Lever (upper) Pinch
		Screw
241741	17328	Knife Driving Lever (upper) complete,
		Nos. 201725D, 241720, 241721 and
		241740
241752	17328	Knife Driving Lever Fork
24173	17328	" " " Swivel
104D	17328	" " Screw
249275	17326	" Guard
200110D	17326	"
241742	17328	" Lever
200168X		" " Screw (2)
200169X		" Screw (2)
241743	17328	" Shaft
241744	17328	" "Spring
214833	17328	" " " Adjusting Collar with
2002000		200380C
S00380C	17328	Knife Shaft Spring Adjusting Collar Set
241745	15000	Screw
	17328	Knife Switch-in Lever with 200061XC
200061XC		" " Pinch Screw
241746	17328	" Switch-out Lever
200284D	17328	" " Hinge Screw
241747	17328	" " Plunger
249269	17329	Needle Bar with 200125F, 200175D and
220251	17220	249270
238251 264718	17329	Needle Bar Connecting Link
201183D	17329	" " " Oil Guard
201183D	17329	
202222	1222	Screw
202333	17329	Needle Bar Connecting Link Stud with
202251	17220	202254
202254	17329	Needle Bar Connecting Link Stud Oil
200374C	17220	Packing (wick)
2003/40	17329	Needle Bar Connecting Link Stud Set
200383C	17329	Screw
2003030	11369	Needle Bar Connecting Link Stud Set
* 206891		Screw Needle Bay Connection St. 1
		Needle Bar Connecting Stud

No.	Plate	Name
202329	17329	
		200086C and 202330
202330	17329	Needle Bar Connecting Stud Oil Packing (wick)
200086	C 17329	Needle Bar Connecting Stud Pinch Screw
202692	17329	
		200383C, 200428C and 202333
237737	17329	Needle Bar Crank 202692 with 202329,
202173	17710	202399, 202400, 237762 and 238251
203172	17329	Needle Bar Crank Friction Washer
2004280		rosition belew
2003350		Det petem
202664	17329	NOCK Flaine
*237794	17325	" " " Driving Eccentric
*237749	17325	Body with 443C and 350107C
3501070	17325	Needle Bar Rock Frame Driving Ec-
3301010	3 11323	centric Body Position Screw
4430	17325	Needle Bar Rock Frame Driving Ec-
1150	3 11323	centric Body Set Screw
11030	17325	Needle Bar Rock Frame Driving Ec-
11030	J 17565	centric Regulating Screw
2171	17325	Needle Bar Rock Frame Driving Ec-
2111		centric Set Screw
7071	17325	Needle Bar Rock Frame Driving Ec-
		centric Set Screw Washer
237750	17325	Needle Bar Rock Frame Driving Ec-
		centric complete, Nos. 217D, 1103C,
		7071, 237749 and 237794
237739	17330	Needle Bar Rock Frame Driving Fork
		Lever with 200029E
200025E	1-330	Needle Bar Rock Frame Driving Fork
		Lever Pinch Strew
2377'49	1 = 330	Needle Bar Rock Frame Driving Fork
		Lever Slide Block (two pieces)
210910	17329	Needle Bar Rock Frame Hinge Stud with 202277
202277	17329	Needle Bar Rock Frame Hinge Stud Oil
		Packing (wick)
200347C	17329	Needle Bar Rock Frame Hinge Stud Set
		Screw
202666	17329	Needle Bar Rock Frame Position
		Bracket
20 0098F	17329	Needle Bar Rock Frame Position
		Bracket Screw
2 02667	17330	Needle Bar Rock Frame Rock Shaft
210978	17330	и и и и и
		202667 with 200387C and 210920
20 2668	17330	Needle Bar Rock Frame Slide Block
210920	17330	11 11 11 11 11
		202668 with 201141C

No.	Plate	Name
2011410	17330	Needle Bar Rock Frame Slide Block
		Screw Stud
2003870	17330	Needle Bar Rock Frame Slide Block
		Screw Stud Set Screw
249270	17329	Needle Bar Thread Guide
2001751		" " " Screw
200125F		" Set Screw
207072	15746	Presser Bar Bushing (2)
200352C		" " Set Screw (2)
202671	15746	" Lifter
200653C		" " Hinge Screw
207963	15746	" Lifting Releasing Lever
	23.10	Bracket
200975F	15746	Presser Bar Lifting Releasing Lever
_00,.51	13110	Bracket Guide Screw
206608	15746	
200000	13140	Bracket Spring
202337	15746	• 9
202338	15746	Presser Bar Position Guide
LULJJU	13140	" " " Lever with 200086F
200086F	15746	
LUUUUUT	13/40	Presser Bar Position Guide Lever Pinch
200352C	15746	Screw
207965	17330	Presser Bar Position Guide Set Screw
210949	15746	op:g (:::=v/
210949	15740	" " Bracket with 200086C
200086C	15746	
2000000	13740	Presser Bar Spring Bracket Pinch Screw
350346C	17330	
200948F		Presser Bar Spring Regulating Screw
201997	15746	Support Berew
201771	15740	Roller Presser, l in. diam., 5/32 in.
		face (fine) with 1528J, 201699C,
249056	15746	350104C and twenty-eight 206417
249057	15746	Roller Presser Arm
233807	15746	249036 With 201997
		Dracket
235088	15746	Position
2001175	1571.7	Collar with 200362C
200117F	15746	Roller Presser Arm Bracket Position
2002626	15767	Collar Position Screw
200362C	15746	Roller Presser Arm Bracket Position
202550		Collar Set Screw
202558	15746	Roller Presser Arm Bracket Spring
202559	15746	" " " " Stop
200141F	15746	
2000015	1	Screw
200096D	15746	Roller Presser Arm Screw
249058	15746	Roller Presser and Bar complete, Nos.
		200096D, 200117F, 202557 to 202559,
		Maril 1991 Marie 1991
066.17	15764	Z00141F
06417	15746	Roller Presser Ball, 1/16 in. diameter

No.	Plate	Name
201699C	15746	Roller Presser Ball Cone
202557	15746	" " Bar
350104C	15746	" " Hinge Screw
1528J	15746	" " " Nut
237762	17329	Take-up Lever
202399	17329	" Driving Stud with 202277
202277	17329	" " " Oil Packing
		(wick)
202400	17329	Take-up Lever Hinge Stud with 202423
202423	17329	" " " Oil Packing
		(wick)
200383C	17329	Take-up Lever Hinge Stud Set Screw
202401	15746	" " Oiling Felt
200132E	15746	" " " Screw
244048	17314	Tension Disc (back)
244049	17314	" " (front)
202404	15746	" Release Plunger
244061	17314	" " Washer
223438	17314	waster
263106	17314	" Spring " " Washer
200625F	17314	" Stud with 204925
2000E3F	17314	" Set Screw
204925	17314	Det Berew
201572X	17314	Washer
240358	17314	Indino ital
240336	1/314	Tension complete, Nos. 200625F, 201572X
		202410, 223438, 244048, 244049, 244061
2021.10	17211	and 263106
202410	17314	Thread Controller Spring
	17211	
241443	17314	" " Stop
200132E	17314	" " Stop
200132E 202412	17314 17325	" " Stop " " Screw " Guide
200132E 202412 210955	17314 17325 17314	" " Stop " " " Screw " Guide " " (upper)
200132E 202412 210955 200582X	17314 17325 17314 17314	" " Stop " " " Screw " Guide " " (upper) " " Screw (2)
200132E 202412 210955 200582X 241755	17314 17325 17314 17314 15745	" " Stop " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt)
200132E 202412 210955 200582X 241755 237779	17314 17325 17314 17314 15745	" " " Stop " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder
200132E 202412 210955 200582X 241755 237779 240439	17314 17325 17314 17314 15745 15745	" " " Stop " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer
200132E 202412 210955 200582X 241755 237779 240439 241758	17314 17325 17314 17314 15745 15745 15745	" " " Stop " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " Reservoir
200132E 202412 210955 200582X 241755 237779 240439 241758 241759	17314 17325 17314 17314 15745 15745 15745 15745 15745	" " " Stop " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " Reservoir " " Wick
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745	" " " Stop " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " Reservoir " " Wick " " Screw
200132E 202412 210955 200582X 241755 237779 240439 241758 241759	17314 17325 17314 17314 15745 15745 15745 15745 15745	" " " Stop " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " Retainer " " Reservoir " " Wick " " Screw " " Nut
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745	" " " Stop " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " Reservoir " " Wick " " Screw
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745	" " " Stop " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " Retainer " " Reservoir " " Wick " " Screw " " Nut
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745	" " " Stop " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " Retainer " " Reservoir " " Wick " " Screw " " Nut " " Washer
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745	" " " Stop " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " Reservoir " " Wick " Screw " " Nut " " Washer Thread Lubricator complete, Nos. 214838
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745	" " " " Stop " " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " Retainer " " Reservoir " " Wick " " Screw " " " Nut " " Washer Thread Lubricator complete, Nos. 214838 237779, 240439, 241755, 241758 and
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838 237780	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745	" " " " Stop " " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " " Reservoir " " " Wick " " " Screw " " " Nut " " Washer Thread Lubricator complete, Nos. 214838 237779, 240439, 241755, 241758 and 241759
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838 237780	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745 15745	" " " " Stop " " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " Retainer " " Reservoir " " Wick " " Screw " " " Nut " " Washer Thread Lubricator complete, Nos. 214838 237779, 240439, 241755, 241758 and 241759 Thread Retainer
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838 237780	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745 15745	" " " " Stop " " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " " Reservoir " " Wick " " Screw " " " Nut " " Washer Thread Lubricator complete, Nos. 214838 237779, 240439, 241755, 241758 and 241759 Thread Retainer " " Bracket with 200397X
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838 237780 240034 210956 200582X	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745 15745	" " " Stop " " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " Reservoir " " Wick " " Screw " " " Nut " " Washer Thread Lubricator complete, Nos. 214838 237779, 240439, 241755, 241758 and 241759 Thread Retainer " " Bracket with 200397X " " Screw (2)
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838 237780 240034 210956 200582X 200366X	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745 15745	" " " Stop " " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " " Retainer " " " Reservoir " " Wick " " Screw " " " Nut " " Washer Thread Lubricator complete, Nos. 214838 237779, 240439, 241755, 241758 and 241759 Thread Retainer " " Bracket with 200397X " " Screw (2) " " Set Screw " " Sleeve
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838 237780 240034 210956 200582X 200366X 210993	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745 15745	" " " " " Stop " " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " Retainer " " Reservoir " " Wick " " Screw " " " Washer Thread Lubricator complete, Nos. 214838 237779, 240439, 241755, 241758 and 241759 Thread Retainer " " Bracket with 200397X " " Screw (2) " " Set Screw " " Sleeve " " Sleeve
200132E 202412 210955 200582X 241755 237779 240439 241758 241759 350432XC 201650X 214838 237780 240034 210956 200582X 200366X 210993 225844 210957	17314 17325 17314 17314 15745 15745 15745 15745 15745 15745 15745 15745 15745 17314 17314 17314 17314	" " " " " Stop " " " " " Screw " Guide " " (upper) " " Screw (2) " Lubricator Oil Pad (felt) " " " Holder " " Reservoir " " Wick " " Screw " " " Washer Thread Lubricator complete, Nos. 214838 237779, 240439, 241755, 241758 and 241759 Thread Retainer " " Bracket with 200397X " " Screw (2) " " Set Screw " " Sleeve " " Sleeve

No.	Plate	Name
200397X	17314	Thread Retainer Stud Set Screw
210959	17314	Thread Retainer (lower) complete, Nos.
		210956 to 210958, 210993 and 223844
249179	15749	Throat Plate Body
249180	15749	" " Needle Plate, 56 elongated
		needle hole, for needle sizes 12 and
		13 (minimum trimming margin .045
		in.)
200587D	15749	Throat Plate Needle Plate Screw
249181	15749	Throat Plate complete, 56 elongated
		needle hole, for needle sizes 12 and
		13, Nos. 249179, 249180 and two
		200587D
200099X	15749	Throat Plate Screw (2)
249066	17330	Vertical Shaft
237745	17330	" Bevel Gear (lower)
205508	17330	" " " Position
		Pin
235857	17330	Vertical Shaft Bevel Gear (upper) with
		200374C and 200396C
200396C	17330	Vertical Shaft Bevel Gear (upper) Posi-
		tion Screw
200374C	17330	Vertical Shaft Bevel Gear (upper) Set
		Screw
237734	17330	Vertical Shaft Bushing (lower)
200346C	15739	" " Set Screw
237746	17330	" " (upper)
200362C	17330	" " Set Screw
237747	17325	" " Driving Gear with 200374C
		and 200396C
200396C	17325	Vertical Shaft Driving Gear Position
		Screw
200374C	17325	Vertical Shaft Driving Gear Set Screw
249067	17330	" Oil Leader (lower) (brass)
237755	17325	" " " (upper) (brass)

SINGER Needles should be used in SINGER Machines These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO.**"

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT SINGER made needles. 2

ACCESSORIES

No.	Plate	Name
233939	17313	Bobbin (2)
228288	15751	Drip Pan with four 3/4 in. wire nails
238632	15740	Feed Wheel Driving Pinion Spacing
Ĺ		Washer (for use in place of Feed
ř.		Wheel Driving Pinion when one or
		two lengths of stitch are required) (2)
238508	17328	Knife
41400	15757	Machine Rest Pin (wood)
16×4		Needles, three each, sizes 12 and 13
120342	15757	Oiler (copper plated) with 120343
120343	15757	" Spout (3-1/2 in. long)
4822	15757	Roller Presser Hinge Screw Nut Wrench
225498	15757	Screw Driver (7-1/4 in. long)
228476	15757	" (Bobbin Case)
225554	15757	Wrench (steel)

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

FOR 5/16 INCH ROUND BELT DRIVE

259428	16615	Brake (leather)
259429	16615	" Clamp
200113F	16615	" Screw
225453	16615	Frame with 202277 and 259660
225454	16615	" Hinge Pin
202277	16615	" Oil Packing (wick)
259660	16615	" Well Washer
225455	16615	" Spring
225456	16615	" " Plunger
225368	16615	Pulley with 200380C
200380C	16615	" Set Screw
225381	16615	Spindle
225444	\$ 16615	Stop Latch
200056E	16615	" " Screw
225458	16615	" " Thumb Lever
23-45-1	2 4n €€	* Ange Hist
225451	14-15	Journal Stand
202-75	16415	Trip Lever
2111.2001	24H 27	मितायुक्त उत्तरका र
225 46 I	16615	Tension Bracket with 201400X

16		ACCESSORIES
No	Dista	N
No. 200082D	Plate	Name
228026	16615	Tension Bracket Screw
2102	16615	wasner
13710	16615	Disc
	16615	Opting
201499X	16615	Stud
201572X	16615	ritatio ivat
225462	16615	Bobbin Winder Tension Bracket com- plete, Nos. 13710, 201572X, 225461 and two 2102
259430	16615	Bobbin Winder and Tension Bracket Base
259431	16615	Universal Bobbin Winder complete, Nos. 200056E, 200082D, 200113F, 200299X, 202478, 225368, 225381, 225444, 225453 to 225456, 225458, 225462, 228026, 259428 to 259430, two each 225459 and wood screws 3/4 in., No. 12, R. H. B.
		KNEE LIFTER
2763	17321	Rock Shaft
7539	17321	" Hanger with two wood screws
		1 in., No. 10
228364	17321	Rock Shaft Knee Plate with 350231C
228318	17321	" " " Arm
228685	17321	" " " Bracket with two 356C
356C	17321	Rock Shaft Knee Plate Arm Bracket Set Screw
228686	17321	Rock Shaft Knee Plate Arm Counter Balance Spring
356C	17321	Rock Shaft Knee Plate Arm Set Screw
150668	17321	" " " Pad (rubber)
350231C	17321	" " Set Screw
6337	17321	" " Lifting Bracket with two
39811	17321	Rock Shaft Lifting Bracket Extension with 39576
356C	17321	Rock Shaft Lifting Bracket Extension Set Screw
356C	17321	Rock Shaft Lifting Bracket Set Screw
227676	17321	" " Chain, 18 in. long, with
		202784
39576	17321	Rock Shaft Lifting Chain Hook (lower)
202784	17321	" " " (upper)
2770	17321	" " Stop Dog with 140219C
140219C	17321	" " Set Screw
228687	17321	Knee Lifter Rock Shaft complete, Nos. 2763 2770,6337,39811,150668,227676,

228318,228364,228685,228686 and two 7539

FEED GEARS

No.	Plate	Name
249020	15739	Feed Wheel Driving Gear (for 12
		stitches)
249021	15739	Feed Wheel Driving Gear (for 13 stitches)
249022	15739	Feed Wheel Driving Gear (for 14
24/022	13137	stitches)
249023	15739	Feed Wheel Driving Gear (for 15
		stitches)
249024	15739	Feed Wheel Driving Gear (for 16 stitches)
249025	15739	Feed Wheel Driving Gear (for 17
21,023	23.57	stitches)
249026	15739	Feed Wheel Driving Gear (for 18
		stitches)
249027	15739	Feed Wheel Driving Gear (for 19
21.00.20	15730	stitches)
249028	15739	Feed Wheel Driving Gear (for 20 stitches)
238641	15739	Feed Wheel Driving Gear (for 21
		stitches)
249029	15739	Feed Wheel Driving Gear (for 23
238642	15730	stitches) Feed Wheel Driving Gear (for 24
230042	15739	stitches)
238605	15739	Feed Wheel Driving Gear (for 26
		stitches)
238606	15739	Feed Wheel Driving Gear (for 29
238607	15739	stitches) Feed Wheel Driving Gear (for 32
230001	13737	stitches)
249034	15740	Feed Wheel Driving Pinion (for 12
		stitches)
249035	15740	Feed Wheel Driving Pinion (for 13
249036	15740	stitches) Feed Wheel Driving Pinion (for 14
21,030	13.10	stitches)
249037	15740	Feed Wheel Driving Pinion (for 15
		stitches)
249038	15740	Feed Wheel Driving Pinion (for 16
249039	15740	stitches) Feed Wheel Driving Pinion (for 17
		stitches)
249040	15740	Feed Wheel Driving Pinion (for 18
2Lantı	15760	stitches)
249041	15740	Feed Wheel Driving Pinion (for 19
		stitches)

1	N	ıE	E	Ц	0	N	11	١G	D	F	VI	F

No.	Plate	Name
249042	15740	Feed Wheel Driving Pinion (for 20
		stitches)
238655	15740	Feed Wheel Driving Pinion (for 21
		stitches)
249043	15740	Feed Wheel Driving Pinion (for 23
		stitches)
238656	15740	Feed Wheel Driving Pinion (for 24
		stitches)
238618	15740	Feed Wheel Driving Pinion (for 26
		stitches)
238619	15740	Feed Wheel Driving Pinion (for 29
		stitches)
238620	15740	Feed Wheel Driving Pinion (for 32
		stitches)

KNIFE HONING DEVICE

259281	17640	Base	with	457A	La	nd tv	vo 89	9 D	
259282	17640	11	25928	31 wi	th 6	74D,	721D	, 259	274 to
		25	9277,	2593	09.	2593	10.35	0372	C and
			0373				•		•
259266	17640	Knife	Hold	er Cl	am	p			
259267	17640	*1	11		••	Bas	e		
259268	17640	11	**		11	**	2592	267 w	vith
		7 7	1X, 13	59J,	360	06, 4	1544.	2592	266.
		25	9269 :	and 2	592	84			
899D	17640	Knife	Holde	er Cl	am	p Bas	se Lo	ckin	Q
		Th	umb S	Screv	v			•	
1359J	17640	Knife	Holde	r Cl	amı	p Hin	ge So	rew	
36006	17640	**	**		., .	•1			asher
259269	17640	**	11		11	Spri	ng		
259284	17640	11	11		• •	Was	her		
771X	17640	11	- 11	Clar	npi	ng T	humb	Scre	ew
41544	17640	11	- 11		,, .	0	11	11	
		Wa	sher						
259270	17640	Knife	Hone						
259271	17640	11	11 (Clam	D				
215057	17640	11	11		•	sitio	n Pin	ı	
200466X	17640	11	11	11	Th	umb	Scre	w	
259272	17640	**	**	Hold	er v	with	two 2	1505	7
259273	17640	11	**	"	25	9272	with	2592	70, two
		eac	h 200	466x				,	,
259274	17640	Knife	Hone	Hold	er	Guid	2		
259275	17640	11	**	11		*1	Coll	ar	
721D	17640	11	11	- 11		**	н	Set	Screw
259276	17640	- 11	**	11		11	11	Yok	:e
674D	17640	**	11	11		11	11	11	Hinge
		Scr	ew						0

No.	Plate	Name
259277	17640	Knife Hone Holder Guide Collar Yoke
		Hinge Screw Bushing
350372C	17640	Knife Hone Holder Guide Collar Yoke
		Hinge Screw Bushing Set Screw
350373X	17640	Knife Hone Holder Guide Thumb Set
		Screw
259310	17640	Knife Stop Pin (long)
259309	17640	" " (short)
457AL	. 17640	" " Set Screw
899D	17640	" " Thumb Screw
259283	17640	Honing Device complete, Nos. 259268,
		259273, 259282, Form 2399W and
		three wood screws $1-1/2$ in., No. 8

THROAT PLATES

249179	15749	Throat Plate Body
249187	15749	" Body
249182	15749	" Needle Plate, 56 elongated
		needle hole, for needle sizes 12 and
		13 (minimum trimming margin .035
		inch)
249180	15749	Throat Plate Needle Plate, 56 elongated
	•	needle hole, for needle sizes 12 and
		13 (minimum trimming margin .045
		inch)
249188	15749	Throat Plate Needle Plate, 56 elongated
,		needle hole, for needle sizes 12 and
		13 (minimum trimming margin . 045
		inch)
200587D	15749	Throat Plate Needle Plate Screw
249181	15749	
249101	15749	Throat Plate complete, 56 elongated
		needle hole, for needle sizes 12 and
		13, Nos. 249179, 249180 and two
		200587D
249183	15749	Throat Plate complete, 56 elongated
		needle hole, for needle sizes 12 and
		13, Nos. 249179, 249182 and two
		200587D
249189	15749	Throat Plate complete, 56 elongated
		needle hole, for needle sizes 12 and
		13, Nos. 249187, 249188 and two
		200587D (for long stitch)
		,

WOOD BASE

(OBLIQUE)

No.	Plate	Name
202259		Bed Hinge Plate
227493	15751	" " 202259 with two wood
		screws 7/8 in., No. 12H
225589	15751	Machine Cushion (leather)
228357	15751	Base with two 227493, four 225589 and
		eight wood screws 1-1/2 in., No.7

SINGER Needles should be used in SINGER Machines
These Needles and their Containers are marked with the
Company's Trade Mark "SIMANCO.**" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT SINGER made needles.

