

SINGER


159B2

159B2 PARTS LIST

Parts No.	Description	Parts No.	Description
159B2 0 2	Oil reservoir	159B2 0 25	Spreader lever large
" 0 3	Pulley	" 0 26	Spreader shaft with nut
" 0 4	Base cover	" 0 27	Collar for 0 25
" 0 4 A	Base cover side	" 0 28	Bushing for 0 29
" 0 4 B	Base cover front	" 0 29	Spreader lever small
" 0 4 C	Stopper spring	" 0 30	Screw for 0 29
" 0 5	Bracket for press spring	" 0 31	Pin for 0 29
" 0 6	Crank shaft	" 0 32	Spreader holder
" 0 7	Bushing lower front	" 0 33	Spreader
" 0 8	Bushing lower rear	" 0 34	Looper rod
" 0 9	Bushing lower middle	" 0 35	Ball stud for 0 34
" 0 10	Bushing upper rear	" 0 36	Guide plate for 0 33
" 0 11	Bushing upper middle	" 0 37	Shaft for 0 39
" 0 12	Flange bushing upper	" 0 38	Bushing for 0 39
" 0 13	Bushing upper front	" 0 39	Looper carrier
" 0 14	Crank connecting rod	" 0 40	Looper
" 0 14 A	Screw for 0 14	" 0 41	Eccentric cam for 0 34
" 0 15	Arm	" 0 42	Eccentric cam for 0 43
" 0 16	Arm shaft crank	" 0 43	Thread regulator rod
" 0 17	Collar for 0 18	" 0 44	Ball stud for 0 43
" 0 18	Looper thread take-up	" 0 45	Guide plate for 0 41
" 0 19	Needle thread take-up	" 0 46	Thread regulating lever
" 0 20	Presser foot right	" 0 46 A	Pin for 0 46
" 0 21	Presser foot left	" 0 47	Thread regulator
" 0 21 A	Presser foot guide	" 0 48	Feed eccentric cam
" 0 22	Looper eccentric cam	" 0 49	Feed rod
" 0 23	Spreader rod	" 0 50	Feed regulating screw set
" 0 23 A	Connecting rod for 0 23	" 0 50 A	Collar for 0 50
" 0 23 B	Nut for 0 23 A	" 0 50 B	Nut for 0 50
" 0 23 C	Nut small for 0 23 A	" 0 51	Feed shaft
" 0 24	Ball stud for 0 23 A	" 0 52	Feed shaft connection


Parts No.	Description
159B2 0-53	Wearing plate upper for 0 52
" 0-54	Wearing plate lower for 0-52
" 0-55	Throat plate
" 0-56	Feed dog
" 0-57	Ruler front
" 0-58	Ruler rear
" 0-59	Ruler lower
" 0-60	Thread guide bar
" 0-61	Looper thread guide
" 0-62	Cover plate
" 0-63	Thread guide
" 0-64	Arm shaft crank
" 0-65	Stud screw for crank
" 0-66	Needle bar connecting rod
" 0-67	Needle bar crank
" 0-68	Presser bar holder right
" 0-69	Presser bar holder left
" 0-70	Presser foot lifter lever
" 0-71	Pin for 0-71
" 0-72	Presser bar
" 0-73	Bushing upper for 0-72
" 0-74	Bushing lower for 0-72
" 0-75	Bracket for 0-70
" 0-76	Presser foot lifting lever
" 0-77	Presser foot lifting spring
" 0-78	Needle bar with nut
" 0-79	Bushing upper for 0-78
" 0-80	Bushing lower for 0-78
" 0-81	Feed shaft pin
" 0-82	Feed shaft
" 0-83	Bushing for 0-82
" 0-84	Feed cam
" 0-85	Needle thread guide
" 0-86	Collar for 0-15

Parts No.	Description
159B2-0-87	Stopper for 0 2
" 0-88	Screw for presser plate
" 0-89	Stopper for 0-89
" 0-90	Thread guide roller
" 0-91	Thread guide
" 0-92	Disc for 0-93
" 0-93	Thread tension set
" 0-94	Spring for 0 93
" 0-95	Nut for 0-93
" 0-96	Cover plate
" 0-97	Arm side cover
" 0-98	Spring piece for 0 93
" S 1	Screw for 0 3
" S 2	Screw for 0 53
" S 3	Screw for 0 96
" S 4	Screw for 0 78
" S 5	Screw for 0 40
" S 6	Screw for 0 36
" S 7	Screw for 0-66
" S 8	Screw for 0 97
" S 9	Screw for 0 60
" S 10	Screw for 0-47
" S 11	Screw for 0 20
" S 12	Screw for 0 7
" S 13	Screw for 0 57
" S 14	Screw for 0 4
" S 15	Screw for 0 75
" S-16	Screw for 0 5
" S 17	Screw for 0-91
" S-18	Screw for 0 56




0-2

0-3



0-4



0-4-A

0-4-B



0-5




0-4-C







0-7




0-8



0-9



0-10



0-11



0-12



0-13



0-14~A



0-16



0-17

0-18



0-19




0-14



0-15



0-20



0-21




0-22



0-21~A

0-23~B




0-23

0-23~A

0-23~C




0-24



0-26



0-27



0-28




0-31



0-33



0-35




0-34



0-41



0-36



0-39



0-37



0-38




0-45




0-40



0-42



0-43



0-46




0-44



0-46~A




0-47



0-48


0-49




0-56

0-50-A

0-50-B




0-50




0-58



0-60



0-52




0-57



0-61




0-62




0-51



0-53



0-54



0-55



0-59



0-63



0-64

0-65



0-66




0-67



0-68



0-71



0-70



0-69



0-72



0-73



0-75




0-76~A



0-76



0-74



0-77

- 10 -



0-78



0-79



0-81



0-82



0-80



0-83


0-85



0-86



0-84



0-88



0-87

- 11 -



0 - 89



0 - 90

0 - 91



0 - 92

0 - 94

0 - 95



0 - 93



0 - 96



0 - 97



S - 1



S - 2



S - 3



S - 4



S - 5



S - 6



S - 7



S - 8



S - 9



S - 10



S - 11



S - 12



S - 13



0 - 98



S - 14



S - 15



S - 16



S - 17



S - 18