

SINGER
17U130,U141,U142


MACHINE PARTS CHART **for** **SINGER***

17U130
17U141
17U142

* A Trademark of THE SINGER COMPANY


© THE SINGER COMPANY 1968


Printed in Japan



SINGER*

17U141





NUMERICAL LIST OF PARTS FOR MACHINES 17U130, 17U141 AND 17U142

CLOTH PLATE FOR MACHINES 17U130 AND 17U141





PART NO.	DESCRIPTION
547784	Cloth Plate
547785	Cloth Plate Bracket
547858	Cloth Plate Bracket Set Screw
549105 (853)	Cloth Plate Screw (2)
547860	Cloth Plate Slide
547849	Cloth Plate Slide Spring
549148 (832)	Cloth Plate Slide Spring Screw (2)

CLOTH PLATE FOR MACHINE 17U142

PART NO.	DESCRIPTION
549706	Cloth Plate
547857	Cloth Plate Bracket
547858	Cloth Plate Bracket Set Screw
549105 (853)	Cloth Plate Screw (2)
547860	Cloth Plate Slide
547849	Cloth Plate Slide Spring
549148 (832)	Cloth Plate Slide Spring Screw (2)
549708	Cloth Plate Washer (2)


ROLLER PRESSER FOR MACHINES 17U130 AND 17U141

PART NO.	DESCRIPTION
547735	Roller with 549061 (810) and 545454 (809)
547736	Roller Arm
504144 (810)	Roller Arm Adjusting Screw
547737	Roller Arm Adjusting Screw 504144 (810) with 545454 (809)
545454 (809)	Roller Arm Adjusting Screw Nut
547738	Roller Arm Bracket
2205	Roller Arm Lock Spring
549060 (810)	Roller Arm Lock Spring Screw
545455 (809)	Roller Arm Lock Spring Screw Nut
549059 (810)	Roller Arm Screw Center (2)
547739	Roller Arm Screw Center 549059 with 545454 (809)
545454 (809)	Roller Arm Screw Center Nut (2)
547740	Roller Presser complete, (7/8" fine roller) Nos. 2205, 545455 (809), 547735, 547736, 547737, 547738, 549060 (810) and two 547739
549061 (810)	Roller Screw
545454 (809)	Roller Screw Nut




PARTS ONLY FOR MACHINE

17U130



PARTS ONLY FOR MACHINE

17U142



NUMERICAL LIST OF PARTS FOR MACHINES 17U130, 17U141 AND 17U142

ACCESSORIES FOR MACHINE 17U142

PART NO.	DESCRIPTION
547794	Drip Pan
547781	Feed Reverse Lever Chain
547778	Feed Reversing Treadle complete
549071 (809)	Machine Bolt (4)
547766	Machine Bolt 549071 (809) with 545464 (809) and 6055
545464 (809)	Machine Bolt Nut (4)
6055	Machine Bolt Washer (4)
547773	Motor Treadle Lever
2083 (16×2)	Needle (6)
PN962	Oiler (filled with Singer Type "B" Oil)
2180	Presser Foot
PN963	Screw Driver (large)
PN964	Screw Driver (small)
2073	Shuttle Bobbin (4)
4918	Wrench (for 545456)
547930	Wrench (for 154981)
547846	Wrench (for 545454 and 545455)

KNEE LIFTER PARTS FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	DESCRIPTION
547829	Presser Bar Lifter Lever Chain
505397	Rock Shaft
547779	Rock Shaft complete, Nos. 505397, 547832, 547833 and two each 505651, 505398 and four Wood Screws (1 in. No. 10)
505398	Rock Shaft Hanger (2)
547831	Rock Shaft Knee Arm
547832	Rock Shaft Knee Arm complete, Nos. 504510 (809), 547831, 505400 and 505402
504510 (809)	Rock Shaft Knee Arm Clamping Nut
505400	Rock Shaft Knee Arm Hub with 504105 (809)
504105 (809)	Rock Shaft Knee Arm Hub Set Screw
505402	Rock Shaft Knee Plate with 504105 (809)
504105 (809)	Rock Shaft Knee Plate Set Screw
547833	Rock Shaft Lifting Bracket with 6338 and two 504105 (809)
6338	Rock Shaft Lifting Bracket Hook
504105 (809)	Rock Shaft Lifting Bracket Hook Set Screw
504105 (809)	Rock Shaft Lifting Bracket Set Screw
505651	Rock Shaft Stop Dog with 504105 (809)
504105 (809)	Rock Shaft Stop Dog Set Screw (2)

BOBBIN WINDER FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	DESCRIPTION
547787	Universal Bobbin Winder complete, Nos. 545962, 545963, 545965, 545966, 545968, 545969, 545970, 545971, 545976, 545977, 545978, 545979, 547788, 549200 (819), 549201 (819), 549202 (819), 549203 (819), 549205 and two 545980 with two 5.5×19 Wood Screws

PART NO.	DESCRIPTION
545979	Bobbin Winder and Tension Bracket Base
545977	Bobbin Winder Brake
545978	Bobbin Winder Brake Clamp
549202 (819)	Bobbin Winder Brake Clamp Screw
545966	Bobbin Winder Frame with 545967
549205	Bobbin Winder Frame Hinge Pin
545967	Bobbin Winder Frame Oil Cup
545968	Bobbin Winder Frame Spring
545969	Bobbin Winder Frame Spring Plunger
545962	Bobbin Winder Pulley with 549204 (819)
549204 (819)	Bobbin Winder Pulley Set Screw
547788	Bobbin Winder Spindle
545965	Bobbin Winder Stop Latch
549200 (819)	Bobbin Winder Stop Latch Screw
545970	Bobbin Winder Stop Latch Thumb Lever
545980	Bobbin Winder Stop Latch Thumb Lever Hinge Stud (2)
545963	Bobbin Winder Stop Latch Trip Lever
549203 (819)	Bobbin Winder Stop Latch Trip Lever Hinge Screw
545973	Bobbin Winder Tension Bracket with 545974
545971	Bobbin Winder Tension complete, Nos. 545470 (819), 545972, 545973 and two 545975
549201 (819)	Bobbin Winder Tension Bracket Screw
545976	Bobbin Winder Tension Bracket Screw Washer
545975	Bobbin Winder Tension Disc (2)
545972	Bobbin Winder Tension Spring
545974	Bobbin Winder Tension Stud
545470 (819)	Bobbin Winder Tension Stud Thumb Nut Wood Screw 5.5×19 (2)

THREAD UNWINDER FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	DESCRIPTION
505656	Thread Unwinder (for two spools) complete, Nos. 545465 (856), 545466 (856), 545467 (856), 546727, 546728, 546729, 546730, 546734, 546735, 546736, 546738, 546740, three 549171 and two each 545468 (856), 546732, 546733, 546737, 546739 and 546741
546732	Thread Unwinder Spool Pin (2)
545468 (856)	Thread Unwinder Spool Pin Nut (2)
546739	Thread Unwinder Spool Pin Spring Washer (2)
546741	Thread Unwinder Spool Pin Washer (2)
546738	Thread Unwinder Spool Rest Bushing with 549172 (850)
545466 (856)	Thread Unwinder Spool Rest Bushing Nut
546736	Thread Unwinder Spool Rest Bushing Nut Washer
549172 (850)	Thread Unwinder Spool Rest Bushing Set Screw
546737	Thread Unwinder Spool Rest Felt (2)
546730	Thread Unwinder Spool Rest (for two spools)
546728	Thread Unwinder Spool Rest Rod (lower)
549170 (828)	Thread Unwinder Spool Rest Rod (lower) Set Screw
546729	Thread Unwinder Spool Rest Rod (upper)
545467 (856)	Thread Unwinder Spool Rest Rod (upper) Nut
546727	Thread Unwinder Spool Stand with 549170 (828)
546733	Thread Unwinder Thread Guide (2)
545465 (856)	Thread Unwinder Thread Guide Lock Nut
546740	Thread Unwinder Thread Guide Lock Nut Spring Washer
546734	Thread Unwinder Thread Guide Position Cup
546735	Thread Unwinder Thread Guide Rod Washer
549171	Wood Screw No. 10×1 inch (3)

NUMERICAL LIST OF PARTS FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	17U 130	17U 141	17U 142	DESCRIPTION	PART NO.	17U 130	17U 141	17U 142	DESCRIPTION
229 (809)	*	*	*	Face Plate Thread Guard (upper) Screw	545256 (850)	*	*	*	Presser Bar Lifter Lever Hinge Screw
229 (809)	*	*	*	Thread Take-up Spring Regulator Plate Adjusting Screw	545284 (802)	*	*	*	Arm Shaft Screw
2070	*	*	*	Presser Bar Spring Washer	545306 (805)	*	*	*	Throat Plate Holder Screw (2)
2073	*	*	*	Shuttle Bobbin	545325 (809)	*	*	*	Shuttle Race Ring Screw (2)
2102	*	*	*	Tension Disc (2)	545382 (850)	*	*	*	Machine Pulley Set Screw (2)
2105	*	*	*	Tension Thread Guard	545404 (856)	*	*	*	Tension Regulating Thumb Nut
2113	*	*	*	Thread Retaining Disc Steady Pin	545454 (809)	*	*	*	Roller Arm Adjusting Screw Nut
2114	*	*	*	Thread Retaining Spring	545454 (809)	*	*	*	Roller Arm Screw Center Nut (2)
2115	*	*	*	Thread Retaining Stud	545454 (809)	*	*	*	Roller Screw Nut
2124	*	*	*	Thread Take-up Spring	545455 (809)	*	*	*	Roller Arm Lock Spring Screw Nut
2127	*	*	*	Thread Take-up Spring Regulator Plate	545456 (851)	*	*	*	Pressure Regulating Thumb Screw Lock Nut
2205	*	*	*	Roller Arm Lock Spring	545819	*	*	*	Feed Regulating Stud Lock Pin
2308	*	*	*	Presser Bar Spring	545820	*	*	*	Feed Regulating Stud Lock Pin Spring
3045	*	*	*	Needle Bar Connecting Link	547633	*	*	*	Tension Releaser Hinge Pin
12424	*	*	*	Oscillating Shaft Crank Slide Block Cap Screw Washer	547703	*	*	*	Arm Shaft
16242	*	*	*	Shuttle Race Ring Cover Latch	547706	*	*	*	Arm Side Cover
52016	*	*	*	Presser Bar Lifter	547707	*	*	*	Crank Connecting Rod with 125044 and two 504071 (833)
52165	*	*	*	Feed Connecting Link	547709	*	*	*	Face Plate with 2105
52239	*	*	*	Arm Spool Pin and Thread Eyelet	547710	*	*	*	Face Plate complete, Nos. 504029 (833), 549056 (833), 504149 (809), 56870, 547780, 547755, 2127, 547633, 547963, 547751, 547709 and two 229 (809)
56870	*	*	*	Face Plate Thread Guard (upper)	547712	*	*	*	Feed Dog Carrier
65163	*	*	*	Presser Foot (narrow toe)	547714	*	*	*	Feed Regulating Stud Head
65169	*	*	*	Shuttle Race Thread Protector	547715	*	*	*	Feed Regulating Stud Head 547714 with two Feed Regulating Stud Head Stop Plate
65170	*	*	*	Throat Plate	547716	*	*	*	Feed Regulator
99662	*	*	*	Feed Reverse Lever Return Spring	547717	*	*	*	Feed Regulator 547716 with 547782 and 549082 (850)
125044	*	*	*	Crank Connecting Rod Oil Pad (felt)	547718	*	*	*	Feed Rock Shaft 547775 with 547712
125314	*	*	*	Tension Spring	547719	*	*	*	Feed Rock Shaft Crank with 545236 (803)
154759 (850)	*	*	*	Crank Connecting Rod Hinge Screw	547720	*	*	*	Machine Pulley with two 545382 (850)
154759 (850)	*	*	*	Feed Connecting Link Hinge Screw (2)	547721	*	*	*	Needle Bar
154759 (850)	*	*	*	Feed Forked Connection Hinge Screw	547722	*	*	*	Needle Bar Connecting Link 3045 with 547723
154777 (850)	*	*	*	Needle Bar Connecting Stud Set Screw	547723	*	*	*	Needle Bar Connecting Stud with 154777 (850)
154981 (819)	*	*	*	Crank Connecting Rod Hinge Screw Nut	547725	*	*	*	Oscillating Rock Shaft with 547791
154981 (819)	*	*	*	Feed Connecting Link Hinge Screw Nut (2)	547726	*	*	*	Oscillating Rock Shaft complete, Nos. 547725 and 547728
154981 (819)	*	*	*	Feed Forked Connection Hinge Screw Nut	547727	*	*	*	Oscillating Rock Shaft Hinge Pin
154981 (819)	*	*	*	Needle Bar Connecting Link Hinge Screw Nut	547728	*	*	*	Oscillating Rock Shaft Hinge Pin 547727 with 504504 (819)
504002 (850)	*	*	*	Arm Shaft Bushing (intermediate) Set Screw	547729	*	*	*	Oscillating Shaft
504002 (850)	*	*	*	Feed Cam Set Screw	547730	*	*	*	Oscillating Shaft 547729 with 547774, 547777 and 548170
504002 (850)	*	*	*	Feed Regulating Stud Bushing Set Screw	547731	*	*	*	Oscillating Shaft Crank
504004 (852)	*	*	*	Arm Side Cover Thumb Screw	547732	*	*	*	Presser Bar
504004 (852)	*	*	*	Cylinder Side Cover Thumb Screw	547733	*	*	*	Presser Bar Lifter Bracket with 504056 (830)
504029 (833)	*	*	*	Belt Safety Guard Set Screw (2)	547734	*	*	*	Presser Bar Lifter Lever
504029 (833)	*	*	*	Tension Screw Stud Set Screw	547735	*	*	*	Roller with 549061 (810) and 545454 (809)
504056 (830)	*	*	*	Presser Bar Lifter Bracket Set Screw	547736	*	*	*	Roller Arm
504063 (810)	*	*	*	Presser Foot Screw	547737	*	*	*	Roller Arm Adjusting Screw 504144 (810) with 545454 (809)
504063 (810)	*	*	*	Roller Presser Screw	547738	*	*	*	Roller Arm Bracket
504064 (805)	*	*	*	Arm Screw (3)	547739	*	*	*	Roller Arm Screw Center 549059 (810) with 545454 (809)
504071 (833)	*	*	*	Crank Connecting Rod Cap Screw (2)	547740	*	*	*	Roller Presser complete, 7/8" fine roller, Nos. 2205, 545455 (809), 547735, 547736, 547737, 547738, 549060 (810) and two 547739
504074 (850)	*	*	*	Feed Regulating Stud Head Cap Screw	547741	*	*	*	Feed Forked Connection
504080 (851)	*	*	*	Face Plate Screw (3)					
504091 (803)	*	*	*	Feed Dog Screw					
504099 (809)	*	*	*	Feed Reverse Lever Return Spring Bracket Screw					
504101 (830)	*	*	*	Belt Safety Guard Shaft Set Screw					
504144 (810)	*	*	*	Roller Arm Adjusting Screw					
504149 (809)	*	*	*	Face Plate Thread Guard (lower) Screw					
504504 (819)	*	*	*	Oscillating Rock Shaft Hinge Pin Lock Nut					
505001	*	*	*	Arm Dowel Pin (2)					
505008	*	*	*	Arm Spool Pin Washer (felt)					
545056 (833)	*	*	*	Oscillating Shaft Crank Set Screw					
545232 (833)	*	*	*	Arm Shaft Bushing (back) Set Screw					
545232 (833)	*	*	*	Thread Take-up Cam Set Screw					
545236 (803)	*	*	*	Feed Rock Shaft Crank Set Screw					

NUMERICAL LIST OF PARTS FOR MACHINES 17U130, 17U141 AND 17U142

PART NO.	17U 130	17U 141	17U 142	DESCRIPTION
547742	*	*	*	Feed Forked Connection complete, Nos. 547741, 52165, 547717 and two each 154759 (850) and 154981 (819)
547743	*	*	*	Feed Cam with 504002 (850)
547744	*	*	*	Shuttle Bobbin 2073 with 547772
547745	*	*	*	Shuttle Race (body)
547746	*	*	*	Shuttle Race 547745 with 549067 (809) and 65169
547747	*	*	*	Shuttle Race complete, Nos. 547750, 547746, 547748 and two each 545325 (809) and 549066 (810)
547748	*	*	*	Shuttle Race Ring
547749	*	*	*	Shuttle Race Ring Cover
547750	*	*	*	Shuttle Race Ring Cover 547749 with 16242 and two 549135 (810)
547751	*	*	*	Tension complete, Nos. 125314, 2124, 547753 and two 2102
547752	*	*	*	Tension Screw Stud
547753	*	*	*	Tension Screw Stud 547752 with 545404 (856)
547754	*	*	*	Thread Retaining Disc with 2113
547755	*	*	*	Thread Retainer Guide complete, Nos. 547754, 2114 and 2115
547756	*	*	*	Thread Take-up Cam with 545232 (833)
547757	*	*	*	Thread Take-up Lever with Roller and Roller Stud
547758	*	*	*	Thread Take-up Lever 547757 with 549069 (851)
547759	*	*	*	Throat Plate Holder
547760	*	*	*	Throat Plate Holder 547759 with 65170
547767	*	*	*	Arm Shaft Bushing (intermediate)
547769	*	*	*	Arm Shaft Bushing (back)
547770	*	*	*	Arm Shaft Bushing (front)
547772	*	*	*	Shuttle Body with Cover
547774	*	*	*	Oscillating Shaft Crank complete, Nos. 547731, 547790, 549083 (809), 12424 and 545056 (833)
547775	*	*	*	Feed Rock Shaft
547776	*	*	*	Presser Bar Lifter Lever Spring
547777	*	*	*	Shuttle Driver and Feed Lifting Cam
547780	*	*	*	Face Plate Thread Guard (lower)
547782	*	*	*	Feed Reverse Lever
547783	*	*	*	Feed Reverse Lever Return Spring Bracket
547789	*	*	*	Feed Dog
547790	*	*	*	Oscillating Shaft Crank Slide Block
547791	*	*	*	Oscillating Rock Shaft Oil Pad (felt)
547792	*	*	*	Feed Reverse Lever Pitman
547793	*	*	*	Feed Regulating Stud Bushing
547795	*	*	*	Arm Shaft 547703 with 547743, 547756 and 548416
547838	*	*	*	Needle Clamp 547852 with 549055 (858) and 547839
547839	*	*	*	Needle Clamp Thread Guide 547851 with 549054 (851)
547851	*	*	*	Needle Clamp Thread Guide
547852	*	*	*	Needle Clamp (body)
547853	*	*	*	Needle Bar Bushing (2)
547853	*	*	*	Presser Bar Bushing
547855	*	*	*	Cylinder Side Cover
547960	*	*	*	Belt Safety Guard with two 504029 (833)
547961	*	*	*	Belt Safety Guard Shaft
547963	*	*	*	Tension Releaser
548170	*	*	*	Oscillating Shaft Crank Pin
548170	*	*	*	Shuttle Driver Pin
548416	*	*	*	Thread Take-up Cam Pin
549051 (803)	*	*	*	Feed Rock Shaft Crank Position Screw
549052 (803)	*	*	*	Needle Bar Connecting Link Hinge Screw

PART NO.	17U 130	17U 141	17U 142	DESCRIPTION
549054 (851)	*	*	*	Needle Clamp Thread Guide Screw
549055 (858)	*	*	*	Needle Clamp Screw
549056 (833)	*	*	*	Thread Retaining Stud Set Screw
549057 (810)	*	*	*	Presser Bar Lifter Screw
549058 (851)	*	*	*	Pressure Regulating Thumb Screw
549059 (810)	*	*	*	Roller Arm Screw Center (2)
549060 (810)	*	*	*	Roller Arm Lock Spring Screw
549061 (810)	*	*	*	Roller Screw
549066 (810)	*	*	*	Shuttle Race Ring Cover Screw (2)
549067 (809)	*	*	*	Shuttle Race Thread Protector Screw
549068 (810)	*	*	*	Shuttle Race Screw (4)
549069 (851)	*	*	*	Thread Take-up Lever Hinge Screw
549082 (850)	*	*	*	Feed Reverse Lever Set Screw
549083 (809)	*	*	*	Oscillating Shaft Crank Slide Block Cap Screw
549113 (803)	*	*	*	Feed Regulator Hinge Screw
549114 (803)	*	*	*	Feed Regulating Stud
549120 (806)	*	*	*	Throat Plate Screw (2)
549135 (810)	*	*	*	Shuttle Race Ring Cover Latch Screw (2)
549701	*	*	*	Feed Dog
549702	*	*	*	Shuttle Race (body)
549703	*	*	*	Shuttle Race complete, Nos. 549712, 547750, 549709 and two each 545325 (809) and 549066 (810)
549704	*	*	*	Throat Plate
549709	*	*	*	Shuttle Race Ring
549710	*	*	*	Feed Regulating Stud Head
549711	*	*	*	Feed Regulating Stud Head 549710 with two Feed Regulating Stud Head Stop Plate
549712	*	*	*	Shuttle Race 549702 with 549067 (809) and 65169
549713	*	*	*	Feed Dog
549714	*	*	*	Feed Dog Carrier
549715	*	*	*	Throat Plate
549717	*	*	*	Feed Regulating Stud Head
549718	*	*	*	Feed Regulating Stud Head 549717 with two Feed Regulating Stud Head Stop Plate

ACCESSORIES

FOR MACHINES 17U130 AND 17U141

PART NO.	DESCRIPTION
547794	Drip Pan
547781	Feed Reverse Lever Chain
547778	Feed Reversing Treadle complete
547763	Guide (roller) complete, Nos. 547765 and 547764
547764	Guide Bracket
547765	Guide Roller with 549070 (810)
549070 (810)	Guide Roller Screw Stud
504004 (809)	Guide Thumb Screw
549071 (809)	Machine Bolt (4)
547766	Machine Bolt 549071 (809) with 545464 (809) and 6055
545464 (809)	Machine Bolt Nut (4)
6055	Machine Bolt Washer (4)
547773	Motor Treadle Lever
2083 (16x2)	Needle (6)
PN962	Oiler (filled with Singer Type "B" Oil)
65164	Presser Foot (wide toe)
PN963	Screw Driver (large)
PN964	Screw Driver (small)
2073	Shuttle Bobbin (4)
4918	Wrench (for 545456)
547930	Wrench (for 154981)
547846	Wrench (for 545454 and 545455)