

SINGER

19W4

Form 3011w

(950)

Printed in U. S. A.

SHOP COPY


SINGER**

19w4




** A TRADE MARK OF

THE SINGER MANUFACTURING COMPANY




Copyright, U. S. A., 1939, 1940, 1941 and 1951,
by The Singer Manufacturing Company
All Rights Reserved for All Countries


13067 - 1/2




16615 - 1/2




17578 - 5/8





17581 - 1/2




17584 - 3/8




208918


$$206448 - \frac{3}{32} - \frac{7}{64} - \frac{1}{8} - \frac{9}{64} - \frac{5}{32}$$


206463 - $\frac{3}{16}$ - $\frac{7}{32}$ - $\frac{1}{4}$




17591 - 1/6



17596 - 2/3



17599 - 1/3



17600 - 3/8

