

Singer 24-35

Form E 361

Revised

January 31, 1917

COPY FOR M. T. D. FILE

ILLUSTRATED

PRICE LIST

OF

PARTS



MACHINE

NO. 24-35

THE SINGER MANUFACTURING COMPANY

ILLUSTRATED

PRICE LIST OF PARTS

FOR

MACHINE NO. 24-35

	NO.	PAGE	NAME	EACH
Serial	765	—	Arm, upper and lower (solid)	\$ —
	9712	3	" Rock Shaft with 1811	60
	1811	4	" " " Roller and Stud	20
	311c	3	" " " Screw Centre (front) ..	08
	310A	4	" " " " " (back) ..	08
	1516B	3	" " " " " " ..	
			Nut	05
Serial	766	—	Arm Rotary Shaft with Serial 28931 ..	1 00
	9504	4	Balance Wheel, 2¼ in. pulley, with 424c	90
	424c	4	Balance Wheel Set Screw	05
	9573	4	" " " Cover	25
	168B	3	" " " " Screw	04
	22306	4	Connecting Rod with two 1012B	50
	1012B	3	" " " Adjusting Screw	05
	44A	3	" " " Screw Stud	10
Serial	767	—	Cloth Plate	2 00
	387B	3	" " " Screw	06
	9935	—	Face Plate	25
	337B	3	" " " Screw	02
	9732	3	Looper with 34418	60
Serial	28931	4	" " Set Screw	03
	34418	—	" " Washer	01
	9560	—	Needle Bar	40
	34170	4	" " " Connecting Link with two 1313E	25

ILLUSTRATED PRICE LIST OF PARTS FOR MACHINE NO. 24-35

	NO.	PAGE	NAME	EACH
Serial 765	—		Arm, upper and lower (solid).....	\$ —
9712	3		“ Rock Shaft with 1811.....	60
1811	4		“ “ “ Roller and Stud.....	20
311c	3		“ “ “ Screw Centre (front).....	08
310A	4		“ “ “ “ “ (back).....	08
1516B	3		“ “ “ “ “ “.....	
			Nut.....	05
Serial 766	—		Arm Rotary Shaft with Serial 28931....	1 00
9504	4		Balance Wheel, 2¼ in. pulley, with 424c.....	90
424c	4		Balance Wheel Set Screw.....	05
9573	4		“ “ “ Cover.....	25
168B	3		“ “ “ “ Screw.....	04
22306	4		Connecting Rod with two 1012B.....	50
1012B	3		“ “ “ Adjusting Screw.....	05
44A	3		“ “ “ Screw Stud.....	10
Serial 767	—		Cloth Plate.....	2 00
387B	3		“ “ “ Screw.....	06
9935	—		Face Plate.....	25
337B	3		“ “ “ Screw.....	02
9732	3		Looper with 34418.....	60
Serial 28931	4		“ “ “ Set Screw.....	03
34418	—		“ “ “ Washer.....	01
9560	—		Needle Bar.....	40
34170	4		“ “ “ Connecting Link with two 1313E.....	25

PARTS FOR MACHINE NO. 24-35

	NO.	PAGE	NAME	EACH
	1313E	4	Needle Bar Connecting Link Adjusting Screw.....	\$ 02
	9570	4	Needle Bar Connecting Stud with 207E.	30
	207E	4	" " " " Clamping Screw.....	02
	9611	3	Needle Bar Thread Tube.....	08
	230A	—	" Set Screw.....	02
	9588	—	Presser Bar.....	40
	9531	4	" " Guide with 462c.....	20
	462c	4	" " " Set Screw.....	02
	9532	3	" " Lifter with 9533.....	20
	22275	3	" " " Steady Spring.....	03
	9533	4	" " " Stop Pin.....	02
	764B	4	" " " Screw.....	06
	1550	4	" " " " Nut.....	03
	9534	4	" " Spring.....	06
	9737	3	" Foot.....	50
	206A	4	" " Screw.....	02
	414B	3	Tension Body and Screw Stud.....	40
	9716	3	" Disc.....	05
	1543B	—	" Regulating Thumb Nut.....	05
	9717	3	" Spring.....	05
	9715	3	Tension complete, Nos. 414B, 1543B, 9717 and two 9716.....	60
	170A	3	Tension Thread Guide Stud.....	04
	9718	3	" " Hook (double).....	05
	330B	3	" " " Screw.....	02
	9937	3	Thread Eyelet (flat).....	05
	9938	3	" " " Spring Plate.....	05
	585B	4	" " Over Spool Pin.....	20
	337B	3	" " Screw.....	02
	9543	3	" Nipper Disc.....	02
	9544	3	" " " Cover.....	12
	228D	3	" " " " Screw.....	02
	9545	3	" " " Spring.....	05
Serial	638	—	Throat Plate, $\frac{3}{8}$ in. slot.....	75
Serial	901	—	" " $\frac{3}{4}$ " ".....	75
	244A	4	" " Screw.....	03
Serial	761	—	Thread Eyelet complete, 22 in. rod.....	25

3



