


HISTORICAL COPY  
DO NOT DESTROY  
RETURN TO STATIONARY DEPARTMENT



Form 19447

(1139)

PRINTED IN U. S. A.



SINGER


241-2



HISTORICAL COPY  
DO NOT DESTROY  
RETURN TO STATIONARY DEPARTMENT


THE SINGER MANUFACTURING COMPANY



800 342 8357




Copyright, U. S. A., 1939  
 by The Singer Manufacturing Co.  
 All Rights Reserved for all Countries

23204 - 1/2






23210 - 1/2




INSERT IN PLACE OF PLATE NOW SHOWING


22248 - 1/8




22919 - 2/3




22950 - 1/3







INSERT IN PLACE OF PLATE  
NOW SHOWING




23213 - 1/2



23214 - 2/3




23215 - 1/3




23216 - 2/3

259452










23217 - 2/3







23218 - 2/3
















28776



120207

