

SINGER

261-1

Form 21195
(561)
Printed in U. S. A.

LIST OF PARTS COMPLETE
FOR
NO. 261-1 MACHINE


SINGER^{*}
261-1
PARTS

THE SINGER COMPANY

Copyright ©1962 by The Singer Company
All Rights Reserved under Inter-American Copyright Union
Copyright under International Copyright Union


Printed in U. S. A.


*A Trademark of THE SINGER COMPANY



● When ordering, state color required.

■ When ordering, state gauge required.





LIST OF PARTS 261-1

CODE	PART NUMBER	NAME	COMPONENTS	CODE	PART NUMBER	NAME	COMPONENTS
1	143615	Oil Shield (felt) upper		97	147070	Arm Hole Plug Screw Washer	
2	143614	Oil Shield (felt) lower		98	23103	Connecting Link and Hinge Pin	
3	143552	BUSHING (back) COMP.	143485 with 143551	99	1047	Set Screw	
4	143485	Bushing (back)		100	141163	Shaft Screw (left)	
5	143551	Oil Seal (rubber)		101	446	Set Screw	
6	443	Set Screw		102	139534	Hinge Stud	
7	143486	Bushing (front)		103	1253	Set Screw (2)	
8	1520	Stud Nut		104	139030	Bushing Cover	
9	128531	Lock Washer		105	139031	Cover Gasket	
10	139059	CRANK	with 1057	106	143443	Bushing (left)	
11	1057	Pinch Screw		107	140331	Set Screw	
12	143484	Looper Holder Shaft		108	143462	LOOPER ECCENTRIC CONNECTION	with 1047
13	139509	Gasket (3)		109	143461	LOOPER ECCENTRIC AND FEED LIFTING ECCENTRIC	with two 1036
14	139510	Oil Plug (3)		110	1036	Set Screw (2)	
15	454	Set Screw		111	139432	Feed Lifting Eccentric Forked Connection	
16	198	Screw (2)		112	143451	Slide Block	
17	29043	Washer (2)		113	143450	Slide Block	
18	139181	Thread Cutter		114	143449	FEED ECCENTRIC (adjustable) COMPLETE	with 217, 7071, 50328 and two 51061
19	143524	Thread Guide					
20	456	Set Screw					
21	1187	Adjusting Screw					
22	51781	Nut					
23	139120	Guard Holder		115	217	Screw	
24	143479	Screw Stud (2)		116	51061	Set Screw (2)	
25	143480	Position Pin (2)		117	50328	Feed Regulating Screw	
26	143465	LOOPER GATE (left)	143464 with 51282 and 143470	118	7071	Clamping Washer	
	143467	LOOPER GATE (left)	143466 with 51282 and 143470	119	376	Bracket Screw	
	143469	LOOPER GATE (left)	143468 with 51282 and 143470	120	141001	Pressure Regulating Thumb Screw	
27	143470	Lock Spring		121	51614	Lock Nut	
28	51282	Screw		122	139158	Needle Thread Guide (2)	
29	143464	Looper Gate (left) for 2 1/32" Throat Plate		123	139158	Looper Thread Guide (2)	
	143466	Looper Gate (left) for 3/4" Throat Plate			139180	Needle Thread Guide	
	143468	Looper Gate (left) for 7/8" Throat Plate		124	139177	Bracket Thread Eyelet	
30	143483	Bushing (eccentric) (2)		125	207	Screw	
31	26276	Position Pin (2)		126	146612	Guide Pin	
32	141158	Socket Screw (2)		127	316	Stop Screw	
33	143482	LOOPER HOLDER (front)	with 141158, 26276	128	1547	Nut	
34	143481	LOOPER HOLDER (back)	with 141158, 26276	129	15444	STOP SCREW	316 with 1547
35	140393	Clamping Screw (2)		130	143512	Presser Bar Spring	
36	143612	DRIVING ARM CONNECTION	with four 175	131	68002	Tension Bracket	
37	175	Cap Screw (4)		132	143447	Face Plate	
38	139070	Ball Screw Stud		133	143543	Gasket	
39	1047	Set Screw		134	146694	LIFTING BRACKET	with 1057
40	139496	DRIVING ARM	with 1047	135	1057	Pinch screw	
41	143613	DRIVING ARM 139496	with 139070 and 143612	136	146751	Bushing (lower)	
42	139097	SHAFT COLLAR	with 1454	137	146752	PRESSER BAR STOP	with 190
43	1454	Pinch Screw		138	190	Presser Bar Stop Pinch Screw	
44	446	Set Screw			190	Presser Foot Screw	
45	139074	Slide Block		139	139462	Presser Bar	
46	143463	Stud		140	1133	Set Screw	
47	140202	Screw (4)		141	139138	PRESSER FOOT (triple hinged)	with 37160, 139134, 139135, 139137, 146167 and three 26276
48	140999	Plug Screw					
49	143435	Screw Gasket		142	37160	Spring (small)	
50	140295	Cover Screw (14)		143	26276	Hinge Pin (3)	
51	143433	Bed Cover		144	139134	Presser Foot Plate (back)	
52	143434	Gasket (cork)		145	139137	Presser Foot Shank	
53	51570	Tension Regulating Thumb Nut (2)		146	146167	Plate Connection	
54	59537	Spring Bushing (large) (2)		147	139135	Presser Foot Plate (front)	
55	131741	Tension Spring (2)		148	139281	Thread Tube (side)	
56	59538	Spring Bushing (small) (2)		149	1255	Feed Dog Screw	
57	32572	Releasing Disc (2)		150	443	Set Screw	
58	2102	Tension Disc (4)		151	1520	Lock Nut	
59	50326	Tension Screw Stud (2)		152	139516	Hinge Pin (eccentric)	
60	54388	Releasing Pin (2)		153	139046	Slide Block	
61	131696	Thread Guide (2)		154	704	Screw (short)	
62	146676	Lifting Bracket Lifter		155	172	Screw (long)	
63	807	Hinge Screw		156	140440	Plug Screw	
64	143510	Lifting Lever		157	12982	Needle Bar Bushing (upper)	
65	802	Hinge Screw		158	1133	Set Screw	
66	59539	TENSION SCREW STUD (2)	50326 with 51570	159	143492	Oil Wick Guide Tube	
67	161	Extension Screw (2)		160	143427	ARM ROTARY SHAFT	143426 with 140359, 143236, 143494
68	110	Hinge Screw (2)					
69	146620	Connecting Link		161	143494	CONNECTING LINK	with 139533 and 143495
70	54872	CRANK	with 624	162	140061	Pinch Screw	
71	140610	Arm Hole Plug Screw		163	143495	STUD	with 140061 and 143619
72	624	Set Screw		164	139533	Screw Cap	
73	143511	Lifting Lever Spring		165	143426	ARM ROTARY SHAFT	with 1036 and 140542
74	140050	Screw (upper)		166	140542	Position Screw	
75	1443	Screw (2)		167	1036	Set Screw	
76	121449	Clamping Plate		168	140552	Hinge Stud Clamping Screw	
77	139366	Slide		169	147079	Eyelet Bushing (2)	
78	68003	Releasing Shaft		170	143523	Needle Thread Take-up	
79	121586	Lap Seam Feller (adjustable)		171	12977	Needle Bar Bushing (lower)	
				172	1133	Set Screw	
80	229	Screw (4)		173	143488	Needle Bar	
81	140061	Screw (lower) (3)		174	143497	Thread Guide	
82	206	Screw		175	139116	NEEDLE CLAMP	with two 1498
83	143498	Needle Guard (3/32 to 3/16" Gauge)		176	1498	Needle Set Screw (2)	
	143541	Needle Guard (7/32 to 3/32" Gauge)		177	143489	NEEDLE BAR	143488 with 139116 and 143497
84	143487	Looper Thread Guide					
85	143452	Looper (back)		178	691	Throat Plate Screw (3)	
86	143453	Looper (front)		179	139538	Throat Plate	
87	143472	LOOPER GATE (right)	143471 with 51282 and 143477	180	143457	Oil Connection	
	143474	LOOPER GATE (right)	143473 with 51282 and 143477	181	120	Screw (2)	
	143476	LOOPER GATE (right)	143475 with 51282 and 143477	182	143459	Slide Block Cover (back)	
88	143477	Lock Spring		183	143460	Slide Block Cover (front)	
89	51282	Screw		184	1324	Pinch Screw	
90	143471	Looper Gate (right) for 2 1/32" Throat Plate		185	139257	CRANK	with 1324
	143473	Looper Gate (right) for 3/4" Throat Plate		186	143491	OIL WICK	143490 with 146703 and two 146580
	143475	Looper Gate (right) for 7/8" Throat Plate		187	146580	Oil Wick Clip (2)	
91	143478	Hinge Pin (2)		188	146703	Oil Wick Clamp and Retainer	
92	139535	COLLAR AND SUPPORT	with 51369 and two 1253	189	143490	Oil Wick	
				190	1485	Screw (2)	
93	139537	Feed Dog		191	143500	OIL PIPE	with two each 143124 and 143125
94	143448	Feed Bar					
95	225	Plug Screw		192	226	Screw (2)	
96	51369	Pinch Screw		193	143125	Sleeve Nut (6)	
				194	143124	Sleeve (6)	
				195	143126	Sleeve Adaptor (5)	

State gauge required

State color required