

# **SINGER**

**44-32 thru 37**

# Price List of Parts

## NUMBERS

**44-32**

**44-33**

**44-34**

**44-35**

**44-36**

**44-37**

## MACHINES.



The Singer Manufacturing Company.

# LIST OF PARTS

## Nos. 44-32 to 44-37

### MACHINES.

### INDEX.

|                                  | PAGE |
|----------------------------------|------|
| No. 44-32 Machine.....           | 4    |
| " 44-33 " .....                  | 14   |
| " 44-34 " .....                  | 19   |
| " 44-35 " .....                  | 27   |
| " 44-36 " .....                  | 35   |
| " 44-37 " .....                  | 41   |
| Attachments and Accessories..... | 43   |
| Bobbin Winder.....               | 46   |
| Driving Attachment .....         | 47   |
| Foot Lifter.....                 | 49   |
| Iron Base, Parts of.....         | 41   |
| Knee Lifter.....                 | 50   |
| Numerical List.....              | 55   |
| Obsolete Parts.....              | 53   |
| Thread Unwinder.....             | 51   |
| Under Driver.....                | 51   |

In ordering from this list, use **ONLY** the **PART** number in the first column.

The number stamped on Sewing Machine parts is in every case the number of the single part only.

Every combination of parts sent out as such, has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the **SAME PART** in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows :

- A. Hardened, Polished and Plated.
- B. Polished and Plated.
- C. Hardened only.
- D. Polished " "
- E. Soft, not Polished.

These letters **MUST BE USED** *when* they appear in the list, and **AFTER** the number, *as* in the list.

In this series

1 to 1500 are Screw Numbers.

1501 " 1800 " Nut " "

1801 " 2000 " Roller " "

2001 and upwards are numbers of Machine Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are **NOT TO BE USED** in ordering.

Parts marked with an asterisk (\*) are furnished only when repairs are made at factory.

When ordering parts which differ as to **GAUGE** (the distance between seams) the **GAUGE** as well as the **NUMBER MUST BE GIVEN** on orders.

## PARTS COMPLETE FOR

**No. 44-32 MACHINE.**

DROP FEED, TWO NEEDLES, TWO SHUTTLES. FOR LEATHER.

| No.    | Plate | Name                                                           | Each |
|--------|-------|----------------------------------------------------------------|------|
| *19107 | —     | Arm.....                                                       | 4 25 |
| 8582   | 1220  | " Dowel Pin.....                                               | 02   |
| 12453  | 1220  | " Oil Tube for intermediate bearing....                        | 06   |
| 12454  | 1220  | " " " " " oiling 12409.....                                    | 06   |
| 11119  | 1220  | " " " " " 19156.....                                           | 10   |
| 748E   | 782   | " Screw (back).....                                            | 08   |
| 868E   | 1221  | " " (front).....                                               | 10   |
| 16511  | 1200  | " Shaft.....                                                   | 1 90 |
| *11104 | —     | " Bushing (front).....                                         | 30   |
| 12357  | 1203  | " Flanged Bushing (back).....                                  | 25   |
| 448o   | 783   | " " " " " Set Screw.....                                       | 03   |
| 144d   | 782   | " " Screw.....                                                 | 12   |
| 12480  | 1205  | " Side Cap.....                                                | 05   |
| 219    | 790   | " " " Screw.....                                               | 02   |
| 12193  | 1202  | " " Cover.....                                                 | 10   |
| 286d   | 783   | " " " Thumb Screw.....                                         | 08   |
| 2415   | 1200  | " Spool Bracket.....                                           | 25   |
| 159    | 1221  | " " " Screw.....                                               | 03   |
| 12403  | 1220  | " " " Spool Pin and Thread<br>Eyelet.....                      | 05   |
| 11241  | 1203  | Arm Spool Bracket Washer (cloth) per 100.                      | 25   |
| 15063  | 1200  | " " " 2415 with two 12403....                                  | 35   |
| 12358  | —     | Balance Wheel, light rim, 2½-in. pulley,<br>with two 448o..... | 75   |
| 12359  | 1200  | Balance Wheel, light rim, 3-in. pulley, with<br>two 448o.....  | 75   |
| 448o   | 783   | Balance Wheel Set Screw.....                                   | 03   |
| *19108 | —     | Bed.....                                                       | 4 50 |
| 12496  | 1201  | Crank Connecting Rod.....                                      | 1 35 |
| *14013 | —     | " " " Cap.....                                                 | —    |
| 896E   | 1221  | " " " " Screw.....                                             | 04   |
| 908o   | 1221  | " " " " Hinge Screw.....                                       | 12   |
| 1619E  | 1222  | " " " " " Nut.....                                             | 05   |
| 19109  | —     | Face Plate.....                                                | 50   |
| 19110  | 1202  | " " 19109 with 19154, 19155 & two 12152                        | 1 00 |
| 190d   | 782   | " " Screw.....                                                 | 03   |
| 286d   | 783   | " " " Thumb Screw.....                                         | 08   |
| 19111  | 1208  | Feed Bar.....                                                  | 75   |
| 313o   | 783   | " " Screw Centre.....                                          | 04   |
| 1519E  | 783   | " " " " Nut.....                                               | 03   |
| 12197  | 1203  | " Cam and Feed Lifting Eccentric with<br>446o.....             | 50   |
| 446o   | 783   | Feed Cam and Feed Lifting Eccentric Set<br>Screw.....          | 03   |

| No.                                                   | Plate | Name                                                                            | Each |
|-------------------------------------------------------|-------|---------------------------------------------------------------------------------|------|
| 30E3                                                  | 1115  | Feed Connecting Link.....                                                       | 20   |
| 375o                                                  | 782   | " " " " Hinge Screw.....                                                        | 12   |
| 1518E                                                 | 783   | " " " " " Nut.....                                                              | 04   |
| 19295                                                 | 790   | " Dog with 19118, for ⅜-in. to ⅝-in.<br>gauge, for vamping.....                 | 1 25 |
| 19183                                                 | 787   | Feed Dog with 19118, for ⅜-in. to ⅝-in.<br>gauge, for shoe staying.....         | 1 50 |
| 20080                                                 | 798   | Feed Dog with 19118, for ⅜-in. to ⅝-in.<br>gauge (used with 19478).....         | 1 50 |
| Note: When ordering Feed Dogs give<br>gauge required. |       |                                                                                 |      |
| 191o                                                  | 1221  | Feed Dog Screw.....                                                             | 03   |
| 19116                                                 | 1220  | " " Spring.....                                                                 | 02   |
| 19117                                                 | 1220  | " " " Hook for 19120.....                                                       | 01   |
| 19118                                                 | 1220  | " " " " " Feed Dogs.....                                                        | 01   |
| 12123                                                 | 1201  | " Forked Connection.....                                                        | 60   |
| 375o                                                  | 782   | " " " " Hinge Screw.....                                                        | 12   |
| 1518E                                                 | 783   | " " " " " Nut.....                                                              | 04   |
| 16504                                                 | 766   | " Lifting Rock Shaft.....                                                       | 45   |
| 19236                                                 | —     | " " " " 16504 with 16506<br>and 19120.....                                      | 1 65 |
| 19120                                                 | 1208  | Feed Lifting Rock Shaft Crank (front) with<br>157E, 19117, 19121 and 19122..... | 1 00 |
| 157E                                                  | 782   | Feed Lifting Rock Shaft Crank (front)<br>Clamping Screw.....                    | 04   |
| 19121                                                 | 1208  | Feed Lifting Rock Shaft Crank (front) Roller                                    | 12   |
| 19122                                                 | 1208  | " " " " " " " Pin.....                                                          | 03   |
| 16556                                                 | 1208  | " " " " " " (back) with 462o                                                    | 20   |
| 2049                                                  | 1220  | " " " " " " " Pin.....                                                          | 01   |
| 462o                                                  | 1221  | " " " " " " Set Screw.....                                                      | 02   |
| 12430                                                 | 1201  | " " " " " Connecting Rod                                                        | 80   |
| *12204                                                | —     | " " " " " " " Cap.....                                                          | —    |
| 145E                                                  | 782   | Feed Lifting Rock Shaft Crank Connecting<br>Rod Cap Screw.....                  | 04   |
| 375o                                                  | 782   | Feed Lifting Rock Shaft Crank Connecting<br>Rod Hinge Screw.....                | 12   |
| 1518E                                                 | 783   | Feed Lifting Rock Shaft Crank Connecting<br>Rod Hinge Screw Nut.....            | 04   |
| 307o                                                  | 783   | Feed Lifting Rock Shaft Screw Centre.....                                       | 06   |
| 1513o                                                 | 783   | " " " " " " Nut.....                                                            | 05   |
| 3039                                                  | 768   | " Regulator.....                                                                | 25   |
| 58E                                                   | 782   | " " Hinge Screw.....                                                            | 15   |
| 818d                                                  | 783   | " " " Thumb ".....                                                              | 12   |
| 16506                                                 | 766   | " Rock Shaft.....                                                               | 35   |
| 16507                                                 | —     | " " " 16506 with 3043.....                                                      | 50   |
| 3043                                                  | 1208  | " " " Crank with 462o.....                                                      | 15   |
| 2049                                                  | 1220  | " " " " " Pin.....                                                              | 01   |
| 462o                                                  | 1221  | " " " " " Set Screw.....                                                        | 02   |
| 307o                                                  | 783   | " " " " " Screw Centre.....                                                     | 06   |
| 1513o                                                 | 783   | " " " " " " Nut.....                                                            | 05   |

| No.                                                         | Plate | Name                                                                                    | Each |
|-------------------------------------------------------------|-------|-----------------------------------------------------------------------------------------|------|
| 19230                                                       | 1228  | Guide.....                                                                              | 15   |
| 219                                                         | 790   | " " Screw.....                                                                          | 02   |
| 7071                                                        | 1220  | " " Washer.....                                                                         | 01   |
| 18014                                                       | 1203  | Needle Bar (hollow).....                                                                | 60   |
| 12382                                                       | 1144  | " " Connecting Link with 791e.....                                                      | 50   |
| 791e                                                        | 1144  | " " " " Adjusting Ser.....                                                              | 03   |
| 12383                                                       | —     | " " " " Stud.....                                                                       | 40   |
| 1904                                                        | 1144  | " " " " Roller (roller only).....                                                       | 12   |
| 453e                                                        | 783   | Needle Bar Connecting Stud Set Screw.....                                               | 02   |
| 12384                                                       | 1144  | " " " " " 12383 with 453e and 1904.....                                                 | 50   |
| 12385                                                       | 1203  | Needle Bar Crank with 855e and 858e.....                                                | 80   |
| 858e                                                        | 783   | " " " " Set Screw.....                                                                  | 03   |
| 855e                                                        | 783   | " " " " Timing Screw.....                                                               | 10   |
| 696e                                                        | 782   | " " " " Plug Screw.....                                                                 | 03   |
| 12495                                                       | 1220  | " " " " Rivet..... per 100.....                                                         | 05   |
| 936b                                                        | 1221  | " " " " Screw Bushing.....                                                              | 66   |
| 19124                                                       | 1218  | " " Clamp with two 460, for $\frac{1}{16}$ -in. to $\frac{3}{16}$ -in. gauge.....       | 1 25 |
| 19308                                                       | 1218  | Needle Clamp with 209 and 460, for $\frac{1}{16}$ -in. gauge and above.....             | 1 25 |
| 2273                                                        | 1219  | Needle Clamp Pin.....                                                                   | 01   |
| NOTE: When ordering No. 19124 or 19308 give gauge required. |       |                                                                                         |      |
| 460                                                         | 783   | Needle Set Screw for 19124 and 19308.....                                               | 02   |
| 209                                                         | 1221  | " " " (right) for 19308.....                                                            | 02   |
| 24020                                                       | 1206  | Oil Cup.....                                                                            | 20   |
| 24021                                                       | 1206  | " " Extension.....                                                                      | 05   |
| 12486                                                       | —     | " " Packing (felt).....                                                                 | 02   |
| 24022                                                       | 1206  | " " complete, Nos. 12486, 24020 & 24021.....                                            | 25   |
| 213                                                         | 1221  | " " " " Screw.....                                                                      | 03   |
| 19386                                                       | 1203  | Oscillating Rock Shaft.....                                                             | 1 00 |
| 19387                                                       | —     | " " " " 19386 with 4781 and 12388.....                                                  | 1 50 |
| 12388                                                       | 1203  | Oscillating Rock Shaft Hinge Pin.....                                                   | 50   |
| 878b                                                        | 783   | " " " " " Oil Hole Stop Screw.....                                                      | 06   |
| 12459                                                       | 1220  | Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather)..... per 100..... | 50   |
| 448e                                                        | 783   | Oscillating Rock Shaft Hinge Pin Set Screw.....                                         | 03   |
| 4781                                                        | 1101  | " " " " Oil Pad.....                                                                    | 01   |
| 19127                                                       | 1200  | " " " " Shaft.....                                                                      | 35   |
| 19496                                                       | —     | " " " " Crank.....                                                                      | 25   |
| 19388                                                       | 1208  | " " " " 19496 with 460e, 1518E and 19390.....                                           | 80   |
| 2049                                                        | 1220  | Oscillating Shaft Crank Pin.....                                                        | 01   |
| 460e                                                        | 783   | " " " " Set Screw.....                                                                  | 02   |
| 19389                                                       | 1208  | " " " " Slide Block.....                                                                | 35   |
| 229b                                                        | 782   | " " " " Cap Ser.....                                                                    | 02   |
| 12124                                                       | 1208  | " " " " Washer.....                                                                     | 02   |

| No.                                                                            | Plate | Name                                                                             | Each |
|--------------------------------------------------------------------------------|-------|----------------------------------------------------------------------------------|------|
| 969e                                                                           | 1208  | Oscillating Shaft Crank Slide Block Ser. Stud.....                               | 15   |
| 1518E                                                                          | 783   | " " " " " " " " Nut.....                                                         | 04   |
| 19390                                                                          | 1208  | Oscillating Shaft Crank Slide Block 19389 with 229b, 969e and 12424.....         | 50   |
| 12391                                                                          | 1203  | Presser Bar (hollow).....                                                        | 80   |
| 12326                                                                          | 1145  | " " " " Guide Bracket with 453e.....                                             | 25   |
| 453e                                                                           | 783   | " " " " Set Screw.....                                                           | 02   |
| 2062                                                                           | 1145  | " " " " Lifter.....                                                              | 25   |
| 689b                                                                           | 782   | " " " " Hinge Screw.....                                                         | 08   |
| 1520e                                                                          | 783   | " " " " " " Nut.....                                                             | 03   |
| 12327                                                                          | 1145  | " " " " Lifting and Releasing Lever Bracket.....                                 | 50   |
| 860E                                                                           | 782   | Presser Bar Plug Screw.....                                                      | 03   |
| 11167                                                                          | 1203  | " " " " Spring (spiral light (.051 wire).....                                    | 05   |
| 12139                                                                          | 1203  | " " " " " " medium (.055 " " ).....                                              | 05   |
| 20023                                                                          | 1203  | " " " " " " heavy (.063 " " ).....                                               | 05   |
| 11170                                                                          | 1220  | " " " " Washer.....                                                              | 01   |
| 19333                                                                          | 1223  | " " Foot for inside stays.....                                                   | 1 50 |
| 19186                                                                          | 1223  | " " " (long toe) for inside stays.....                                           | 1 50 |
| 20051                                                                          | 1223  | " " " with keel, slotted for tape, for staying.....                              | 1 75 |
| 19476                                                                          | 1227  | Presser Foot for 19478.....                                                      | 2 50 |
| 19477                                                                          | 1227  | " " " Bracket with 465e.....                                                     | 1 60 |
| 465e                                                                           | 1227  | " " " " Set Screw.....                                                           | 01   |
| 4460                                                                           | 1227  | " " " " Guide with 735e.....                                                     | 75   |
| 735e                                                                           | 1227  | " " " " Set Screw.....                                                           | 02   |
| 4461                                                                           | 1227  | " " " " Spring.....                                                              | 02   |
| 4462                                                                           | 1227  | " " " " Screw Bushing.....                                                       | 15   |
| 1607b                                                                          | 1227  | " " " " Stop Nut.....                                                            | 03   |
| 19478                                                                          | 1227  | " " " complete (spring presser) Nos. 1607b, 4460 to 4462, 19476 and 19477.....   | 5 00 |
| 190b                                                                           | 782   | Presser Foot Screw.....                                                          | 03   |
| NOTE: When ordering Presser Feet or parts of Presser Feet give gauge required. |       |                                                                                  |      |
| 688E                                                                           | 783   | Pressure Regulating Thumb Screw.....                                             | 25   |
| 1839                                                                           | 1210  | Roller, $1\frac{1}{2}$ -in. diam., with 386b and 1548b, for 19211 and 19212..... | 40   |
| 1875                                                                           | 1210  | Roller, $1\frac{1}{2}$ -in. diam., with 634b and 1548b, for 19213 and 19214..... | 60   |
| 19196                                                                          | —     | Roller Arm for 19211.....                                                        | 20   |
| 19197                                                                          | —     | " " " " 19212.....                                                               | 20   |
| 19198                                                                          | —     | " " " " 19213.....                                                               | 20   |
| 19199                                                                          | —     | " " " " 19214.....                                                               | 20   |
| 440                                                                            | 1221  | " " " " Adjusting Screw.....                                                     | 03   |
| 1547b                                                                          | 1146  | " " " " " " Nut.....                                                             | 03   |
| 19200                                                                          | —     | " " " " Bracket for 19212 and 19214.....                                         | 30   |
| 17567                                                                          | —     | " " " " " " 19211.....                                                           | 30   |
| 4777                                                                           | —     | " " " " " " 19213.....                                                           | 35   |
| 316                                                                            | 1221  | " " " " " " Screw Centre.....                                                    | 03   |
| 1547b                                                                          | 1146  | " " " " " " Nut.....                                                             | 03   |

| No.   | Plate | Name                                                                                                                                                                                                                    | Each |
|-------|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 7556  | 1210  | Roller Arm Lock Spring.....                                                                                                                                                                                             | 05   |
| 176   | 1221  | " " " " Screw.....                                                                                                                                                                                                      | 03   |
| 1549D | 1222  | " " " " Nut.....                                                                                                                                                                                                        | 03   |
| 19201 | 1210  | " Needle Guard (flat) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in.<br>gauge, for 19211.....                                                                                                                               | 40   |
| 19204 | 1210  | Roller Needle Guard (flat) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in.<br>gauge, for 19213.....                                                                                                                          | 40   |
| 207   | 1219  | Roller Needle Guard (flat) Screw.....                                                                                                                                                                                   | 02   |
| 19207 | 1210  | " " " (round) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in.<br>gauge, for 19211.....                                                                                                                                       | 45   |
| 19208 | 1210  | Roller Needle Guard (round) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in.<br>gauge, for 19212 and 19214.....                                                                                                               | 45   |
| 19209 | 1210  | Roller Needle Guard (round) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in.<br>gauge, for 19213.....                                                                                                                         | 45   |
| 171   | 1221  | Roller Needle Guard (round) Set Screw.....                                                                                                                                                                              | 03   |
| 19211 | 1209  | " Presser complete, $1\frac{1}{2}$ -in. roller, Nos.<br>171, 176, 207, 440, 1549D, 1839, 7556, 17567,<br>19196, 19201, 19207, two 316 and three 1547D,<br>for $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge.....     | 2 05 |
| 19212 | 1209  | Roller Presser complete, $1\frac{1}{2}$ -in. roller, Nos.<br>171, 176, 440, 1549D, 1839, 7556, 19197,<br>19200, 19208, two 316 and three 1547D, for<br>$\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge.....            | 4 65 |
| 19213 | 1209  | Roller Presser complete, $1\frac{1}{2}$ -in. roller, Nos.<br>171, 176, 207, 440, 1549D, 1875, 4777, 7556,<br>19198, 19204, 19209, two 316 and three 1547D,<br>for $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge..... | 2 25 |
| 19214 | 1209  | Roller Presser complete, $1\frac{1}{2}$ -in. roller, Nos.<br>171, 176, 440, 1549D, 1875, 7556, 19199, 19200,<br>19208, two 316 and three 1547D, for $\frac{1}{32}$ -in.<br>to $\frac{1}{16}$ -in. gauge.....            | 1 85 |
| 190D  | 782   | Roller Presser Screw.....                                                                                                                                                                                               | 03   |
| 386D  | 1101  | " Screw for 1839.....                                                                                                                                                                                                   | 08   |
| 634D  | 1221  | " " " 1875.....                                                                                                                                                                                                         | 08   |
| 1548D | 1222  | " " Nut.....                                                                                                                                                                                                            | 03   |

NOTE: When ordering Roller Pressers or  
parts of Roller Pressers give  
gauge required.

|       |      |                                                                                      |      |
|-------|------|--------------------------------------------------------------------------------------|------|
| 19131 | 1216 | Shuttle (inside) Bobbin.....                                                         | 05   |
| 19134 | 1216 | " " " Case Latch and Posi-<br>tion Finger.....                                       | 35   |
| 2521  | 1216 | Shuttle (inside) Bobbin Case Latch and Posi-<br>tion Finger Spring.....              | 02   |
| 592E  | 1216 | Shuttle (inside) Bobbin Case Latch and Posi-<br>tion Finger Stop Screw.....          | 02   |
| 19132 | 1216 | Shuttle (inside) Bobbin Case complete, Nos.<br>591, 592E, 2521, 19134 and 19149..... | 75   |
| 19136 | 1216 | Shuttle (inside) Body for 19129.....                                                 | 75   |
| 591   | 1216 | " " Tension Regulating Screw.....                                                    | 02   |
| 19149 | 1216 | " " Spring for 19132.....                                                            | 10   |
| 19129 | 1216 | Shuttle (inside) $1\frac{1}{16}$ -in. diam., No. 19136 with<br>19131 and 19132.....  | 1 50 |

| No.    | Plate | Name                                                                                                                             | Each |
|--------|-------|----------------------------------------------------------------------------------------------------------------------------------|------|
| 19131  | 1216  | Shuttle (outside) Bobbin.....                                                                                                    | 05   |
| 19135  | 1216  | " " " Case Latch and<br>Position Finger.....                                                                                     | 35   |
| 2521   | 1216  | Shuttle (outside) Bobbin Case Latch and<br>Position Finger Spring.....                                                           | 02   |
| 592E   | 1216  | Shuttle (outside) Bobbin Case Latch and<br>Position Finger Stop Screw.....                                                       | 02   |
| 19170  | 1216  | Shuttle (outside) Bobbin Case complete,<br>Nos. 591, 592E, 2521, 19135 and 19172.....                                            | 75   |
| 19137  | 1216  | Shuttle (outside) Body for 19130.....                                                                                            | 75   |
| 19171  | 1217  | " " " " 19169.....                                                                                                               | 75   |
| 591    | 1216  | " " Tension Regulating Screw.....                                                                                                | 02   |
| 19172  | 1216  | " " Spring for 19170.....                                                                                                        | 10   |
| 19169  | 1217  | " " $1\frac{1}{16}$ -in. diam., No. 19171<br>with 19131 and 19170, for gauges up to<br>$\frac{1}{16}$ -in.....                   | 1 50 |
| 19130  | 1216  | Shuttle (outside) $1\frac{1}{16}$ -in. diam., No. 19137<br>with 19131 and 19170, for $\frac{1}{32}$ -in. gauge and<br>above..... | 1 50 |
| *19138 | -     | Shuttle Driver.....                                                                                                              | 2 50 |
| 19139  | 1208  | " " 19138 with two 453c.....                                                                                                     | 2 50 |

NOTE: When ordering 19139 give gauge  
required.

|       |      |                                                                                    |      |
|-------|------|------------------------------------------------------------------------------------|------|
| 2019  | 1220 | Shuttle Driver Pin.....                                                            | 01   |
| 453c  | 783  | " " Set Screw.....                                                                 | 02   |
| 19277 | -    | " Race Body.....                                                                   | 1 75 |
| 19278 | 1212 | " " Loop Separator.....                                                            | 1 50 |
| 934D  | 1221 | " " " Screw.....                                                                   | 02   |
| 19279 | 1212 | " " Ring (inside).....                                                             | 1 50 |
| 19280 | 1212 | " " " (outside).....                                                               | 1 50 |
| 2532  | 1220 | " " Position Pin, per 100.....                                                     | 10   |
| 2533  | 1215 | " " Spring.....                                                                    | 15   |
| 907D  | 1221 | " " " Screw.....                                                                   | 05   |
| 19282 | 1212 | " " complete, Nos. 19277 to 19280,<br>two each 907D, 934D, 2533 and four 2532..... | 6 00 |

NOTE: When ordering Shuttle Races or  
parts of Shuttle Races give  
gauge required.

|       |      |                                                                 |    |
|-------|------|-----------------------------------------------------------------|----|
| 145   | 782  | Shuttle Race Screw.....                                         | 04 |
| 19145 | 1204 | " " Slide (inside).....                                         | 30 |
| 19146 | 1204 | " " " (outside) for $\frac{7}{16}$ -in. gauge<br>and below..... | 25 |
| 19147 | 1220 | Shuttle Race Slide Friction Spring.....                         | 03 |
| 651E  | 1221 | " " " " Screw.....                                              | 01 |
| 19148 | 1204 | " " " Guide with 651E & 19147.....                              | 50 |
| 19185 | 1204 | " " " (front) with 651E<br>and 19147 for 19230 and 26268.....   | 50 |
| 691   | 782  | Shuttle Race Slide Guide Screw.....                             | 04 |
| 2921  | 1146 | Tension Disc.....                                               | 05 |
| 19191 | 1146 | " Plate for upper tension with 19231.....                       | 50 |
| 134D  | 1221 | " " Screw.....                                                  | 06 |
| 1560c | 1146 | " Regulating Thumb Nut.....                                     | 04 |

| No.                                                    | Plate | Name                                                                                                                              | Each |
|--------------------------------------------------------|-------|-----------------------------------------------------------------------------------------------------------------------------------|------|
| 19192                                                  | 1146  | Tension Releaser.....                                                                                                             | 15   |
| 12397                                                  | 1145  | " Releasing Lever.....                                                                                                            | 20   |
| 12398                                                  | 1145  | " " " Hinge Pin.....                                                                                                              | 01   |
| 12329                                                  | 1145  | " " " Spring.....                                                                                                                 | 02   |
| 19193                                                  | 1146  | " " " (intermediate).....                                                                                                         | 10   |
| 19231                                                  | 1146  | " " " ".....                                                                                                                      |      |
| 2269                                                   | 1146  | Hinge Block.....                                                                                                                  |      |
|                                                        |       | Tension Releasing Lever (intermediate).....                                                                                       |      |
|                                                        |       | Hinge Pin.....                                                                                                                    | 01   |
| 19194                                                  | 1146  | Tension Releasing Lever (intermediate).....                                                                                       |      |
|                                                        |       | Spring.....                                                                                                                       | 03   |
| 916                                                    | 1146  | Tension Screw Stud.....                                                                                                           | 08   |
| 1547D                                                  | 1146  | " " " Nut.....                                                                                                                    | 03   |
| 2923                                                   | 1146  | " Spring.....                                                                                                                     | 03   |
| 12149                                                  | 1218  | " Thread Guard.....                                                                                                               | 05   |
| 19195                                                  | 1146  | (upper) complete with Tension Release, Nos. 2269, 19191, 19193, 19194, two each 916, 1547D, 1560c, 2923, 19192 and four 2921..... | 1 50 |
| 19154                                                  | 1220  | Thread Guard (lower) for 19110.....                                                                                               | 25   |
| 12152                                                  | 1220  | " " " Rivet.....per 100..                                                                                                         | 10   |
| 19155                                                  | 1220  | " " (upper) for 19110.....                                                                                                        | 20   |
| 12152                                                  | 1220  | " " " Rivet.....per 100..                                                                                                         | 10   |
| 19159                                                  | 1218  | " Guide Body.....                                                                                                                 | 30   |
| 19161                                                  | 1218  | " " Cap.....                                                                                                                      | 10   |
| 19160                                                  | 1218  | " " Roller.....                                                                                                                   | 10   |
| 905D                                                   | 1218  | " " Screw.....                                                                                                                    | 04   |
| 19162                                                  | ---   | " " complete (roller) Nos. 905D and 19159 to 19161.....                                                                           | 50   |
| 12404                                                  | 1144  | Thread Take-up Crank.....                                                                                                         | 80   |
| 3094                                                   | 1144  | " " " " Wedge.....                                                                                                                | 10   |
| 690E                                                   | 1144  | " " " " Screw.....                                                                                                                | 05   |
| 19156                                                  | 1144  | " " " Lever.....                                                                                                                  | 30   |
| 775E                                                   | 1144  | " " " " Cap Screw.....                                                                                                            | 06   |
| 12166                                                  | 1144  | " " " " Hinge Pin.....                                                                                                            | 05   |
| 12409                                                  | 1144  | " " " " Link.....                                                                                                                 | 25   |
| 11204                                                  | 1144  | " " " " " Hinge Pin.....                                                                                                          | 15   |
| 430D                                                   | 1144  | " " " " " ".....                                                                                                                  |      |
|                                                        |       | Set Screw.....                                                                                                                    | 04   |
| 19157                                                  | 1144  | Thread Take-up Lever 19156 with 12166 and 12409.....                                                                              | 65   |
| 19158                                                  | 1218  | Thread Take-up Spring (music wire).....                                                                                           | 03   |
| 7336                                                   | 1218  | " " " " Regulator.....                                                                                                            | 25   |
| 448c                                                   | 783   | " " " " " Set Scr.....                                                                                                            | 03   |
| 19184                                                  | 787   | Throat Plate for 19183.....                                                                                                       | 1 50 |
| 19296                                                  | 790   | " " " with Loop Separator (solid) for 19295.....                                                                                  | 1 50 |
| 20081                                                  | 798   | Throat Plate for 20083.....                                                                                                       | 1 50 |
| 691                                                    | 782   | " " Screw.....                                                                                                                    | 04   |
| NOTE: When ordering Throat Plates give gauge required. |       |                                                                                                                                   |      |
| 24079                                                  |       | Drip Pan with four 1-in wire nails.....                                                                                           | 25   |

NOTE: When ordering Throat Plates give gauge required.

**No. 44-33 MACHINE.**

DROP FEED, TWO NEEDLES, TWO SHUTTLES, FOR LEATHER,  
WITH MECHANISM FOR STOPPING THE LEFT HAND NEEDLE.

| No.    | Plate | Name                                                                     | Each |
|--------|-------|--------------------------------------------------------------------------|------|
| *19232 |       | Arm.....                                                                 | 4 25 |
| 8582   | 1220  | " Dowel Pin.....                                                         | 02   |
| 12453  | 1220  | " Oil Tube for intermediate bearing....                                  | 06   |
| 12454  | 1220  | " " " " oiling 12409.....                                                | 06   |
| 11119  | 1220  | " " " " 19156.....                                                       | 10   |
| 748E   | 782   | " Screw (back).....                                                      | 08   |
| 868E   | 1221  | " " (front).....                                                         | 10   |
| 16511  | 1200  | " Shaft.....                                                             | 1 90 |
| *11104 |       | " " Bushing (front).....                                                 | 30   |
| 12357  | 1203  | " " Flanged Bushing (back).....                                          | 25   |
| 448c   | 783   | " " " " Set Screw.....                                                   | 03   |
| 141D   | 782   | " " Screw.....                                                           | 12   |
| 12480  | 1205  | " Side Cap.....                                                          | 05   |
| 219    | 790   | " " " Screw.....                                                         | 02   |
| 12193  | 1202  | " " Cover.....                                                           | 10   |
| 286D   | 783   | " " " Thumb Screw.....                                                   | 08   |
| 2415   | 1200  | " Spool Bracket.....                                                     | 25   |
| 159    | 1221  | " " " Screw.....                                                         | 03   |
| 12403  | 1220  | " " " Spool Pin and Thread<br>Eyelet.....                                | 05   |
| 11241  | 1203  | Arm Spool Bracket Washer (cloth) per 100.....                            | 25   |
| 15063  | 1200  | " " " 2415 with two 12403....                                            | 35   |
| 12358  | -     | Balance Wheel, light rim, 2½-in. pulley,<br>with two 448c.....           | 75   |
| 12359  | 1200  | Balance Wheel, light rim, 3-in. pulley, with<br>two 448c.....            | 75   |
| 448c   | 783   | Balance Wheel Set Screw.....                                             | 03   |
| *19108 | -     | Bed.....                                                                 | 4 50 |
| 12496  | 1201  | Crank Connecting Rod.....                                                | 1 35 |
| *14013 |       | " " " Cap.....                                                           |      |
| 896R   | 1221  | " " " Screw.....                                                         | 01   |
| 908c   | 1221  | " " " Hinge ".....                                                       | 12   |
| 1619E  | 1222  | " " " " Nut.....                                                         | 05   |
| 19233  | -     | Face Plate.....                                                          | 75   |
| 19234  | 1202  | " " 19233 with 185, 9544, 9545, 12152,<br>19154, 19337 and two 9543..... | 1 25 |
| 286D   | 783   | Face Plate Thumb Screw.....                                              | 08   |
| 19111  | 1208  | Feed Bar.....                                                            | 75   |
| 313c   | 783   | " " " Screw Centre.....                                                  | 04   |
| 1549E  | 783   | " " " " Nut.....                                                         | 03   |
| 12197  | 1203  | " Cam and Feed Lifting Eccentric with<br>446c.....                       | 50   |

## No. 44-33 Machine Parts.

| No.                                                | Plate | Name                                                                                                                            | Each |
|----------------------------------------------------|-------|---------------------------------------------------------------------------------------------------------------------------------|------|
| 446c                                               | 783   | Feed Cam & Feed Lifting Eccentric Set Ser.                                                                                      | 03   |
| 3033                                               | 1145  | " Connecting Link.....                                                                                                          | 20   |
| 375c                                               | 782   | " " " Hinge Screw.....                                                                                                          | 12   |
| 1518E                                              | 783   | " " " " Nut.....                                                                                                                | 04   |
| 19183                                              | 787   | " Dog with 19118, for $\frac{1}{8}$ -in. to $\frac{3}{16}$ -in. gauge, for shoe staying.....                                    | 1 50 |
| 20070                                              | 796   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{3}{8}$ -in. gauge, one long and one short row of teeth, for vamping..... | 1 50 |
| NOTE: When ordering Feed Dogs give gauge required. |       |                                                                                                                                 |      |
| 191c                                               | 1221  | Feed Dog Screw.....                                                                                                             | 03   |
| 19116                                              | 1220  | " " Spring.....                                                                                                                 | 02   |
| 19117                                              | 1220  | " " " Hook for 19120.....                                                                                                       | 01   |
| 19118                                              | 1220  | " " " " " Feed Dogs.....                                                                                                        | 01   |
| 12123                                              | 1201  | " Forked Connection.....                                                                                                        | 60   |
| 375c                                               | 782   | " " " " Hinge Screw.....                                                                                                        | 12   |
| 1518E                                              | 783   | " " " " " Nut.....                                                                                                              | 04   |
| 16504                                              | 766   | " Lifting Rock Shaft.....                                                                                                       | 45   |
| 19236                                              |       | " " " " 16504 with 16536 and 19120.....                                                                                         | 1 65 |
| 19120                                              | 1208  | Feed Lifting Rock Shaft Crank (front) with 157E, 19117, 19121 and 19122.....                                                    | 1 00 |
| 157E                                               | 782   | Feed Lifting Rock Shaft Crank (front) Clamping Screw.....                                                                       | 04   |
| 19121                                              | 1208  | Feed Lifting Rock Shaft Crank (front) Roller.....                                                                               | 12   |
| 19122                                              | 1208  | " " " " " " " Pin.....                                                                                                          | 03   |
| 16556                                              | 1208  | " " " " " " (back) with 462c.....                                                                                               | 20   |
| 2049                                               | 1220  | Feed Lifting Rock Shaft Crank (back) Pin.....                                                                                   | 01   |
| 462c                                               | 1221  | " " " " " " " Set Ser.....                                                                                                      | 02   |
| 12430                                              | 1201  | " " " " " " Connecting Rod.....                                                                                                 | 80   |
| *12204                                             |       | Feed Lifting Rock Shaft Crank Connecting Rod Cap.....                                                                           |      |
| 145E                                               | 782   | Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw.....                                                                     | 04   |
| 375c                                               | 782   | Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw.....                                                                   | 12   |
| 1518E                                              | 783   | Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut.....                                                               | 04   |
| 307c                                               | 783   | Feed Lifting Rock Shaft Screw Centre.....                                                                                       | 06   |
| 1513c                                              | 783   | " " " " " " Nut.....                                                                                                            | 05   |
| 3039                                               | 768   | " Regulator.....                                                                                                                | 25   |
| 58E                                                | 782   | " " Hinge Screw.....                                                                                                            | 15   |
| 818D                                               | 783   | " " Thumb ".....                                                                                                                | 12   |
| 16506                                              | 766   | " Rock Shaft.....                                                                                                               | 35   |
| 16507                                              |       | " " " 16506 with 3043.....                                                                                                      | 50   |
| 3043                                               | 1208  | " " " Crank with 462c.....                                                                                                      | 15   |
| 2049                                               | 1220  | " " " " Pin.....                                                                                                                | 01   |
| 462c                                               | 1221  | " " " " " Set Screw.....                                                                                                        | 02   |

## No. 44-33 Machine Parts.

13

| No.                                                                                                                                    | Plate | Name                                                                                                                                                             | Each |
|----------------------------------------------------------------------------------------------------------------------------------------|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 307c                                                                                                                                   | 783   | Feed Rock Shaft Screw Centre.....                                                                                                                                | 06   |
| 1513c                                                                                                                                  | 783   | " " " " " Nut.....                                                                                                                                               | 05   |
| 19230                                                                                                                                  | 1228  | Guide.....                                                                                                                                                       | 15   |
| 219                                                                                                                                    | 790   | " Screw.....                                                                                                                                                     | 02   |
| 7071                                                                                                                                   | 1220  | " " Washer.....                                                                                                                                                  | 01   |
| *19465                                                                                                                                 |       | Needle Bar for right hand needle with 620.....                                                                                                                   |      |
| *19466                                                                                                                                 |       | " " " left " " " 4766.....                                                                                                                                       |      |
| 12382                                                                                                                                  | 1144  | " " Connecting Link with 794c.....                                                                                                                               | 50   |
| 794c                                                                                                                                   | 1144  | " " " " Adjusting Ser.....                                                                                                                                       | 03   |
| 19239                                                                                                                                  |       | " " " Stud.....                                                                                                                                                  | 40   |
| 19240                                                                                                                                  | 1219  | " " " " 19239 with 1904.....                                                                                                                                     | 50   |
| 1904                                                                                                                                   | 1144  | " " " " " Roller (roller only).....                                                                                                                              | 12   |
| 930E                                                                                                                                   | 1219  | Needle Bar Connecting Stud Screw.....                                                                                                                            | 01   |
| *4766                                                                                                                                  |       | " " Coupling.....                                                                                                                                                | 30   |
| 19452                                                                                                                                  | 1219  | " " " Pin.....                                                                                                                                                   | 10   |
| 4768                                                                                                                                   | 1219  | " " " " Lever.....                                                                                                                                               | 03   |
| 19453                                                                                                                                  | 1219  | " " " " " Hub with 207.....                                                                                                                                      | 20   |
| 207                                                                                                                                    | 1219  | " " " " " " Set Ser.....                                                                                                                                         | 02   |
| 19454                                                                                                                                  | 1219  | " " " " " " Shaft.....                                                                                                                                           | 05   |
| 19455                                                                                                                                  | 1219  | " " " " " " Bracket.....                                                                                                                                         | 2 00 |
| 190D                                                                                                                                   | 782   | " " " " " " Ser.....                                                                                                                                             | 03   |
| 19456                                                                                                                                  | 1219  | " " " " " " Crank.....                                                                                                                                           | 20   |
| 2273                                                                                                                                   | 1219  | " " " " " " Pin.....                                                                                                                                             | 01   |
| 19457                                                                                                                                  |       | " " " " " " 19454 with 2273 and 19456.....                                                                                                                       | 25   |
| 19246                                                                                                                                  | 1219  | Needle Bar Coupling Pin Rest.....                                                                                                                                | 05   |
| 207                                                                                                                                    | 1219  | " " " " " " Set Screw.....                                                                                                                                       | 02   |
| 12385                                                                                                                                  | 1203  | " " Crank with 855c and 858c.....                                                                                                                                | 80   |
| 858c                                                                                                                                   | 783   | " " " Set Screw.....                                                                                                                                             | 03   |
| 855c                                                                                                                                   | 783   | " " " Timing Screw.....                                                                                                                                          | 10   |
| 931D                                                                                                                                   | 1219  | " " Screw Bushing.....                                                                                                                                           | 10   |
| 4840                                                                                                                                   | 1219  | " " Spring for left hand needle.....                                                                                                                             | 02   |
| 19247                                                                                                                                  | 1219  | " " " Collar.....                                                                                                                                                | 15   |
| 224                                                                                                                                    | 1219  | " " " " Screw.....                                                                                                                                               | 02   |
| 19458                                                                                                                                  | 1205  | " " complete, 19465 and 19466, with 224, 665D, 930E, 4840, 19240, 19247, 19452, 19459 and 19460, for $\frac{3}{16}$ -in. to $\frac{3}{8}$ -in. gauge.....        | 5 60 |
| 24017                                                                                                                                  |       | Needle Bar complete, 19465 and 19466, with 224, 665D, 930E, 4840, 19240, 19247, 19452, 19460 and 24015, for $\frac{3}{16}$ -in. to $\frac{1}{2}$ -in. gauge..... | 5 00 |
| 24018                                                                                                                                  |       | Needle Bar complete, 19465 and 19466, with 224, 665D, 930E, 4840, 19240, 19247, 19452, 19460 and 24016, for $\frac{7}{16}$ -in. gauge and above.....             | 5 00 |
| NOTE:—When ordering 19458, 24017 or 24018, state the gauge required. For illustration showing position of needle holes see Plate 1218. |       |                                                                                                                                                                  |      |
| 19460                                                                                                                                  | 1219  | Needle Bar Thread Guide for 19458, 24017 and 24018.....                                                                                                          | 20   |

## No. 44-33 Machine Parts.

| No.    | Plate | Name                                                                         | Each |
|--------|-------|------------------------------------------------------------------------------|------|
| 665d   | 1219  | Needle Bar Thread Guide Screw for 19460 ..                                   | 02   |
| 19255  | 1201  | " " Trip Lever.....                                                          | 35   |
| 5596   | 768   | " " " " Bell Crank.....                                                      | 05   |
| 5599   | 768   | " " " " " " Bracket.....                                                     | 08   |
| 178c   | 782   | " " " " " " " " Screw.....                                                   | 03   |
| 5601   | 1220  | Needle Bar Trip Lever Bell Crank Hinge Pin                                   | 01   |
| 5602   | 1220  | " " " " " " Spring.....                                                      | 02   |
| 5598   | 768   | " " " " " " " " 5596 with                                                    |      |
| 12415  | 768   | Needle Bar Trip Lever Connection.....                                        | 20   |
| 12416  | 1145  | " " " " " " " " Joint.....                                                   | 08   |
| 76d    | 782   | " " " " " " " " Hinge Screw.....                                             | 05   |
| 1521e  | 1222  | Needle Bar Trip Lever Connection Lock Nut                                    | 03   |
| 9534   | 1219  | " " " " " " " " Spring.....                                                  | 06   |
| 19256  | 1219  | " " " " " " " " Collar with 187.....                                         | 17   |
| 187    | 1219  | Needle Bar Trip Lever Connection Spring                                      |      |
| 6312   | 1219  | Needle Bar Trip Lever Connection Spring                                      | 02   |
|        |       | Washer.....                                                                  | 03   |
| 892d   | 782   | Needle Bar Trip Lever Hinge Screw.....                                       | 12   |
| 19462  | 1203  | " " " " " " Pitman.....                                                      | 50   |
| 95d    | 1221  | " " " " " " " " Hinge Screw                                                  |      |
|        |       | (crank end).....                                                             | 05   |
| 90d    | 1221  | Needle Bar Trip Lever Pitman Hinge Screw                                     |      |
|        |       | (lever end).....                                                             | 05   |
| 19459  | 1219  | Needle Clamp for left hand needle with 468,                                  |      |
|        |       | 994 and 19461, for $\frac{3}{32}$ -in. to $\frac{1}{4}$ -in. gauge.....      | 1 25 |
| *24015 |       | Needle Clamp for left hand needle with 468,                                  |      |
|        |       | 620, 994 and 19461, for $\frac{5}{32}$ -in. to $\frac{1}{4}$ -in. gauge..... | 1 25 |
| 24016  |       | Needle Clamp for left hand needle with two                                   |      |
|        |       | 620, for $\frac{3}{32}$ -in. gauge and above.....                            | 1 25 |

NOTE: When ordering No. 19459 or 24016  
give gauge required.

|       |      |                                             |      |
|-------|------|---------------------------------------------|------|
| 19461 | 1219 | Needle Clamp Thread Guide for 19459         |      |
|       |      | and 24015.....                              | 01   |
| 468   | 1219 | Needle Clamp Thread Guide Set Screw for     |      |
|       |      | 19461.....                                  | 02   |
| 620   | 1219 | Needle Set Screw for right hand needle..... | 02   |
| 994   | 1219 | " " " " " left " " " ".....                 | 03   |
| 24020 | 1206 | Oil Cup.....                                | 20   |
| 24021 | 1206 | " " Extension.....                          | 05   |
| 12486 | —    | " " Packing (felt).....                     | 02   |
| 24022 | 1206 | " " complete, Nos. 12486, 24020 & 24021     | 25   |
| 213   | 1221 | " " Screw.....                              | 03   |
| 19386 | 1203 | Oscillating Rock Shaft.....                 | 1 00 |
| 19387 |      | " " " " 19386 with 4784 and                 |      |
|       |      | 12388.....                                  | 1 50 |

## No. 44-33 Machine Parts.

| No.   | Plate | Name                                                      | Each |
|-------|-------|-----------------------------------------------------------|------|
| 12388 | 1203  | Oscillating Rock Shaft Hinge Pin.....                     | 50   |
| 878d  | 783   | " " " " " " Oil Hole                                      |      |
|       |       | Stop Screw.....                                           | 06   |
| 12459 | 1220  | Oscillating Rock Shaft Hinge Pin Oil Hole                 |      |
|       |       | Stop Screw Washer (leather).....per 100...                | 50   |
| 448c  | 783   | Oscillating Rock Shaft Hinge Pin Set Screw                | 03   |
| 4784  | 1101  | " " " " Oil Pad.....                                      | 01   |
| 19127 | 1200  | " " Shaft.....                                            | 35   |
| 19496 | —     | " " Crank.....                                            | 25   |
| 19388 | 1208  | " " " " 19496 with 460c,                                  |      |
|       |       | 1518e and 19390.....                                      | 80   |
| 2049  | 1220  | Oscillating Shaft Crank Pin.....                          | 01   |
| 460d  | 783   | " " " " Set Screw.....                                    | 02   |
| 19389 | 1208  | " " " " Slide Block.....                                  | 35   |
| 229d  | 782   | " " " " " " Cap Ser                                       | 02   |
| 12424 | 1208  | " " " " " " " " Washer.....                               | 02   |
| 969c  | 1208  | Oscillating Shaft Crank Slide Block Ser. Stud             | 15   |
| 1518e | 783   | " " " " " " " " Nut.....                                  | 04   |
| 19390 | 1208  | Oscillating Shaft Crank Slide Block 19389                 |      |
|       |       | with 229d, 969c and 12424.....                            | 50   |
| 12391 | 1203  | Presser Bar (hollow).....                                 | 80   |
| 12326 | 1145  | " " " Guide Bracket with 453c.....                        | 25   |
| 453c  | 783   | " " " " " " Set Screw.....                                | 02   |
| 2062  | 1145  | " " " Lifter.....                                         | 25   |
| 689c  | 782   | " " " " Hinge Screw.....                                  | 08   |
| 1520c | 783   | " " " " " " Nut.....                                      | 03   |
| 12327 | 1145  | " " " Lifting and Releasing Lever                         |      |
|       |       | Bracket.....                                              | 50   |
| 860e  | 782   | Presser Bar Plug Screw.....                               | 03   |
| 11167 | 1203  | " " " Spring (spiral) light (.051 wire)                   | 05   |
| 12139 | 1203  | " " " " " " medium (.055 " " )                            | 05   |
| 20023 | 1203  | " " " " " " heavy (.063 " " )                             | 05   |
| 11170 | 1220  | " " " " Washer.....                                       | 01   |
| 688e  | 783   | Pressure Regulating Thumb Screw.....                      | 25   |
| 1875  | 1210  | Roller, $1\frac{1}{2}$ -in. diam., with 634d and 1548d... | 60   |
| 19199 |       | " Arm.....                                                | 20   |
| 440   | 1221  | " " Adjusting Screw.....                                  | 03   |
| 1547d | 1146  | " " " " " Nut.....                                        | 03   |
| 19200 |       | " " Bracket.....                                          | 30   |
| 316   | 1221  | " " " " Screw Centre.....                                 | 03   |
| 1547d | 1146  | " " " " " " Nut.....                                      | 03   |
| 7556  | 1210  | " " Lock Spring.....                                      | 05   |
| 176   | 1221  | " " " " " Screw.....                                      | 03   |
| 1549d | 1222  | " " " " " " Nut.....                                      | 03   |
| 19208 | 1210  | " Needle Guard (round).....                               | 45   |
| 171   | 1221  | " " " " " " Set Screw.....                                | 03   |
| 19214 | 1209  | " Presser complete ( $1\frac{1}{2}$ -in. roller) Nos.     |      |
|       |       | 171, 176, 440, 1549d, 1875, 7556, 19199, 19200,           |      |
|       |       | 19208, two 316 and three 1549d, for $\frac{3}{32}$ -in.   |      |
|       |       | to $\frac{1}{8}$ -in. gauge.....                          | 1 85 |

| No.                                                                                  | Plate | Name                                                                                                                   | Each |
|--------------------------------------------------------------------------------------|-------|------------------------------------------------------------------------------------------------------------------------|------|
| 190b                                                                                 | 782   | Roller Presser Screw.....                                                                                              | 03   |
| 634b                                                                                 | 1221  | " " Screw.....                                                                                                         | 08   |
| 1548b                                                                                | 1222  | " " Nut.....                                                                                                           | 03   |
| NOTE:—When ordering Roller Pressers or parts of Roller Pressers give gauge required. |       |                                                                                                                        |      |
| 19131                                                                                | 1216  | Shuttle (inside) Bobbin.....                                                                                           | 05   |
| 19134                                                                                | 1216  | " " " Case Latch and Position Finger.....                                                                              | 35   |
| 2521                                                                                 | 1216  | Shuttle (inside) Bobbin Case Latch and Position Finger Spring.....                                                     | 02   |
| 592E                                                                                 | 1216  | Shuttle (inside) Bobbin Case Latch and Position Finger Stop Screw.....                                                 | 02   |
| 19132                                                                                | 1216  | Shuttle (inside) Bobbin Case complete, Nos. 591, 592E, 2521, 19134 and 19149.....                                      | 75   |
| 19136                                                                                | 1216  | Shuttle (inside) Body for 19129.....                                                                                   | 75   |
| 591                                                                                  | 1216  | " " Tension Regulating Screw.....                                                                                      | 02   |
| 19149                                                                                | 1216  | " " " Spring for 19132.....                                                                                            | 10   |
| 19129                                                                                | 1216  | " " $1\frac{1}{16}$ -in. diam., No. 19136 with 19131 and 19132.....                                                    | 1 50 |
| 19131                                                                                | 1216  | Shuttle (outside) Bobbin.....                                                                                          | 05   |
| 19135                                                                                | 1216  | " " " Case Latch and Position Finger.....                                                                              | 35   |
| 2521                                                                                 | 1216  | Shuttle (outside) Bobbin Case Latch and Position Finger Spring.....                                                    | 02   |
| 592E                                                                                 | 1216  | Shuttle (outside) Bobbin Case Latch and Position Finger Stop Screw.....                                                | 02   |
| 19170                                                                                | 1216  | Shuttle (outside) Bobbin Case complete, Nos. 591, 592E, 2521, 19135 and 19172.....                                     | 75   |
| 19137                                                                                | 1216  | Shuttle (outside) Body for 19130.....                                                                                  | 75   |
| 19171                                                                                | 1217  | " " " " 19169.....                                                                                                     | 75   |
| 591                                                                                  | 1216  | " " Tension Regulating Screw.....                                                                                      | 02   |
| 19172                                                                                | 1216  | " " " Spring for 19170.....                                                                                            | 10   |
| 19169                                                                                | 1217  | " " $1\frac{1}{16}$ -in. diam., No. 19171 with 19131 and 19170, for gauges up to $\frac{13}{16}$ -in.....              | 1 50 |
| 19130                                                                                | 1216  | Shuttle (outside) $1\frac{1}{16}$ -in. diam., No. 19137 with 19131 & 19170, for $\frac{7}{32}$ -in. gauge & above..... | 1 50 |
| *19138                                                                               |       | Shuttle Driver.....                                                                                                    | 2 50 |
| 19139                                                                                | 1208  | " " 19138 with two 453c.....                                                                                           | 2 50 |
| NOTE: When ordering No. 19139 give gauge required.                                   |       |                                                                                                                        |      |
| 2049                                                                                 | 1220  | Shuttle Driver Pin.....                                                                                                | 01   |
| 453c                                                                                 | 783   | " " Set Screw.....                                                                                                     | 02   |
| 19277                                                                                | ----- | " Race Body.....                                                                                                       | 1 75 |
| 19278                                                                                | 1212  | " " Loop Separator.....                                                                                                | 1 50 |
| 934b                                                                                 | 1221  | " " " Screw.....                                                                                                       | 02   |
| 19279                                                                                | 1212  | " " Ring (inside).....                                                                                                 | 1 50 |
| 19280                                                                                | 1212  | " " " (outside).....                                                                                                   | 1 50 |

| No.                                                                              | Plate | Name                                                                                                                                | Each |
|----------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------------------------------------------------------------------|------|
| 2532                                                                             | 1220  | Shuttle Race Ring Position Pin...per 100..                                                                                          | 10   |
| 2533                                                                             | 1215  | " " " Spring.....                                                                                                                   | 15   |
| 907b                                                                             | 1221  | " " " " Screw.....                                                                                                                  | 05   |
| 19282                                                                            | 1212  | " " complete, Nos. 19277 to 19280, two each 907b, 934b, 2533 and four 2532.....                                                     | 6 00 |
| NOTE:—When ordering Shuttle Races or parts of Shuttle Races give gauge required. |       |                                                                                                                                     |      |
| 145                                                                              | 782   | Shuttle Race Screw.....                                                                                                             | 04   |
| 19145                                                                            | 1204  | " " Slide (inside).....                                                                                                             | 30   |
| 19146                                                                            | 1204  | " " " (outside) for $\frac{7}{16}$ -in. gauge and below.....                                                                        | 25   |
| 19147                                                                            | 1220  | Shuttle Race Slide Friction Spring.....                                                                                             | 03   |
| 651E                                                                             | 1221  | " " " " " Screw.....                                                                                                                | 01   |
| 19148                                                                            | 1204  | " " " Guide with 651E & 19147.....                                                                                                  | 50   |
| 19185                                                                            | 1204  | " " " " (front) with 651E and 19147, for 19230 and 26268.....                                                                       | 50   |
| 691                                                                              | 782   | Shuttle Race Slide Guide Screw.....                                                                                                 | 04   |
| 2921                                                                             | 1146  | Tension Disc.....                                                                                                                   | 05   |
| 19191                                                                            | 1146  | " Plate for upper tension with 19231.....                                                                                           | 50   |
| 134b                                                                             | 1221  | " " Screw.....                                                                                                                      | 06   |
| 1560c                                                                            | 1146  | " Regulating Thumb Nut.....                                                                                                         | 04   |
| 19192                                                                            | 1146  | " Releaser.....                                                                                                                     | 15   |
| 12397                                                                            | 1145  | " Releasing Lever.....                                                                                                              | 20   |
| 12398                                                                            | 1145  | " " " Hinge Pin.....                                                                                                                | 01   |
| 12329                                                                            | 1145  | " " " Spring.....                                                                                                                   | 02   |
| 19193                                                                            | 1146  | " " " (intermediate).....                                                                                                           | 10   |
| 19231                                                                            | 1146  | " " " " ".....                                                                                                                      | —    |
| 2269                                                                             | 1146  | Tension Releasing Lever (intermediate) Hinge Pin.....                                                                               | 01   |
| 19194                                                                            | 1146  | Tension Releasing Lever (intermediate) Spring.....                                                                                  | 03   |
| 916                                                                              | 1146  | Tension Screw Stud.....                                                                                                             | 08   |
| 1547b                                                                            | 1146  | " " " Nut.....                                                                                                                      | 03   |
| 2923                                                                             | 1146  | " Spring.....                                                                                                                       | 03   |
| 12149                                                                            | 1218  | " Thread Guard.....                                                                                                                 | 05   |
| 19195                                                                            | 1146  | " (upper) complete with Tension Release, Nos. 2269, 19191, 19193, 19194, two each 916, 1547b, 1560c, 2923, 19192 and four 2921..... | 1 50 |
| 19154                                                                            | 1220  | Thread Guard (lower) for 19234.....                                                                                                 | 25   |
| 12152                                                                            | 1220  | " " Rivet.....per 100..                                                                                                             | 10   |
| 19159                                                                            | 1218  | " Guide Body.....                                                                                                                   | 30   |
| 19161                                                                            | 1218  | " " Cap.....                                                                                                                        | 10   |
| 19160                                                                            | 1218  | " " Roller.....                                                                                                                     | 10   |
| 905b                                                                             | 1218  | " " Screw.....                                                                                                                      | 04   |
| 19162                                                                            | ----- | " " complete (roller) Nos. 905b and 19159 to 19161.....                                                                             | 50   |

| No.                                                    | Plate | Name                                                 | Each |
|--------------------------------------------------------|-------|------------------------------------------------------|------|
| 9543                                                   | 1219  | Thread Retainer Disc.....                            | 02   |
| 9544                                                   | 1219  | " " " " Cover.....                                   | 12   |
| 185                                                    | 1219  | " " " " " Screw.....                                 | 02   |
| 9545                                                   | 1219  | " " " " " Spring.....                                | 05   |
| 19337                                                  | 1219  | " " " " " Thread Guard for 19234.....                | 05   |
| 12404                                                  | 1144  | " " " " " Take-up Crank.....                         | 80   |
| 3094                                                   | 1144  | " " " " " Wedge.....                                 | 10   |
| 690E                                                   | 1144  | " " " " " " Screw.....                               | 05   |
| 19156                                                  | 1144  | " " " " " Lever.....                                 | 30   |
| 775E                                                   | 1144  | " " " " " Cap Screw.....                             | 06   |
| 12166                                                  | 1144  | " " " " " Hinge Pin.....                             | 05   |
| 12409                                                  | 1144  | " " " " " Link.....                                  | 25   |
| 11204                                                  | 1144  | " " " " " " Hinge Pin.....                           | 15   |
| 430G                                                   | 1144  | " " " " " " " " Set Screw.....                       | 04   |
| 19157                                                  | 1144  | Thread Take-up Lever 19156 with 12166 and 12409..... | 65   |
| 19158                                                  | 1218  | Thread Take-up Spring (music wire).....              | 03   |
| 7336                                                   | 1218  | " " " " " Regulator.....                             | 25   |
| 448G                                                   | 783   | " " " " " " Set Ser.....                             | 03   |
| 19184                                                  | 787   | Throat Plate for 19183.....                          | 1 50 |
| 20071                                                  | 796   | " " " " " 20070.....                                 | 1 50 |
| 691                                                    | 782   | " " " " " Screw.....                                 | 04   |
| NOTE:—When ordering Throat Plates give gauge required. |       |                                                      |      |
| 24079                                                  |       | Drip Pan with four 1-in. wire nails.....             | 25   |

## PARTS COMPLETE FOR No. 44-34 MACHINE.

DROP FEED. TWO NEEDLES. TWO SHUTTLES, THROAT PLATE  
FLUSH WITH BED PLATE, FOR SHOE WORK.

| No.    | Plate | Name                                                        | Each |
|--------|-------|-------------------------------------------------------------|------|
| *19107 | —     | Arm.....                                                    | 4 25 |
| 8582   | 1220  | " Dowel Pin.....                                            | 02   |
| 12453  | 1220  | " Oil Tube for intermediate bearing.....                    | 06   |
| 12454  | 1220  | " " " " " Coiling 12409.....                                | 06   |
| 11119  | 1220  | " " " " " " 19156.....                                      | 10   |
| 748E   | 782   | " Screw (back).....                                         | 08   |
| 868E   | 1221  | " " (front).....                                            | 10   |
| 16511  | 1200  | " Shaft.....                                                | 1 90 |
| *11104 | —     | " " Bushing (front).....                                    | 30   |
| 12357  | 1203  | " " Flanged Bushing (back).....                             | 25   |
| 448G   | 783   | " " " " " " Set Screw.....                                  | 03   |
| 144D   | 782   | " " Screw.....                                              | 12   |
| 12480  | 1205  | " Side Cap.....                                             | 05   |
| 219    | 790   | " " " Screw.....                                            | 02   |
| 12193  | 1202  | " " Cover.....                                              | 10   |
| 286D   | 783   | " " " Thumb Screw.....                                      | 08   |
| 2415   | 1200  | " Spool Bracket.....                                        | 25   |
| 159    | 1221  | " " " " " Screw.....                                        | 03   |
| 12403  | 1220  | " " " Spool Pin and Thread Eyelet.....                      | 05   |
| 11211  | 1203  | Arm Spool Bracket Washer (cloth) per 100.....               | 25   |
| 15063  | 1200  | " " " " 2415 with two 12403.....                            | 35   |
| 12358  | —     | Balance Wheel, light rim, 2½-in. pulley, with two 448G..... | 75   |
| 12359  | 1200  | Balance Wheel, light rim, 3-in. pulley, with two 448G.....  | 75   |
| 448G   | 783   | Balance Wheel Set Screw.....                                | 03   |
| *19303 | —     | Bed.....                                                    | 4 50 |
| 12496  | 1201  | Crank Connecting Rod.....                                   | 1 35 |
| *14013 | —     | " " " Cap.....                                              | —    |
| 896E   | 1221  | " " " " " Screw.....                                        | 04   |
| 908G   | 1221  | " " " " " Hinge.....                                        | 12   |
| 1619E  | 1222  | " " " " " " Nut.....                                        | 05   |
| 19304  | —     | Face Plate.....                                             | 50   |
| 19305  | 1202  | " " 19304 with 19155, 19327 and two 12152.....              | 1 00 |
| 190D   | 782   | Face Plate Screw.....                                       | 03   |
| 286D   | 783   | " " Thumb Screw.....                                        | 08   |
| 19111  | 1208  | Feed Bar.....                                               | 75   |
| 313G   | 783   | " " " " " " Screw Centre.....                               | 04   |
| 1519E  | 783   | " " " " " " Nut.....                                        | 03   |
| 12197  | 1203  | " Cam and Feed Lifting Eccentric with 446G.....             | 50   |

| No.                                                | Plate | Name                                                                                             | Each |
|----------------------------------------------------|-------|--------------------------------------------------------------------------------------------------|------|
| 446c                                               | 783   | Feed Cam and Feed Lifting Eccentric Set Screw.....                                               | 03   |
| 3033                                               | 1145  | Feed Connecting Link.....                                                                        | 20   |
| 375c                                               | 782   | " " " Hinge Screw.....                                                                           | 12   |
| 1518E                                              | 783   | " " " " " Nut.....                                                                               | 04   |
| 19306                                              | 790   | " Dog with 19118, for $\frac{1}{32}$ -in. to $\frac{3}{16}$ -in. gauge, for vamping.....         | 1 25 |
| 19470                                              | 793   | Feed Dog with 19118, for $\frac{1}{32}$ -in. to $\frac{3}{16}$ -in. gauge, for shoe staying..... | 1 50 |
| NOTE:—When ordering Feed Dogs give gauge required. |       |                                                                                                  |      |
| 191c                                               | 1221  | Feed Dog Screw.....                                                                              | 03   |
| 19116                                              | 1220  | " " Spring.....                                                                                  | 02   |
| 19117                                              | 1220  | " " " Hook for 19120.....                                                                        | 01   |
| 19118                                              | 1220  | " " " " " Feed Dogs.....                                                                         | 01   |
| 12123                                              | 1201  | " Forked Connection.....                                                                         | 60   |
| 375c                                               | 782   | " " " Hinge Screw.....                                                                           | 12   |
| 1518E                                              | 783   | " " " " " Nut.....                                                                               | 04   |
| 16504                                              | 766   | " Lifting Rock Shaft.....                                                                        | 45   |
| 19236                                              | —     | " " " " 16504 with 16556 and 19120.....                                                          | 1 65 |
| 19120                                              | 1208  | Feed Lifting Rock Shaft Crank (front) with 157E, 19117, 19121 and 19122.....                     | 1 00 |
| 157E                                               | 782   | Feed Lifting Rock Shaft Crank (front) Clamping Screw.....                                        | 04   |
| 19121                                              | 1208  | Feed Lifting Rock Shaft Crank (front) Roller.....                                                | 12   |
| 19122                                              | 1208  | Feed Lifting Rock Shaft Crank (front) Roller Pin.....                                            | 03   |
| 16556                                              | 1208  | Feed Lifting Rock Shaft Crank (back) with 462c.....                                              | 20   |
| 2049                                               | 1220  | Feed Lifting Rock Shaft Crank (back) Pin.....                                                    | 01   |
| 462c                                               | 1221  | " " " " " Set Screw.....                                                                         | 02   |
| 12430                                              | 1201  | Feed Lifting Rock Shaft Crank Connecting Rod.....                                                | 80   |
| *12204                                             | —     | Feed Lifting Rock Shaft Crank Connecting Rod Cap.....                                            | —    |
| 445E                                               | 782   | Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw.....                                      | 04   |
| 375c                                               | 782   | Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw.....                                    | 12   |
| 1518E                                              | 783   | Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut.....                                | 04   |
| 307c                                               | 783   | Feed Lifting Rock Shaft Screw Centre.....                                                        | 06   |
| 1513c                                              | 783   | " " " " " Nut.....                                                                               | 05   |
| 3039                                               | 768   | Feed Regulator.....                                                                              | 25   |
| 58E                                                | 782   | " " Hinge Screw.....                                                                             | 15   |
| 818D                                               | 783   | " " Thumb ".....                                                                                 | 12   |
| 16506                                              | 766   | " Rock Shaft.....                                                                                | 35   |

| No.                                                         | Plate | Name                                                                                | Each |
|-------------------------------------------------------------|-------|-------------------------------------------------------------------------------------|------|
| 16507                                                       | —     | Feed Rock Shaft 16506 with 3043.....                                                | 50   |
| 3043                                                        | 1208  | " " " Crank with 462c.....                                                          | 15   |
| 2049                                                        | 1220  | " " " " Pin.....                                                                    | 01   |
| 462c                                                        | 1221  | " " " " Set Screw.....                                                              | 02   |
| 307c                                                        | 783   | " " " Screw Centre.....                                                             | 06   |
| 1513c                                                       | 783   | " " " " Nut.....                                                                    | 05   |
| 18014                                                       | 1203  | Needle Bar (hollow).....                                                            | 60   |
| 12382                                                       | 1144  | " " Connecting Link with 794c.....                                                  | 50   |
| 794c                                                        | 1144  | " " " Adjusting Ser.....                                                            | 03   |
| 12383                                                       | —     | " " " Stud.....                                                                     | 40   |
| 1904                                                        | 1144  | " " " Roller (roller only).....                                                     | 12   |
| 453c                                                        | 783   | Needle Bar Connecting Stud Set Screw.....                                           | 02   |
| 12384                                                       | 1144  | " " " " 12383 with 453c and 1904.....                                               | 50   |
| 12385                                                       | 1203  | Needle Bar Crank with 855c and 858c.....                                            | 80   |
| 858c                                                        | 783   | " " " Set Screw.....                                                                | 03   |
| 855c                                                        | 783   | " " " Timing Screw.....                                                             | 10   |
| 696E                                                        | 782   | " " Plug Screw.....                                                                 | 03   |
| 12495                                                       | 1220  | " " " Rivet.....per 100..                                                           | 05   |
| 936D                                                        | 1221  | " " Screw Bushing.....                                                              | 06   |
| 19124                                                       | 1218  | " Clamp with two 460, for $\frac{1}{32}$ -in. to $\frac{3}{32}$ -in. gauge.....     | 1 25 |
| 19308                                                       | 1218  | Needle Clamp with 209 and 460, for $\frac{7}{16}$ -in. gauge and above.....         | 1 25 |
| NOTE:—When ordering No. 19124 or 19308 give gauge required. |       |                                                                                     |      |
| 2273                                                        | 1219  | Needle Clamp Pin.....                                                               | 01   |
| 460                                                         | 783   | " Set Screw for 19124 and 19308.....                                                | 02   |
| 209                                                         | 1221  | " " " (right) for 19308.....                                                        | 02   |
| 24020                                                       | 1206  | Oil Cup.....                                                                        | 20   |
| 24021                                                       | 1206  | " " Extension.....                                                                  | 05   |
| 12486                                                       | —     | " " Packing (felt).....                                                             | 02   |
| 24022                                                       | 1206  | " " complete, Nos. 12486, 24020 & 24021.....                                        | 25   |
| 213                                                         | 1221  | " " Screw.....                                                                      | 03   |
| 19386                                                       | 1203  | Oscillating Rock Shaft.....                                                         | 1 00 |
| 19387                                                       | —     | " " " 19386 with 4784 and 12388.....                                                | 1 50 |
| 12388                                                       | 1203  | Oscillating Rock Shaft Hinge Pin.....                                               | 50   |
| 858D                                                        | 783   | " " " " Oil Hole Stop Screw.....                                                    | 06   |
| 12459                                                       | 1220  | Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....per 100.. | 50   |
| 448c                                                        | 783   | Oscillating Rock Shaft Hinge Pin Set Ser.....                                       | 03   |
| 4784                                                        | 1101  | " " " Oil Pad.....                                                                  | 01   |
| 19127                                                       | 1200  | " Shaft.....                                                                        | 35   |
| 19496                                                       | —     | " " Crank.....                                                                      | 25   |
| 19388                                                       | 1208  | " " " 19496 with 460c, 1518E and 19390.....                                         | 80   |
| 2049                                                        | 1220  | Oscillating Shaft Crank Pin.....                                                    | 01   |
| 460c                                                        | 783   | " " " Set Screw.....                                                                | 02   |

## No. 44-34 Machine Parts.

| No.   | Plate | Name                                          | Each |
|-------|-------|-----------------------------------------------|------|
| 19389 | 1208  | Oscillating Shaft Crank Slide Block.....      | 35   |
| 229D  | 782   | " " " " " Cap Ser                             | 02   |
| 12424 | 1208  | " " " " " " "                                 |      |
|       |       | Washer.....                                   | 02   |
| 969C  | 1208  | Oscillating Shaft Crank Slide Block Screw     |      |
|       |       | Stud.....                                     | 15   |
| 1518E | 783   | Oscillating Shaft Crank Slide Block Screw     |      |
|       |       | Stud Nut.....                                 | 04   |
| 19390 | 1208  | Oscillating Shaft Crank Slide Block 19389     |      |
|       |       | with 229D, 969C and 12424.....                | 50   |
| 12391 | 1203  | Presser Bar (hollow).....                     | 80   |
| 12326 | 1145  | " " Guide Bracket with 453C.....              | 25   |
| 453C  | 783   | " " " " " Set Screw.....                      | 02   |
| 2062  | 1145  | " " Lifter.....                               | 25   |
| 689C  | 782   | " " " " " Hinge Screw.....                    | 08   |
| 1520C | 783   | " " " " " Nut.....                            | 03   |
| 13327 | 1145  | " " Lifting and Releasing Lever               |      |
|       |       | Bracket.....                                  | 50   |
| 860E  | 782   | Presser Bar Plug Screw.....                   | 03   |
| 11167 | 1203  | " " Spring (spiral) light (.051 wire)         |      |
| 12139 | 1203  | " " " " " medium (.055                        |      |
|       |       | wire).....                                    | 05   |
| 20023 | 1203  | Presser Bar Spring (spiral) heavy (.063 wire) |      |
| 11170 | 1220  | " " " " " Washer.....                         | 01   |
| 19333 | 1223  | " " Foot for inside stays.....                | 1 50 |
| 19186 | 1223  | " " (long toe) for inside stays.....          | 1 50 |
| 20051 | 1223  | " " with keel, slotted for tape, for          |      |
|       |       | staying.....                                  | 1 75 |
| 19476 | 1227  | Presser Foot for 19478.....                   | 2 50 |
| 19477 | 1227  | " " Bracket with 165C.....                    | 1 60 |
| 465C  | 1227  | " " " " " Set Screw.....                      | 01   |
| 4460  | 1227  | " " Guide with 735C.....                      | 75   |
| 735C  | 1227  | " " " " " Set Screw.....                      | 02   |
| 4461  | 1227  | " " Spring.....                               | 02   |
| 4462  | 1227  | " " " " " Screw Bushing.....                  | 15   |
| 1607D | 1227  | " " Stop Nut.....                             | 03   |
| 19478 | 1227  | " " complete (spring presser) Nos.            |      |
|       |       | 1607D, 4460 to 4462, 19476 and 19477.....     | 5 00 |

NOTE:—When ordering Presser Feet or parts  
of Presser Feet give gauge required.

|       |      |                                                             |    |
|-------|------|-------------------------------------------------------------|----|
| 190D  | 782  | Presser Foot Screw.....                                     | 03 |
| 688E  | 783  | Pressure Regulating Thumb Screw.....                        | 25 |
| 1839  | 1210 | Roller, $1\frac{1}{2}$ -in. diam., with 386C and 1548D, for |    |
|       |      | 19211 and 19212.....                                        | 40 |
| 1875  | 1210 | Roller, $1\frac{1}{2}$ -in. diam., with 634D and 1548D, for |    |
|       |      | 19213 and 19214.....                                        | 60 |
| 19196 | -    | Roller Arm for 19211.....                                   | 20 |
| 19197 | -    | " " " " " 19212.....                                        | 20 |
| 19198 | -    | " " " " " 19213.....                                        | 20 |
| 19199 | -    | " " " " " 19214.....                                        | 20 |

## No. 44-34 Machine Parts.

| No.   | Plate | Name                                                                   | Each |
|-------|-------|------------------------------------------------------------------------|------|
| 440   | 1221  | Roller Arm Adjusting Screw.....                                        | 03   |
| 1547D | 1146  | " " " " " Nut.....                                                     | 03   |
| 19200 | -     | " " Bracket for 19212 and 19214.....                                   | 30   |
| 17567 | -     | " " " " " 19211.....                                                   | 30   |
| 4777  | -     | " " " " " 19213.....                                                   | 35   |
| 316   | 1221  | " " " " " Screw Centre.....                                            | 03   |
| 1547D | 1146  | " " " " " " Nut.....                                                   | 03   |
| 7556  | 1210  | " " Lock Spring.....                                                   | 05   |
| 176   | 1221  | " " " " " Screw.....                                                   | 03   |
| 1549D | 1222  | " " " " " " Nut.....                                                   | 03   |
| 19201 | 1210  | " Needle Guard (flat) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in.       |      |
|       |       | gauge, for 19211.....                                                  | 40   |
| 19204 | 1210  | Roller Needle Guard (flat) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in.  |      |
|       |       | gauge, for 19213.....                                                  | 40   |
| 207   | 1219  | Roller Needle Guard (flat) Screw.....                                  | 02   |
| 19207 | 1210  | " " " (round) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in.               |      |
|       |       | gauge, for 19211.....                                                  | 45   |
| 19208 | 1210  | Roller Needle Guard (round) $\frac{3}{32}$ -in. to $\frac{1}{8}$ -in.  |      |
|       |       | gauge, for 19212 and 19214.....                                        | 45   |
| 19209 | 1210  | Roller Needle Guard (round) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. |      |
|       |       | gauge, for 19213.....                                                  | 45   |
| 171   | 1221  | Roller Needle Guard (round) Set Screw....                              | 03   |
| 19211 | 1209  | " Presser complete, $1\frac{1}{2}$ -in. roller, Nos.                   |      |
|       |       | 171, 176, 207, 440, 1549D, 1839, 7556, 17567,                          |      |
|       |       | 19196, 19201, 19207, two 316 and three                                 |      |
|       |       | 1547D, for $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge.....       | 2 05 |
| 19212 | 1209  | Roller Presser complete, $1\frac{1}{2}$ -in. roller, Nos.              |      |
|       |       | 171, 176, 440, 1549D, 1839, 7556, 19197,                               |      |
|       |       | 19200, 19208, two 316 and three 1547D, for                             |      |
|       |       | $\frac{3}{32}$ -in. to $\frac{1}{8}$ -in. gauge.....                   | 1 65 |
| 19213 | 1209  | Roller Presser complete, $1\frac{1}{2}$ -in. roller, Nos.              |      |
|       |       | 171, 176, 207, 440, 1549D, 1875, 4777, 7556,                           |      |
|       |       | 19198, 19204, 19209, two 316 and three                                 |      |
|       |       | 1547D, for $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge.....       | 2 25 |
| 19214 | 1209  | Roller Presser complete, $1\frac{1}{2}$ -in. roller, Nos.              |      |
|       |       | 171, 176, 440, 1549D, 1875, 7556, 19199,                               |      |
|       |       | 19200, 19208, two 316 and three 1547D, for                             |      |
|       |       | $\frac{3}{32}$ -in. to $\frac{1}{8}$ -in. gauge.....                   | 1 85 |
| 190D  | 782   | Roller Presser Screw.....                                              | 03   |
| 386D  | 1101  | " " " " " Screw for 1839.....                                          | 08   |
| 634D  | 1221  | " " " " " 1875.....                                                    | 08   |
| 1548D | 1222  | " " " " " Nut.....                                                     | 03   |

NOTE:—When ordering Roller Pressers or Parts  
of Roller Pressers give gauge required.

|       |      |                                              |    |
|-------|------|----------------------------------------------|----|
| 19131 | 1216 | Shuttle (inside) Bobbin.....                 | 05 |
| 19310 | 1217 | " " " " " Case Latch and Posi-               |    |
|       |      | tion Finger.....                             | 35 |
| 2521  | 1216 | Shuttle (inside) Bobbin Case Latch and Posi- |    |
|       |      | tion Finger Spring.....                      | 02 |
| 592E  | 1216 | Shuttle (inside) Bobbin Case Latch and Posi- |    |
|       |      | tion Finger Stop Screw.....                  | 02 |

## No. 44-34 Machine Parts.

| No.    | Plate | Name                                                                                                    | Each |
|--------|-------|---------------------------------------------------------------------------------------------------------|------|
| 19312  | 1217  | Shuttle (inside) Bobbin Case complete, Nos. 591, 592E, 2521, 19149 and 19310.....                       | 75   |
| 19136  | 1216  | Shuttle (inside) Body.....                                                                              | 75   |
| 591    | 1216  | " " Tension Regulating Screw.....                                                                       | 02   |
| 19149  | 1216  | " " " Spring.....                                                                                       | 10   |
| 19324  | 1217  | " " 1 1/4-in. diam., No. 19136 with 19131 and 19312.....                                                | 1 50 |
| 19131  | 1216  | Shuttle (outside) Bobbin.....                                                                           | 05   |
| 19311  | 1217  | " " " Case Latch and Position Finger.....                                                               | 35   |
| 2521   | 1216  | Shuttle (outside) Bobbin Case Latch and Position Finger Spring.....                                     | 02   |
| 592E   | 1216  | Shuttle (outside) Bobbin Case Latch and Position Finger Stop Screw.....                                 | 02   |
| 19313  | 1217  | Shuttle (outside) Bobbin Case complete, Nos. 591, 592E, 2521, 19172 and 19311, for 19325 and 19326..... | 75   |
| 19137  | 1216  | Shuttle (outside) Body for 19325.....                                                                   | 75   |
| 19171  | 1217  | " " " " 19326.....                                                                                      | 75   |
| 591    | 1216  | " " Tension Regulating Screw.....                                                                       | 02   |
| 19172  | 1216  | " " " Spring.....                                                                                       | 10   |
| 19326  | 1217  | " " 1 1/4-in. diam., No. 19171 with 19131 and 19313, for 1/2-in. to 3/4-in. gauge.....                  | 1 50 |
| 19325  | 1217  | Shuttle (outside) 1 1/4-in. diam., No. 19137 with 19131 and 19313, for 3/2-in. gauge and above.....     | 1 50 |
| *19138 | —     | Shuttle Driver.....                                                                                     | 2 50 |
| 19139  | 1208  | " " 19138 with two 453c.....                                                                            | 2 50 |

NOTE: When ordering No. 19139 give gauge required.

|       |      |                                                                                                                                     |      |
|-------|------|-------------------------------------------------------------------------------------------------------------------------------------|------|
| 2049  | 1220 | Shuttle Driver Pin.....                                                                                                             | 01   |
| 453c  | 783  | " " Set Screw.....                                                                                                                  | 02   |
| 19315 | —    | " Race Body for 24013.....                                                                                                          | 1 75 |
| 19379 | —    | " " " " 19382 and 24014.....                                                                                                        | 1 75 |
| 19309 | 1213 | " " Needle Guard for 24013.....                                                                                                     | 25   |
| 337D  | 1221 | " " " " Screw.....                                                                                                                  | 02   |
| 19317 | 1213 | " " Ring (inside) for 19309 & 24013.....                                                                                            | 1 50 |
| 19380 | 1214 | " " " " " 19382 " 24014.....                                                                                                        | 1 50 |
| 19318 | 1213 | " " " (outside) " 24013 " ".....                                                                                                    | 1 50 |
| 19381 | 1214 | " " " " " 19382.....                                                                                                                | 1 50 |
| 2532  | 1220 | " " " Position Pin.....per 100....                                                                                                  | 10   |
| 2533  | 1215 | " " " Spring.....                                                                                                                   | 15   |
| 907D  | 1221 | " " " " Screw.....                                                                                                                  | 05   |
| 19382 | 1214 | " " complete, Nos. 19379 to 19381, two each 907D, 2533 and four 2532, for 1/2-in. to 3/4-in. gauge.....                             | 5 00 |
| 24014 | 1215 | Shuttle Race complete, Nos. 19318, 19379, 19380, two each 907D, 2533 and four 2532, for 3/2-in. to 1 1/4-in. gauge, for vamping.... | 5 00 |

## No. 44-34 Machine Parts.

| No.                                                                              | Plate | Name                                                                                                                                 | Each |
|----------------------------------------------------------------------------------|-------|--------------------------------------------------------------------------------------------------------------------------------------|------|
| 24013                                                                            | 1215  | Shuttle Race complete, Nos. 19309, 19315, 19317, 19318, two each 337D, 907D, 2533 and four 2532, for 1 1/4-in. gauge and above. 5 00 |      |
| NOTE: When ordering Shuttle Races or parts of Shuttle Races give gauge required. |       |                                                                                                                                      |      |
| 145                                                                              | 782   | Shuttle Race Screw.....                                                                                                              | 04   |
| 19319                                                                            | 1204  | " " Slide (inside).....                                                                                                              | 35   |
| 19320                                                                            | 1220  | " " " " Stop Stud.....                                                                                                               | 05   |
| 19321                                                                            | 1220  | " " " " " Spring.....                                                                                                                | 02   |
| 19322                                                                            | 1204  | " " " (outside) with 662E and 19147, for 1/4-in. gauge and below.....                                                                | 30   |
| 19491                                                                            | 1202  | Shuttle Race Slide (outside) with 662E and 19147, for 1 1/2-in. to 1 3/4-in. gauge.....                                              | 30   |
| 19492                                                                            | 1202  | Shuttle Race Slide (outside) with 662E and 19147, for 3/4-in. to 1 1/4-in. gauge.....                                                | 30   |
| 19147                                                                            | 1220  | Shuttle Race Slide (outside) Friction Spring.....                                                                                    | 03   |
| 662E                                                                             | 782   | " " " " " " Screw.....                                                                                                               | 01   |
| 2921                                                                             | 1146  | Tension Disc.....                                                                                                                    | 05   |
| 19191                                                                            | 1146  | " Plate for upper tension with 19231.....                                                                                            | 50   |
| 131D                                                                             | 1221  | " " Screw.....                                                                                                                       | 06   |
| 1560c                                                                            | 1146  | " Regulating Thumb Nut.....                                                                                                          | 04   |
| 19192                                                                            | 1146  | " Releaser.....                                                                                                                      | 15   |
| 12397                                                                            | 1145  | " Releasing Lever.....                                                                                                               | 20   |
| 12398                                                                            | 1145  | " " " Hinge Pin.....                                                                                                                 | 01   |
| 12329                                                                            | 1145  | " " " Spring.....                                                                                                                    | 02   |
| 19193                                                                            | 1146  | " " " (intermediate).....                                                                                                            | 10   |
| 19231                                                                            | 1146  | " " " " Hinge Block.....                                                                                                             | —    |
| 2269                                                                             | 1146  | Tension Releasing Lever (intermediate) Hinge Pin.....                                                                                | 01   |
| 19194                                                                            | 1146  | Tension Releasing Lever (intermediate) Spring.....                                                                                   | 03   |
| 916                                                                              | 1146  | Tension Screw Stud.....                                                                                                              | 08   |
| 1547D                                                                            | 1146  | " " " Nut.....                                                                                                                       | 03   |
| 2923                                                                             | 1146  | " Spring.....                                                                                                                        | 03   |
| 12149                                                                            | 1218  | " Thread Guard.....                                                                                                                  | 05   |
| 19195                                                                            | 1146  | " (upper) complete with Tension Release, Nos. 2269, 19191, 19193, 19194, two each 916, 1547D, 1560c, 2923, 19192 and four 2921.....  | 1 50 |
| 19327                                                                            | 1220  | Thread Guard (lower) for 19305.....                                                                                                  | 25   |
| 12152                                                                            | 1220  | " " " Rivet.....per 100....                                                                                                          | 10   |
| 19155                                                                            | 1220  | " " (upper) for 19305.....                                                                                                           | 20   |
| 12152                                                                            | 1220  | " " " Rivet.....per 100....                                                                                                          | 10   |
| 19159                                                                            | 1218  | " Guide Body.....                                                                                                                    | 30   |
| 19161                                                                            | 1218  | " Cap.....                                                                                                                           | 10   |
| 19160                                                                            | 1218  | " Roller.....                                                                                                                        | 10   |
| 905D                                                                             | 1218  | " " Screw.....                                                                                                                       | 04   |
| 19162                                                                            | —     | " " complete (roller) Nos. 905D and 19159 to 19161.....                                                                              | 50   |

NOTE: When ordering Throat Plates or Parts  
of Throat Plates give gauge required.

| PARTS COMPLETE FOR                                                                         |       |                                                                         |      |
|--------------------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------|------|
| <b>No. 44-35 MACHINE.</b>                                                                  |       |                                                                         |      |
| <b>DROP FEED, TWO NEEDLES, TWO SHUTTLES, HIGH RAISE FEED,<br/>FOR HEAVY WORK IN CLOTH.</b> |       |                                                                         |      |
| No.                                                                                        | Plate | Name                                                                    | Each |
| *19107                                                                                     |       | Arm.....                                                                | 4 25 |
| 8582                                                                                       | 1220  | " Dowel Pin.....                                                        | 02   |
| 12453                                                                                      | 1220  | " Oil Tube for intermediate bearing.....                                | 06   |
| 12454                                                                                      | 1220  | " " " " oiling 12409.....                                               | 06   |
| 11119                                                                                      | 1220  | " " " " " 19156.....                                                    | 10   |
| 748E                                                                                       | 782   | " Screw (back).....                                                     | 08   |
| 868E                                                                                       | 1221  | " " (front).....                                                        | 10   |
| 16511                                                                                      | 1200  | " Shaft.....                                                            | 1 90 |
| *11104                                                                                     |       | " " Bushing (front).....                                                | 30   |
| 12357                                                                                      | 1203  | " " Flanged Bushing (back).....                                         | 25   |
| 448c                                                                                       | 783   | " " " " " Set Screw                                                     | 03   |
| 141D                                                                                       | 782   | " " Screw.....                                                          | 12   |
| 12480                                                                                      | 1205  | " Side Cap.....                                                         | 05   |
| 219                                                                                        | 790   | " " " Screw.....                                                        | 02   |
| 12193                                                                                      | 1202  | " " Cover.....                                                          | 10   |
| 286D                                                                                       | 783   | " " " Thumb Screw.....                                                  | 08   |
| 2415                                                                                       | 1200  | " Spool Bracket.....                                                    | 25   |
| 159                                                                                        | 1221  | " " " Screw.....                                                        | 03   |
| 12403                                                                                      | 1220  | " " " Spool Pin & Thread Eyelet                                         | 05   |
| 11241                                                                                      | 1203  | " " " Washer (cloth), per 100.                                          | 25   |
| 15063                                                                                      | 1200  | " " " 2415 with two 12403.....                                          | 35   |
| 12358                                                                                      | —     | Balance Wheel, light rim, 2½-in. pulley,<br>with two 448c.....          | 75   |
| 12359                                                                                      | 1200  | Balance Wheel, light rim, 3-in. pulley,<br>with two 448c.....           | 75   |
| 448c                                                                                       | 783   | Balance Wheel Set Screw.....                                            | 03   |
| *19108                                                                                     |       | Bed.....                                                                | 4 50 |
| 12496                                                                                      | 1201  | Crank Connecting Rod.....                                               | 1 35 |
| *14013                                                                                     |       | " " " Cap.....                                                          |      |
| 896E                                                                                       | 1221  | " " " " Screw.....                                                      | 04   |
| 908c                                                                                       | 1221  | " " " Hinge ".....                                                      | 12   |
| 1619E                                                                                      | 1222  | " " " " " Nut.....                                                      | 05   |
| 19109                                                                                      | —     | Face Plate.....                                                         | 50   |
| 19110                                                                                      | 1202  | " " 19109 with 19154, 19155 & two 12152                                 | 1 00 |
| 190D                                                                                       | 783   | " " " Screw.....                                                        | 03   |
| 286D                                                                                       | 783   | " " " Thumb Screw.....                                                  | 08   |
| 19111                                                                                      | 1208  | Feed Bar.....                                                           | 75   |
| 313c                                                                                       | 783   | " " " Screw Centre.....                                                 | 04   |
| 1519E                                                                                      | 783   | " " " " Nut.....                                                        | 03   |
| 3033                                                                                       | 1145  | " Connecting Link.....                                                  | 20   |
| 375c                                                                                       | 782   | " " " Hinge Screw.....                                                  | 12   |
| 1518E                                                                                      | 783   | " " " " " Nut....                                                       | 04   |
| 19274                                                                                      | 788   | " Dog with 19118, for ⅜-in. to ⅝-in.<br>gauge, for lap seam feller..... | 1 50 |

## No. 44-35 Machine Parts.

| No.                                                | Plate | Name                                                                                                                                             | Each |
|----------------------------------------------------|-------|--------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 19338                                              | 786   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, for general work.....                                                  | 1 50 |
| 19339                                              | 786   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, for general work.....                                                  | 1 50 |
| 19340                                              | 785   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{2}$ -in. gauge, for lap seam feller.....                                               | 1 50 |
| 19341                                              | 789   | Feed Dog with 19118, for $\frac{1}{4}$ -in. to $\frac{1}{2}$ -in. gauge, for knit goods and general work..                                       | 1 50 |
| 19342                                              | 785   | Feed Dog with 19118, for $\frac{1}{4}$ -in. to $\frac{3}{16}$ -in. gauge, for collars and cuffs.....                                             | 1 50 |
| 19343                                              | 789   | Feed Dog with 19118, for $\frac{1}{4}$ -in. to $\frac{3}{16}$ -in. gauge, for general work.....                                                  | 1 50 |
| 19344                                              | 788   | Feed Dog with 19118, for $\frac{1}{4}$ -in. to $\frac{3}{16}$ -in. gauge, for lap seam feller.....                                               | 1 50 |
| 19479                                              | 793   | Feed Dog with 19118, for staying overgaiters                                                                                                     | 1 50 |
| 19482                                              | 794   | " " " " rounding                                                                                                                                 | 1 50 |
| 20068                                              | 795   | " " " " $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, for boning and corset strip.....                                                        | 1 50 |
| 20072                                              | 796   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{2}$ -in. gauge, two long rows of teeth.....                                            | 1 50 |
| 20074                                              | 797   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, for knit goods and general work..                                      | 1 50 |
| 20076                                              | 797   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, two long and two short rows of teeth, for heavy lap seam feller.....   | 1 50 |
| 20082                                              | 798   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, for collars and cuffs.....                                             | 1 50 |
| 20084                                              | 799   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, three long and two short rows of teeth, for general work.....          | 1 50 |
| 20086                                              | 799   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, for heavy bolting cloth.....                                           | 1 50 |
| 20088                                              | 800   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, three long and two short rows of teeth, for heavy lap seam feller..... | 1 75 |
| 20103                                              | 800   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, for lap seam feller.....                                               | 1 50 |
| 20108                                              | 801   | Feed Dog (spiked teeth) with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{4}$ -in. gauge, for collars and cuffs.                                  | 1 50 |
| NOTE:—When ordering Feed Dogs give gauge required. |       |                                                                                                                                                  |      |
| 191c                                               | 1221  | Feed Dog Screw.....                                                                                                                              | 03   |
| 19116                                              | 1220  | " " Spring.....                                                                                                                                  | 02   |
| 19117                                              | 1220  | " " " Hook for 19120.....                                                                                                                        | 01   |
| 19118                                              | 1220  | " " " " Feed Dogs.....                                                                                                                           | 01   |
| 19275                                              | 1203  | " and Feed Lifting Eccentric with 446c.                                                                                                          | 50   |
| 446c                                               | 783   | " " " " Set Screw.                                                                                                                               | 03   |
| 12429                                              | 1201  | " Forked Connection.....                                                                                                                         | 75   |
| 375c                                               | 782   | " " " " Hinge Screw.....                                                                                                                         | 12   |
| 1518g                                              | 783   | " " " " Nut.....                                                                                                                                 | 04   |

## No. 44-35 Machine Parts.

| No.    | Plate | Name                                                                         | Each |
|--------|-------|------------------------------------------------------------------------------|------|
| 16504  | 766   | Feed Lifting Rock Shaft.....                                                 | 45   |
| 19119  | "     | " " " " 16504 with 12200 and 19120.....                                      | 1 65 |
| 19120  | 1208  | Feed Lifting Rock Shaft Crank (front) with 157E, 19117, 19121 and 19122..... | 1 00 |
| 157E   | 782   | Feed Lifting Rock Shaft Crank (front) Clamping Screw.....                    | 04   |
| 19121  | 1208  | Feed Lifting Rock Shaft Crank (front) Roller.....                            | 12   |
| 19122  | 1208  | Feed Lifting Rock Shaft Crank (front) Roller Pin.....                        | 03   |
| 12200  | 1208  | Feed Lifting Rock Shaft Crank (back) with 462c.....                          | 20   |
| 2049   | 1220  | Feed Lifting Rock Shaft Crank (back) Pin.                                    | 01   |
| 462c   | 1221  | " " " " " " Set Screw.....                                                   | 02   |
| 12430  | 1201  | Feed Lifting Rock Shaft Crank Connecting Rod.....                            | 80   |
| #12204 | "     | Feed Lifting Rock Shaft Crank Connecting Rod Cap.....                        | "    |
| 145E   | 782   | Feed Lifting Rock Shaft Crank Connecting Rod Cap Screw.....                  | 04   |
| 375c   | 782   | Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw.....                | 12   |
| 1518E  | 783   | Feed Lifting Rock Shaft Crank Connecting Rod Hinge Screw Nut.....            | 04   |
| 307c   | 783   | Feed Lifting Rock Shaft Screw Centre....                                     | 06   |
| 1513c  | 783   | " " " " " " Nut.                                                             | 05   |
| 3039   | 768   | " Regulator.....                                                             | 25   |
| 58E    | 782   | " " " Hinge Screw.....                                                       | 15   |
| 818b   | 783   | " " " Thumb ".....                                                           | 12   |
| 16506  | 766   | " Rock Shaft.....                                                            | 35   |
| 16507  | "     | " " " 16506 with 3043.....                                                   | 50   |
| 3043   | 1208  | " " " Crank with 462c.....                                                   | 15   |
| 2049   | 1220  | " " " " Pin.....                                                             | 01   |
| 462c   | 1221  | " " " " Set Screw.....                                                       | 02   |
| 307c   | 783   | " " " " Screw Centre.....                                                    | 06   |
| 1513c  | 783   | " " " " " Nut.....                                                           | 05   |
| 19215  | 1228  | Guide for collars and cuffs.....                                             | 30   |
| 207    | 1219  | " Screw.....                                                                 | 02   |
| 7071   | 1220  | " " Washer.....                                                              | 01   |
| 18014  | 1203  | Needle Bar (hollow).....                                                     | 60   |
| 12382  | 1144  | " " Connecting Link with 794c...                                             | 50   |
| 794c   | 1144  | " " " " Adjusting Ser                                                        | 03   |
| 12383  | "     | " " " Stud.....                                                              | 40   |
| 1904   | 1144  | " " " " Roller (roller only).....                                            | 12   |
| 453c   | 783   | Needle Bar Connecting Stud Set Screw....                                     | 02   |
| 12381  | 1144  | " " " " 12383 with 453c and 1904.....                                        | 50   |

| No.                                                         | Plate | Name                                                                                 | Each |
|-------------------------------------------------------------|-------|--------------------------------------------------------------------------------------|------|
| 12385                                                       | 1203  | Needle Bar Crank with 855c and 858c.....                                             | 80   |
| 858c                                                        | 783   | " " " Set Screw.....                                                                 | 03   |
| 855c                                                        | 783   | " " " Timing Screw.....                                                              | 10   |
| 696e                                                        | 782   | Needle Bar Plug Screw.....                                                           | 03   |
| 12495                                                       | 1220  | " " " Rivet.....per 100 ..                                                           | 05   |
| 936b                                                        | 1221  | " " " Screw Bushing.....                                                             | 06   |
| 19124                                                       | 1218  | " " Clamp with two 460, for $\frac{1}{8}$ -in. to $\frac{3}{8}$ -in. gauge.....      | 1 25 |
| 19276                                                       | 1218  | Needle Clamp with two 209, for $\frac{7}{16}$ -in. gauge and above.....              | 1 25 |
| NOTE: When ordering No. 19124 or 19276 give gauge required. |       |                                                                                      |      |
| 2273                                                        | 1219  | Needle Clamp Pin.....                                                                | 01   |
| 209                                                         | 1221  | " Set Screw for 19276.....                                                           | 02   |
| 460                                                         | 783   | " " " " 19124.....                                                                   | 02   |
| 19386                                                       | 1203  | Oscillating Rock Shaft.....                                                          | 1 00 |
| 19387                                                       | ----- | " " " 19386 with 4784 and 12388.....                                                 | 1 50 |
| 12388                                                       | 1203  | Oscillating Rock Shaft Hinge Pin.....                                                | 50   |
| 878b                                                        | 783   | " " " " " Oil Hole Stop Screw.....                                                   | 06   |
| 12459                                                       | 1220  | Oscillating Rock Shaft Hinge Pin Oil Hole Stop Screw Washer (leather).....per 100... | 50   |
| 448c                                                        | 783   | Oscillating Rock Shaft Hinge Pin Set Screw.....                                      | 03   |
| 4784                                                        | 1101  | " " " Oil Pad.....                                                                   | 01   |
| 19127                                                       | 1200  | " Shaft.....                                                                         | 35   |
| 19496                                                       | ----- | " " " Crank.....                                                                     | 25   |
| 19388                                                       | 1208  | " " " " 19496 with 460c, 1518e and 19390.....                                        | 80   |
| 2049                                                        | 1220  | Oscillating Shaft Crank Pin.....                                                     | 01   |
| 460c                                                        | 783   | " " " Set Screw.....                                                                 | 02   |
| 19389                                                       | 1208  | " " " Slide Block.....                                                               | 35   |
| 229b                                                        | 782   | " " " " " Cap Scr.....                                                               | 02   |
| 12424                                                       | 1208  | " " " " " Washer.....                                                                | 02   |
| 969c                                                        | 1208  | Oscillating Shaft Crank Slide Block Scr. Stud.....                                   | 15   |
| 1518e                                                       | 783   | " " " " " Nut.....                                                                   | 04   |
| 19390                                                       | 1208  | Oscillating Shaft Crank Slide Block 19389 with 229b, 969c and 12424.....             | 50   |
| 12391                                                       | 1203  | Presser Bar (hollow).....                                                            | 80   |
| 12326                                                       | 1145  | " " Guide Bracket with 453c.....                                                     | 25   |
| 453c                                                        | 783   | " " " Set Screw.....                                                                 | 02   |
| 2062                                                        | 1145  | " " Lifter.....                                                                      | 25   |
| 689c                                                        | 782   | " " " Hinge Screw.....                                                               | 08   |
| 1520c                                                       | 783   | " " " " " Nut.....                                                                   | 03   |
| 12327                                                       | 1145  | " " Lifting and Releasing Lever Bracket.....                                         | 50   |
| 860e                                                        | 782   | Presser Bar Plug Screw.....                                                          | 03   |
| 11167                                                       | 1203  | " " Spring (spiral) light (.051 wire).....                                           | 05   |

| No.                                                                            | Plate | Name                                                                               | Each |
|--------------------------------------------------------------------------------|-------|------------------------------------------------------------------------------------|------|
| 12139                                                                          | 1203  | Presser Bar Spring (spiral) medium (.055 wire).....                                | 05   |
| 20023                                                                          | 1203  | " " " " heavy (.063 " ).....                                                       | 05   |
| 11170                                                                          | 1220  | " " " Washer.....                                                                  | 01   |
| 19128                                                                          | 1223  | " Foot, for general work.....                                                      | 1 00 |
| 19216                                                                          | 1225  | " " with 228, for 19342 and 25967... ..                                            | 1 00 |
| 19480                                                                          | 1223  | " " for staying overgaiters.....                                                   | 1 50 |
| 19183                                                                          | 1223  | " " rounding " ".....                                                              | 1 50 |
| 26276                                                                          | 1220  | " " Hinge Pin.....                                                                 | 01   |
| 20044                                                                          | ----- | " " Plate.....                                                                     | 1 00 |
| 26275                                                                          | ----- | " " Shank.....                                                                     | 75   |
| 20045                                                                          | 1223  | " " (hinged) Nos. 20044, 26275 and 26276.....                                      | 1 75 |
| 20046                                                                          | 1223  | Presser Foot (tube).....                                                           | 2 00 |
| 26276                                                                          | 1220  | " " Hinge Pin.....                                                                 | 01   |
| 20047                                                                          | ----- | " " Plate.....                                                                     | 2 00 |
| 26231                                                                          | 1220  | " " Spring.....                                                                    | 02   |
| 20048                                                                          | ----- | " " Shank.....                                                                     | 75   |
| 20049                                                                          | 1224  | " " (tube) hinged, Nos. 20047, 20048, 26231 and 26276.....                         | 2 75 |
| 20050                                                                          | 1224  | Presser Foot (tube) for taping.....                                                | 2 00 |
| 20052                                                                          | 1224  | " " for outside stays and strips... ..                                             | 1 50 |
| 20053                                                                          | 1224  | " " (strip) for boning.....                                                        | 1 75 |
| 20112                                                                          | 1225  | " " with 228, for 20108 and 25967... ..                                            | 1 00 |
| NOTE: When ordering Presser Feet or parts of Presser Feet give gauge required. |       |                                                                                    |      |
| 190b                                                                           | 782   | Presser Foot Screw.....                                                            | 03   |
| 688e                                                                           | 783   | Pressure Regulating Thumb Screw.....                                               | 25   |
| 19131                                                                          | 1216  | Shuttle (inside) Bobbin.....                                                       | 05   |
| 19134                                                                          | 1216  | " " " Case Latch and Position Finger.....                                          | 35   |
| 2521                                                                           | 1216  | Shuttle (inside) Bobbin Case Latch and Position Finger Spring.....                 | 02   |
| 592e                                                                           | 1216  | Shuttle (inside) Bobbin Case Latch and Position Finger Stop Screw.....             | 02   |
| 19132                                                                          | 1216  | Shuttle (inside) Bobbin Case complete, Nos. 591, 592e, 2521, 19134 and 19149.....  | 75   |
| 19136                                                                          | 1216  | Shuttle (inside) Body for 19129.....                                               | 75   |
| 591                                                                            | 1216  | " " Tension Regulating Screw.....                                                  | 02   |
| 19149                                                                          | 1216  | " " " Spring for 19132... ..                                                       | 10   |
| 19129                                                                          | 1216  | " " $1\frac{1}{16}$ -in. diam., No. 19136 with 19131 and 19132.....                | 1 50 |
| 19131                                                                          | 1216  | Shuttle (outside) Bobbin.....                                                      | 05   |
| 19135                                                                          | 1216  | " " " Case Latch and Position Finger.....                                          | 35   |
| 2521                                                                           | 1216  | Shuttle (outside) Bobbin Case Latch and Position Finger Spring.....                | 02   |
| 592e                                                                           | 1216  | Shuttle (outside) Bobbin Case Latch and Position Finger Stop Screw.....            | 02   |
| 19170                                                                          | 1216  | Shuttle (outside) Bobbin Case complete, Nos. 591, 592e, 2521, 19135 and 19172..... | 75   |

| No.    | Plate | Name                                                                                                                             | Each |
|--------|-------|----------------------------------------------------------------------------------------------------------------------------------|------|
| 19137  | 1216  | Shuttle (outside) Body for 19130.....                                                                                            | 75   |
| 19171  | 1217  | " " " " 19169.....                                                                                                               | 75   |
| 591    | 1216  | " " Tension Regulating Ser.....                                                                                                  | 02   |
| 19172  | 1216  | " " " Spring for 19170.....                                                                                                      | 10   |
| 19169  | 1217  | " " $1\frac{1}{16}$ -in. diam., No. 19171<br>with 19131 and 19170, for gauges up to<br>$\frac{13}{16}$ -in.....                  | 1 50 |
| 19130  | 1216  | Shuttle (outside) $1\frac{1}{16}$ -in. diam., No. 19137<br>with 19131 and 19170, for $\frac{3}{32}$ -in. gauge and<br>above..... | 1 50 |
| *19138 | —     | Shuttle Driver.....                                                                                                              | 2 50 |
| 19139  | 1208  | " " 19138 with two 453c.....                                                                                                     | 2 50 |

NOTE:—When ordering No. 19139 give  
gauge required.

|       |      |                                                                                    |      |
|-------|------|------------------------------------------------------------------------------------|------|
| 2049  | 1220 | Shuttle Driver Pin.....                                                            | 01   |
| 453c  | 783  | " " Set Screw.....                                                                 | 02   |
| 19277 | —    | " Race Body.....                                                                   | 1 75 |
| 19278 | 1212 | " " Loop Separator.....                                                            | 1 50 |
| 934b  | 1221 | " " " Screw.....                                                                   | 02   |
| 19279 | 1212 | " " Ring (inside).....                                                             | 1 50 |
| 19280 | 1212 | " " " (outside).....                                                               | 1 50 |
| 2532  | 1220 | " " " Position Pin, per 100.....                                                   | 10   |
| 2533  | 1215 | " " " Spring.....                                                                  | 15   |
| 907b  | 1221 | " " " " Screw.....                                                                 | 05   |
| 19282 | 1212 | " " complete, Nos. 19277 to 19280,<br>two each 907b, 934b, 2533 and four 2532..... | 6 00 |

NOTE: When ordering Shuttle Races or  
parts of Shuttle Races give gauge  
required.

|       |      |                                                                                             |    |
|-------|------|---------------------------------------------------------------------------------------------|----|
| 145   | 782  | Shuttle Race Screw.....                                                                     | 04 |
| 19145 | 1204 | " " Slide (inside).....                                                                     | 30 |
| 19146 | 1204 | " " " (outside) for $\frac{7}{16}$ -in. gauge<br>and below.....                             | 25 |
| 19281 | 1204 | Shuttle Race Slide (outside) for $\frac{15}{32}$ -in. to<br>$\frac{13}{16}$ -in. gauge..... | 25 |
| 19385 | 1204 | Shuttle Race Slide (outside) for $\frac{31}{32}$ in. to<br>$1\frac{1}{16}$ -in. gauge.....  | 25 |
| 19147 | 1220 | Shuttle Race Slide Friction Spring.....                                                     | 03 |
| 651E  | 1221 | " " " " " Screw.....                                                                        | 01 |
| 19148 | 1204 | " " " Guide with 651E & 19147.....                                                          | 50 |
| 691   | 782  | " " " " " Screw.....                                                                        | 04 |
| 2921  | 1146 | Tension Disc.....                                                                           | 05 |
| 19191 | 1146 | " Plate for upper tension with 19231.....                                                   | 50 |
| 134b  | 1221 | " " Screw.....                                                                              | 06 |
| 1560c | 1146 | " Regulating Thumb Nut.....                                                                 | 04 |

| No.   | Plate | Name                                                                                                                                           | Each |
|-------|-------|------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 19192 | 1146  | Tension Releaser.....                                                                                                                          | 15   |
| 12397 | 1145  | " Releasing Lever.....                                                                                                                         | 20   |
| 12398 | 1145  | " " " Hinge Pin.....                                                                                                                           | 01   |
| 12329 | 1145  | " " " Spring.....                                                                                                                              | 02   |
| 19193 | 1146  | " " " (intermediate).....                                                                                                                      | 10   |
| 19231 | 1146  | " " " " Hinge<br>Block.....                                                                                                                    | —    |
| 2269  | 1146  | Tension Releasing Lever (intermediate)<br>Hinge Pin.....                                                                                       | 01   |
| 19194 | 1146  | Tension Releasing Lever (intermediate)<br>Spring.....                                                                                          | 03   |
| 916   | 1146  | Tension Screw Stud.....                                                                                                                        | 08   |
| 1547b | 1146  | " " " Nut.....                                                                                                                                 | 03   |
| 2923  | 1146  | " Spring.....                                                                                                                                  | 03   |
| 12149 | 1218  | " Thread Guard.....                                                                                                                            | 05   |
| 19195 | 1146  | " complete (upper) with Tension Re-<br>lease, Nos. 2269, 19191, 19193, 19194, two<br>each 916, 1547b, 1560c, 2923, 19192 and<br>four 2921..... | 1 50 |
| 19154 | 1220  | Thread Guard (lower) for 19110.....                                                                                                            | 25   |
| 12152 | 1220  | " " " Rivet.....per 100.....                                                                                                                   | 10   |
| 19155 | 1220  | " " (upper) for 19110.....                                                                                                                     | 20   |
| 12152 | 1220  | " " " Rivet.....per 100.....                                                                                                                   | 10   |
| 19159 | 1218  | " Guide Body.....                                                                                                                              | 30   |
| 19161 | 1218  | " " Cap.....                                                                                                                                   | 10   |
| 19160 | 1218  | " " Roller.....                                                                                                                                | 10   |
| 905b  | 1218  | " " Screw.....                                                                                                                                 | 04   |
| 19162 | —     | " " complete (roller) Nos. 905b,<br>19159 to 19161.....                                                                                        | 50   |
| 12401 | 1144  | Thread Take-up Crank.....                                                                                                                      | 80   |
| 3091  | 1144  | " " " Wedge.....                                                                                                                               | 10   |
| 690E  | 1144  | " " " " Screw.....                                                                                                                             | 05   |
| 19156 | 1144  | " " Lever.....                                                                                                                                 | 30   |
| 775E  | 1144  | " " " Cap Screw.....                                                                                                                           | 06   |
| 12166 | 1144  | " " " Hinge Pin.....                                                                                                                           | 05   |
| 12409 | 1144  | " " " Link.....                                                                                                                                | 25   |
| 11201 | 1144  | " " " " Hinge Pin.....                                                                                                                         | 15   |
| 430c  | 1144  | " " " " " " Set<br>Screw.....                                                                                                                  | 04   |
| 19157 | 1144  | Thread Take-up Lever 19156 with 12166 and<br>12409.....                                                                                        | 65   |
| 19158 | 1218  | Thread Take-up Spring (music wire).....                                                                                                        | 03   |
| 7336  | 1218  | " " " Regulator.....                                                                                                                           | 25   |
| 448c  | 783   | " " " " Set Screw.....                                                                                                                         | 03   |
| 19283 | 788   | Throat Plate for 19274.....                                                                                                                    | 1 50 |
| 19287 | 786   | " " " 19338.....                                                                                                                               | 1 50 |
| 19288 | 786   | " " " 19339.....                                                                                                                               | 1 50 |
| 19190 | 785   | " " " 19340.....                                                                                                                               | 1 50 |
| 19291 | 789   | " " " 19341.....                                                                                                                               | 1 50 |
| 19163 | 785   | " " " 19215 and 19342.....                                                                                                                     | 1 50 |
| 19290 | 789   | " " " 19343.....                                                                                                                               | 1 50 |

| No.   | Plate | Name                                              | Each |
|-------|-------|---------------------------------------------------|------|
| 19289 | 788   | Throat Plate for 19344.....                       | 1 50 |
| 19481 | 793   | " " with 4515, for 19479.....                     | 1 50 |
| 4515  | —     | " " Spring Guide for 19481.....                   | 25   |
| 19484 | 794   | " " with 240b, 19485 and 19486, for<br>19482..... | 2 50 |
| 19485 | —     | Throat Plate Arm for 19484.....                   | 15   |
| 19486 | —     | " " Spring Guide for 19484.....                   | 50   |
| 240b  | 782   | " " " " Screw.....                                | 01   |
| 20069 | 795   | " " for 20068.....                                | 1 50 |
| 20073 | 796   | " " " 20072.....                                  | 1 50 |
| 20075 | 797   | " " " 20074.....                                  | 1 50 |
| 20077 | 797   | " " " 20076.....                                  | 1 50 |
| 20083 | 798   | " " " 20082.....                                  | 1 50 |
| 20085 | 799   | " " " 20084.....                                  | 1 50 |
| 20087 | 799   | " " " 20086.....                                  | 1 50 |
| 20089 | 800   | " " " 20088.....                                  | 1 50 |
| 20104 | 800   | " " " 20103.....                                  | 1 50 |
| 20109 | 801   | " " " 20108.....                                  | 1 50 |

NOTE:—When ordering Throat Plates give  
gauge required.

|       |     |                                          |    |
|-------|-----|------------------------------------------|----|
| 691   | 782 | Throat Plate Screw.....                  | 04 |
| 24079 | —   | Drip Pan with four 1-in. wire nails..... | 25 |

## PARTS COMPLETE FOR

**No. 44-36 MACHINE.**

DROP FEED, TWO NEEDLES, TWO SHUTTLES, THROAT PLATE  
FLUSH WITH BED PLATE, FOR COLLARS AND CUFFS.

| No.    | Plate | Name                                                           | Each |
|--------|-------|----------------------------------------------------------------|------|
| *19107 | —     | Arm.....                                                       | 4 25 |
| 8582   | 1220  | " Dowel Pin.....                                               | 02   |
| 12453  | 1220  | " Oil Tube for intermediate bearing ....                       | 06   |
| 12454  | 1220  | " " " " oiling 12409.....                                      | 06   |
| 11149  | 1220  | " " " " " 19156.....                                           | 10   |
| 748E   | 782   | " Screw (back).....                                            | 08   |
| 868E   | 1221  | " " (front).....                                               | 10   |
| 16511  | 1200  | " Shaft.....                                                   | 1 90 |
| *11104 | —     | " Bushing (front).....                                         | 30   |
| 12357  | 1203  | " " Flanged Bushing (back).....                                | 25   |
| 448c   | 783   | " " " " " Set Scr.....                                         | 03   |
| 144b   | 782   | " " Screw.....                                                 | 12   |
| 12480  | 1205  | " Side Cap.....                                                | 05   |
| 219    | 790   | " " " Screw.....                                               | 02   |
| 12193  | 1202  | " " Cover.....                                                 | 10   |
| 286b   | 783   | " " " Thumb Screw.....                                         | 08   |
| 2415   | 1200  | " Spool Bracket.....                                           | 25   |
| 159    | 1221  | " " " Screw.....                                               | 03   |
| 12403  | 1220  | " " " Spool Pin and Thread<br>Eyelet.....                      | 05   |
| 11241  | 1203  | Arm Spool Bracket Washer (cloth)...per 100                     | 25   |
| 15063  | 1200  | " " " 2415 with two 12403... ..                                | 35   |
| 12358  | —     | Balance Wheel, light rim, 2½-in. pulley,<br>with two 448c..... | 75   |
| 12359  | 1200  | Balance Wheel, light rim, 3-in. pulley, with<br>two 448c.....  | 75   |
| 448c   | 783   | Balance Wheel Set Screw.....                                   | 03   |
| *19303 | —     | Bed.....                                                       | 4 50 |
| 12496  | 1201  | Crank Connecting Rod.....                                      | 1 35 |
| *14013 | —     | " " " Cap.....                                                 | —    |
| 896E   | 1221  | " " " " Screw.....                                             | 04   |
| 908c   | 1221  | " " " " Hinge Screw.....                                       | 12   |
| 1619E  | 1222  | " " " " " Nut.....                                             | 05   |
| 19304  | —     | Face Plate.....                                                | 50   |
| 19305  | 1202  | " " 19304 with 19155, 19327 and two<br>12452.....              | 1 00 |
| 190b   | 782   | Face Plate Screw.....                                          | 03   |
| 286b   | 783   | " " Thumb Screw.....                                           | 08   |
| 19111  | 1208  | Feed Bar.....                                                  | 75   |
| 343c   | 783   | " " Screw Centre.....                                          | 04   |
| 1519E  | 783   | " " " " Nut.....                                               | 03   |
| 3033   | 1445  | " Connecting Link.....                                         | 20   |
| 375c   | 782   | " " " " Hinge Screw.....                                       | 12   |
| 1518E  | 783   | " " " " " Nut... ..                                            | 04   |



| No.   | Plate | Name                                               | Each |
|-------|-------|----------------------------------------------------|------|
| 12391 | 1203  | Presser Bar (hollow).....                          | 80   |
| 12326 | 1145  | " " Guide Bracket with 453c.....                   | 25   |
| 453c  | 783   | " " " " Set Screw.....                             | 02   |
| 2062  | 1145  | " " Lifter.....                                    | 25   |
| 689c  | 782   | " " " Hinge Screw.....                             | 08   |
| 1520c | 783   | " " " " " Nut.....                                 | 03   |
| 12327 | 1145  | " " Lifting and Releasing Lever Bracket.....       | 50   |
| 860E  | 782   | Presser Bar Plug Screw.....                        | 03   |
| 11167 | 1203  | " " Spring (spiral) light (.051 wire).....         | 05   |
| 12139 | 1203  | " " " " " medium (.055 wire).....                  | 05   |
| 20023 | 1203  | Presser Bar Spring (spiral) heavy (.063 wire)..... | 05   |
| 11170 | 1220  | " " " Washer.....                                  | 01   |
| 19216 | 1225  | " Foot with 228, for 19150 and 25967.....          | 1 00 |
| 20112 | 1225  | " " " " " 20110 " " ..                             | 1 00 |

NOTE:—When ordering No. 19216 or 20112 give gauge required.

|       |      |                                                                                                                              |      |
|-------|------|------------------------------------------------------------------------------------------------------------------------------|------|
| 1900  | 782  | Presser Foot Screw.....                                                                                                      | 03   |
| 688E  | 783  | Pressure Regulating Thumb Screw.....                                                                                         | 25   |
| 19131 | 1216 | Shuttle (inside) Bobbin.....                                                                                                 | 05   |
| 19310 | 1217 | " " " Case Latch and Position Finger.....                                                                                    | 35   |
| 2521  | 1216 | Shuttle (inside) Bobbin Case Latch and Position Finger Spring.....                                                           | 02   |
| 592E  | 1216 | Shuttle (inside) Bobbin Case Latch and Position Finger Stop Screw.....                                                       | 02   |
| 19312 | 1217 | Shuttle (inside) Bobbin Case complete, Nos. 591, 592E, 2521, 19149 and 19310.....                                            | 75   |
| 19136 | 1216 | Shuttle (inside) Body.....                                                                                                   | 75   |
| 591   | 1216 | " " " Tension Regulating Screw.....                                                                                          | 02   |
| 19149 | 1216 | " " " " Spring.....                                                                                                          | 10   |
| 19324 | 1217 | " " " 1 $\frac{1}{16}$ -in. diam., No. 19136 with 19131 and 19312.....                                                       | 1 50 |
| 19131 | 1216 | Shuttle (outside) Bobbin.....                                                                                                | 05   |
| 19311 | 1217 | " " " " Case Latch and Position Finger.....                                                                                  | 35   |
| 2521  | 1216 | Shuttle (outside) Bobbin Case Latch and Position Finger Spring.....                                                          | 02   |
| 592E  | 1216 | Shuttle (outside) Bobbin Case Latch and Position Finger Stop Screw.....                                                      | 02   |
| 19133 | 1217 | Shuttle (outside) Bobbin Case complete, Nos. 591, 592E, 2521, 19172 and 19311, for 19325 and 19326.....                      | 75   |
| 19137 | 1216 | Shuttle (outside) Body for 19325.....                                                                                        | 75   |
| 19171 | 1217 | " " " " 19326.....                                                                                                           | 75   |
| 591   | 1216 | " " " Tension Regulating Ser.....                                                                                            | 02   |
| 19172 | 1216 | " " " " Spring.....                                                                                                          | 10   |
| 19326 | 1217 | " " " 1 $\frac{1}{16}$ -in. diam., No. 19171 with 19131 and 19313, for $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge..... | 1 50 |

| No.    | Plate | Name                                                                                                                        | Each |
|--------|-------|-----------------------------------------------------------------------------------------------------------------------------|------|
| 19325  | 1217  | Shuttle (outside) 1 $\frac{1}{16}$ -in. diam., No. 19137 with 19131 and 19313, for $\frac{1}{32}$ -in. gauge and above..... | 1 50 |
| *19138 | ----- | Shuttle Driver.....                                                                                                         | 2 50 |
| 19139  | 1208  | " " 19138 with two 453c.....                                                                                                | 2 50 |

NOTE:—When ordering No. 19139 give gauge required.

|       |       |                                                                                                                                                       |      |
|-------|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 2049  | 1220  | Shuttle Driver Pin.....                                                                                                                               | 01   |
| 453c  | 783   | " " " Set Screw.....                                                                                                                                  | 02   |
| 19315 | ----- | " Race Body for 19323 and 24013.....                                                                                                                  | 1 75 |
| 19379 | ----- | " " " " 19382.....                                                                                                                                    | 1 75 |
| 19316 | 1213  | " " " Loop Separator for 19323.....                                                                                                                   | 15   |
| 19309 | 1213  | " " " Needle Guard for 19323 and 24013.....                                                                                                           | 25   |
| 337D  | 1221  | Shuttle Race Needle Guard Screw.....                                                                                                                  | 02   |
| 19317 | 1213  | " " " Ring (inside) for 19309, 19323 and 24013.....                                                                                                   | 1 50 |
| 19380 | 1214  | Shuttle Race Ring (inside) for 19382.....                                                                                                             | 1 50 |
| 19318 | 1213  | " " " " (outside) for 19323 and 24013.....                                                                                                            | 1 50 |
| 19381 | 1214  | Shuttle Race Ring (outside) for 19382.....                                                                                                            | 1 50 |
| 2532  | 1220  | " " " " Position Pin, per 100.....                                                                                                                    | 10   |
| 2533  | 1215  | " " " " Spring.....                                                                                                                                   | 15   |
| 907D  | 1221  | " " " " Screw.....                                                                                                                                    | 05   |
| 19382 | 1214  | " " " complete, Nos. 19379 to 19381, two each 907D, 2533 and four 2532, for $\frac{1}{32}$ -in. to $\frac{5}{16}$ -in. gauge.....                     | 5 00 |
| 19323 | 1213  | Shuttle Race complete, Nos. 19309, 19315 to 19318, two each 337D, 907D, 2533 and four 2532, for $\frac{1}{32}$ -in. to $\frac{5}{16}$ -in. gauge..... | 5 00 |
| 24013 | 1215  | Shuttle Race complete, Nos. 19309, 19315, 19317, 19318, two each 337D, 907D, 2533 and four 2532, for $\frac{1}{16}$ -in. gauge & above.....           | 5 00 |

NOTE:—When ordering Shuttle Races or parts of Shuttle Races give gauge required.

|       |      |                                                                                                             |    |
|-------|------|-------------------------------------------------------------------------------------------------------------|----|
| 145   | 782  | Shuttle Race Screw.....                                                                                     | 04 |
| 19319 | 1204 | " " " Slide (inside).....                                                                                   | 35 |
| 19320 | 1220 | " " " " " Stop Stud.....                                                                                    | 05 |
| 19321 | 1220 | " " " " " " Spring.....                                                                                     | 02 |
| 19322 | 1204 | " " " " (outside) with 662E and 19147, for $\frac{1}{16}$ -in. gauge and below.....                         | 30 |
| 19491 | 1202 | Shuttle Race Slide (outside) with 662E and 19147, for $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge..... | 30 |
| 19492 | 1202 | Shuttle Race Slide (outside) with 662E and 19147, for $\frac{1}{32}$ -in. to $\frac{1}{4}$ -in. gauge.....  | 30 |
| 19147 | 1220 | Shuttle Race Slide (outside) Friction Spring.....                                                           | 30 |
| 662E  | 782  | " " " " " " " Screw.....                                                                                    | 01 |
| 2921  | 1146 | Tension Disc.....                                                                                           | 05 |
| 19191 | 1146 | " " Plate for upper tension with 19231.....                                                                 | 50 |

**No. 44-37 MACHINE.**

This Machine is the same as 44-36, with the following exceptions:

NOTE:--When ordering Feed Dogs give gauge required.

NOTE:—When ordering Presser Feet or parts of Presser Feet give gauge required.

NOTE :- When ordering Throat Plates give gauge required.

| No.   | Plate | Name                             | Each |
|-------|-------|----------------------------------|------|
| 19219 | 1206  | Bed Frame Cushion (leather)..... | 05   |
| 1580  | 1206  | “ “ “ Screw.....                 | 03   |
| 19220 | 1206  | “ “ “ Spring.....                | 05   |

## For Machine on Iron Base.

| No.   | Plate | Name                                                                                                                                            | Each |
|-------|-------|-------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 19226 | 1206  | Bed Frame Hinge Connection.....                                                                                                                 | 15   |
| 19397 | 1206  | " " " " Cap.....                                                                                                                                | 30   |
| 211   | 1206  | " " " " " Screw....                                                                                                                             | 03   |
| 19398 | "     | " " " " 19226 with 211<br>and 19397.....                                                                                                        | 20   |
| 16555 | 1206  | Bed Frame Hinge Plate.....                                                                                                                      | 15   |
| 14010 | 1206  | " " " " Rivet.....                                                                                                                              | 01   |
| 970b  | 1221  | " " Thumb Screw.....                                                                                                                            | 20   |
| 19399 | 1231  | " " complete, Nos. 970b, two each<br>16555, 19398, four each 19219, 19220, six<br>each 14010, wood screws 1½-in. No. 10,<br>and eight 158c..... | 2 35 |

## Attachments &amp; Accessories.

| No.   | Plate | Name                                                                       | Each |
|-------|-------|----------------------------------------------------------------------------|------|
| 12361 | 1207  | Machine Hinge Connection.....                                              | 15   |
| 12362 | 1207  | " " Plate.....                                                             | 15   |
| 12363 | "     | " " complete, Nos. 12361, 12362<br>and two wood screws, 1¼-in. No. 14..... | 30   |
| 12405 | 1207  | Machine Rest (felt).....                                                   | 02   |
| 25955 | 1161  | Oiler with 25956.....                                                      | 15   |
| 25956 | 1161  | " Spout, 8½-in. long.....                                                  | 07   |
| 26026 | 1161  | Screw Driver (machine).....                                                | 10   |
| 26027 | 1161  | " " (shuttle tension).....                                                 | 05   |
| 10874 | 1205  | Tweezers.....                                                              | 10   |
| 4347  | 1161  | Wrench for 1513 and 1518.....                                              | 15   |
| 4822  | 1207  | " " 1547, 1548 and 1549.....                                               | 05   |
| 8908  | 1161  | " " 1520.....                                                              | 10   |
| 19221 | 1161  | " " 936 and 1619.....                                                      | 15   |

## GUIDES.

| No.   | Plate | Name                                    | Each |
|-------|-------|-----------------------------------------|------|
| 26266 | 1228  | Stay Guide Plate (lower).....           | 20   |
| 26267 | 1228  | " " " (upper).....                      | 20   |
| 193   | 1221  | " " Screw.....                          | 03   |
| 7074  | 1220  | " " Washer.....                         | 01   |
| 26268 | "     | " " complete, Nos. 26266 and 26267..... | 40   |

## LAP SEAM FELLER PARTS.

| No.   | Plate | Name                                                                | Each |
|-------|-------|---------------------------------------------------------------------|------|
| 26269 | "     | Folder for 26272.....                                               | 3 25 |
| 18114 | "     | " Slide.....                                                        | 15   |
| 19294 | 1226  | " " Spring.....                                                     | 05   |
| 405E  | 1226  | " " " Screw.....                                                    | 02   |
| 26272 | 1226  | Lap Seam Feller (right hand) complete,<br>Nos. 18114 and 26269..... | 3 40 |
| 26396 | 1226  | Folder for 26397.....                                               | 3 25 |
| 18118 | 1227  | Holder with 8505 and 18116, for 44-37 Mach.                         | 75   |
| 207   | 1219  | " Screw.....                                                        | 02   |
| 18116 | 1227  | " Spring.....                                                       | 05   |
| 8505  | 1227  | " " Rivet.....per 100...                                            | 10   |
| 26397 | 1226  | Lap Seam Feller (left hand) complete, Nos.<br>18114 and 26396.....  | 3 40 |

NOTE: When ordering No. 26272 or 26397  
give gauge required.

| No.                                                                                                                             | Plate | Name                                                                                                     | Each |
|---------------------------------------------------------------------------------------------------------------------------------|-------|----------------------------------------------------------------------------------------------------------|------|
| 26274                                                                                                                           | —     | Presser Foot Plate.....                                                                                  | 1 25 |
| 26276                                                                                                                           | 1220  | “ “ Hinge Pin.....                                                                                       | 01   |
| 26275                                                                                                                           | —     | “ “ Shank.....                                                                                           | 75   |
| 26273                                                                                                                           | 1223  | “ “ (hinged) Nos. 26274 to 26276,<br>for light lap seam feller.....                                      | 2 00 |
| 26330                                                                                                                           | —     | Presser Foot Plate.....                                                                                  | 1 75 |
| 26276                                                                                                                           | 1220  | “ “ Hinge Pin.....                                                                                       | 01   |
| 26275                                                                                                                           | —     | “ “ Shank.....                                                                                           | 75   |
| 26329                                                                                                                           | 1226  | “ “ (hinged) Nos. 26275, 26276<br>and 26330, for medium or heavy lap seam<br>feller.....                 | 2 50 |
| 26382                                                                                                                           | —     | Presser Foot Plate.....                                                                                  | 1 75 |
| 26276                                                                                                                           | 1220  | “ “ Hinge Pin.....                                                                                       | 01   |
| 26395                                                                                                                           | —     | “ “ Shank.....                                                                                           | 75   |
| 26383                                                                                                                           | 1226  | “ “ (hinged) Nos. 26276, 26382 and<br>26395, for X heavy, XX heavy and XXX<br>heavy lap seam feller..... | 2 50 |
| NOTE:— When ordering 26273, 26329<br>or 26383 give the gauge and size<br>of the lap seam feller with<br>which it is to be used. |       |                                                                                                          |      |
| 19147                                                                                                                           | 1220  | Shuttle Race Slide Friction Spring.....                                                                  | 03   |
| 651E                                                                                                                            | 1221  | “ “ “ “ “ Screw.....                                                                                     | 01   |
| 19189                                                                                                                           | 1204  | “ “ “ Guide with 651E & 19147.....                                                                       | 75   |
| 914                                                                                                                             | 1221  | “ “ “ “ “ Screw.....                                                                                     | 01   |

**PRESSER FEET.**

| No.   | Plate | Name                                                                     | Each |
|-------|-------|--------------------------------------------------------------------------|------|
| 26404 | 1224  | Presser Foot (tube) for reeding.....                                     | 2 50 |
| 26405 | ----- | " " Plate.....                                                           | 2 50 |
| 26276 | 1220  | " " Hinge Pin.....                                                       | 01   |
| 26275 | ----- | " " Shank.....                                                           | 75   |
| 26406 | 1224  | " " (tube) hinged for reeding, Nos.<br>26275, 26276 and 26405.....       | 3 25 |
| 26407 | 1224  | Presser Foot for double strips (tube) for<br>reeding.....                | 3 00 |
| 26408 | 1224  | Presser Foot for double strips (tube).....                               | 2 25 |
| 26409 | ----- | " " Plate.....                                                           | 2 25 |
| 26276 | 1220  | " " Hinge Pin.....                                                       | 01   |
| 26275 | ----- | " " Shank.....                                                           | 75   |
| 26410 | 1224  | " " for double strips (tube) hinged,<br>Nos. 26275, 26276 and 26409..... | 3 00 |
| 26411 | 1225  | Presser Foot (strip folding) for cording.....                            | 4 00 |
| 26414 | 1225  | " " " " " opening<br>seams and enclosing folded edges.....               | 5 75 |

| No.                                                                                  | Plate | Name                                                                                             | Each |
|--------------------------------------------------------------------------------------|-------|--------------------------------------------------------------------------------------------------|------|
| 26415                                                                                | 1225  | Presser Foot (strip folding).....                                                                | 3 50 |
| 26416                                                                                | 1225  | “ “ “ “ with guide for<br>opening seams.....                                                     | 3 50 |
| 26417                                                                                | -     | Presser Foot Plate.....                                                                          | 3 50 |
| 26276                                                                                | 1220  | “ “ Hinge Pin.....                                                                               | 01   |
| 26275                                                                                | -     | “ “ Shank.....                                                                                   | 75   |
| 26418                                                                                | 1225  | “ “ (strip folding) hinged, with<br>guide for opening seams, Nos. 26275,<br>26276 and 26417..... | 4 25 |
| NOTE:—When ordering Presser Feet or<br>parts of Presser Feet give<br>gauge required. |       |                                                                                                  |      |
| 26279                                                                                | -     | Presser Foot Extension, $\frac{1}{16}$ in., for 19216....                                        | 15   |
| 26280                                                                                | 1225  | “ “ “ “ “ “ “ “ .....                                                                            | 15   |
| 26281                                                                                | -     | “ “ “ “ “ “ “ “ .....                                                                            | 15   |
| 26282                                                                                | -     | “ “ “ “ “ “ “ “ .....                                                                            | 15   |
| 26283                                                                                | -     | “ “ “ “ “ “ “ “ .....                                                                            | 15   |
| 2280                                                                                 | 1221  | “ “ “ “ “ Screw.....                                                                             | 02   |
| 25967                                                                                | 1225  | “ “ Strip Gauge.....                                                                             | 15   |
| 2280                                                                                 | 1221  | “ “ “ “ “ Screw.....                                                                             | 02   |

NOTE:—When ordering Presser Feet or parts of Presser Feet give gauge required.

**SPOOL HOLDER (DISC).**

| No.   | Plate | Name                                        | Each |
|-------|-------|---------------------------------------------|------|
| 26041 | 1205  | Bracket with 219 and 287D.....              | 15   |
| 219   | 790   | " " Screw .....                             | 02   |
| 287D  | 783   | " " Thumb Screw.....                        | 09   |
| 26042 | 1205  | Spindle with Disc.....                      | 30   |
| 26043 | 1205  | Spool Holder complete, Nos. 26041 and 26042 | 50   |

## STRIP FOLDER.

|        |      |                           |   |    |
|--------|------|---------------------------|---|----|
| *26412 | -    | Strip Folder.....         | 2 | 35 |
| 18114  | -    | " " Slide.....            |   | 15 |
| 26413  | 1226 | " " 26412 with 18114..... | 2 | 50 |

NOTE:- When ordering No. 26413 give gauge required.

**TAPE HOLDER (8-IN. DISC).**

| No.   | Plate     | Name                                       | Each |
|-------|-----------|--------------------------------------------|------|
| 26061 | 989       | Bracket Wire with Disc.....                | 20   |
| 26062 | 989       | Disc (adjustable) with 286p.....           | 30   |
|       | 286p 783  | " Thumb Screw.....                         | 08   |
| 26325 | 1200      | Foot with 736p.....                        | 20   |
|       | 736p 1221 | " Screw.....                               | 10   |
| 26063 | 989       | Tape Holder complete, Nos. 26061 and 26062 | 50   |
| 26065 | —         | " " 26063 with 26325.....                  | 70   |

**TAPE HOLDER (10-IN. DISC).**

| No.   | Plate | Name                                                   | Each |
|-------|-------|--------------------------------------------------------|------|
| 26066 | 989   | Bracket Wire.....                                      | -    |
| 26067 | —     | " " 26066 with 26068 and 26072.....                    | 60   |
| 26068 | 989   | Disc.....                                              | -    |
| 26069 | 989   | " Hub.....                                             | -    |
| 26070 | —     | " " Rivet.....                                         | -    |
| 26071 | —     | " 26068 with 26069 and three 26070.....                | 40   |
| 26064 | 1200  | Foot with 736d.....                                    | 20   |
| 736d  | 1221  | " Screw.....                                           | 10   |
| 26072 | 989   | Tape Guide.....                                        | -    |
| 26073 | 1206  | Tension Adjusting Collar with 286d.....                | 15   |
| 286d  | 783   | " " " Thumb Screw.....                                 | 08   |
| 13211 | 1206  | " " " Spring.....                                      | 02   |
| 26074 | 989   | Tape Holder complete, Nos. 13211, 26067 and 26071..... | 1 25 |
| 26343 | —     | Tape Holder 26074 with 26061.....                      | 1 45 |

**TAPE SPOOL FIXTURE (WIRE).**

| No.   | Plate | Name                                           | Each |
|-------|-------|------------------------------------------------|------|
| 4516  | —     | Tape Spool Fixture (wire) with fixed cone..... | 60   |
| 4518  | 1206  | " " " Cone.....                                | 10   |
| 1541B | 1222  | " " " Regulating Thumb Nut.....                | 05   |
| 8019  | 1206  | " " " Spring.....                              | 02   |
| 4517  | 1205  | " " " 4516 with 1541B, 4518 and 8019.....      | 75   |

**SPOOL FIXTURE (WIRE).**

| No.   | Plate | Name                                     | Each |
|-------|-------|------------------------------------------|------|
| 4715  | —     | Spool Fixture (wire) with two 10145..... | 55   |
| 4717  | —     | " " Flange.....                          | 10   |
| 10145 | 1220  | " " Thread Eyelet.....                   | 01   |
| 4718  | —     | " " Washer (felt).....                   | 01   |
| 4716  | 1205  | " " 4715 with two 4717 & three 4718..... | 75   |

**BOBBIN WINDER.****BOBBIN WINDER (SWINGING AUTOMATIC, RIGHT HAND).**

| No.   | Plate | Name                              | Each |
|-------|-------|-----------------------------------|------|
| 27552 | 1162  | Base.....                         | 15   |
| 15072 | 1220  | Bobbin Position Pin.....per 100.. | 10   |
| 27302 | 1162  | Frame.....                        | 15   |
| 32d   | 782   | " Hinge Screw.....                | 15   |
| 27303 | 1220  | " Spring.....                     | 03   |

**Bobbin Winder.**

47

| No.   | Plate | Name                                                                                                        | Each |
|-------|-------|-------------------------------------------------------------------------------------------------------------|------|
| 27553 | 1162  | Pulley.....                                                                                                 | 20   |
| 27538 | 1162  | Spindle with 15072.....                                                                                     | 20   |
| 27306 | 1162  | Spool Pin.....                                                                                              | 05   |
| 27307 | 1162  | " Stand.....                                                                                                | 10   |
| 27308 | 1162  | " " 27307 with 418d, 1562d, 2106, 10141, 11241, 27306, wood screw 1-in. No. 10 and two 2455.....            | 35   |
| 11241 | 1203  | Spool Washer (cloth).....per 100..                                                                          | 25   |
| 27587 | 1162  | Stop Latch.....                                                                                             | 10   |
| 35d   | 1221  | " " Hinge Screw.....                                                                                        | 07   |
| 2455  | 1220  | Tension Disc.....                                                                                           | 02   |
| 1562d | 1222  | " Regulating Thumb Nut.....                                                                                 | 04   |
| 118d  | 1221  | " Screw Stud.....                                                                                           | 08   |
| 10141 | 1220  | " Spring.....                                                                                               | 01   |
| 2106  | 1220  | " Thread Guide.....                                                                                         | 01   |
| 27651 | 1162  | Bobbin Winder, Nos. 32d, 35d, 27302, 27303, 27538, 27552, 27553, 27587 and two wood screws 1-in. No. 7..... | 1 00 |
| 27588 | —     | Bobbin Winder (swinging automatic, right hand) complete, 27651 with 27308.....                              | 1 35 |

**DRIVING ATTACHMENT.**

| No.   | Plate | Name                                                                                               | Each |
|-------|-------|----------------------------------------------------------------------------------------------------|------|
| 16592 | 1230  | Balance Wheel (friction) with 7958, 16524 and two 448c.....                                        | 1 00 |
| 16524 | —     | Balance Wheel Friction Ring (leather).....                                                         | 05   |
| 7958  | 1220  | " " " Stop Pin.....                                                                                | 01   |
| 448c  | 783   | " " Set Screw.....                                                                                 | 03   |
| 15072 | 1220  | Bobbin Position Pin for 15077.....per 100..                                                        | 10   |
| 16514 | 768   | " Winder Frame.....                                                                                | 15   |
| 32d   | 782   | " " " Hinge Screw.....                                                                             | 15   |
| 16515 | 768   | " " " complete, Nos. 333d, 5960, 5961, 5963, 15077 and 16514.....                                  | 60   |
| 5960  | 768   | Bobbin Winder Friction Wheel (leather)...                                                          | 10   |
| 5961  | 768   | " " " Washer.....                                                                                  | 05   |
| 333d  | 782   | " " " " Screw.....                                                                                 | 04   |
| 15077 | 1207  | " " Spindle with 15072.....                                                                        | 15   |
| 5963  | 768   | " " Flange.....                                                                                    | 06   |
| 27306 | 1162  | " " Spool Pin.....                                                                                 | 05   |
| 27307 | 1162  | " " Stand.....                                                                                     | 10   |
| 27308 | 1162  | " " " 27307 with 418d, 1562d, 2106, 10141, 11241, 27306, wood screw 1-in. No. 10 and two 2455..... | 35   |
| 11241 | 1203  | Bobbin Winder Spool Washer (cloth).....per 100..                                                   | 25   |
| 12170 | 1207  | " " Spring.....                                                                                    | 03   |
| 180   | 782   | " " Screw.....                                                                                     | 03   |
| 19258 | 1207  | " " Stop Latch with 152 & 1550.....                                                                | 50   |
| 152   | 782   | " " " " Adjusting Screw.....                                                                       | 03   |
| 1550  | 783   | " " " " " " Nut.....                                                                               | 03   |

**Driving Attachment.**

| No.   | Plate | Name                                                                                                                                                               | Each |
|-------|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 2877  | 1230  | Treadle Pitman Rod (upper) for 15130.....                                                                                                                          | 05   |
| 14081 | 1230  | " " " " " 14233.....                                                                                                                                               | 10   |
| 9079  | 362   | " " " Clamp with 354c.....                                                                                                                                         | 12   |
| 354c  | 1101  | " " " " Screw.....                                                                                                                                                 | 06   |
| 15130 | 1230  | " " complete, Nos. 2762, 2877,<br>9079, 27637 and 27638.....                                                                                                       | 35   |
| 14233 | 1230  | Treadle Pitman complete, Nos. 2762, 9079,<br>14081, 27637 and 27638, for Bench Stand..                                                                             | 40   |
| 2878  | 363   | Treadle Stand.....                                                                                                                                                 | 15   |
| 27642 | -     | " 27636 with 2878, 9082 and four<br>wood screws, 1-in., No 16.....                                                                                                 | 45   |
| 15131 | -     | Treadle & Pitman complete, Nos. 15130 & 27642                                                                                                                      | 80   |
| 14234 | -     | " " " " " 14233 " " "                                                                                                                                              | 85   |
| 2762  | 1206  | " Stop Collar with 362.....                                                                                                                                        | 10   |
| 362   | 1221  | " " " Set Screw.....                                                                                                                                               | 05   |
| 19264 | -     | Driving Attachment complete, Nos. 397b,<br>692b, 932b, 12188, 14234 or 15131, 16519,<br>16592, 16594, 19260, 19262, 27070, 27308 and<br>two each 65p and 130p..... | 5 00 |

## FOOT LIFTER PARTS.

| No                                                  | Plate | Name                                                      | Each |
|-----------------------------------------------------|-------|-----------------------------------------------------------|------|
| 5596                                                | 768   | Bell Crank.....                                           | 05   |
| 5599                                                | 768   | " " Bracket.....                                          | 08   |
| 178c                                                | 782   | " " " Screw.....                                          | 03   |
| 5601                                                | 1220  | " " " Hinge Pin.....                                      | 01   |
| 5602                                                | 1220  | " " " Spring.....                                         | 02   |
| 5598                                                | 768   | " " 5596 with 5599, 5601 and 5602....                     | 20   |
| 5670                                                | --    | Chain, length 26-in. to 35-in.....                        | 15   |
| NOTE: When ordering No. 5670 state length required. |       |                                                           |      |
| 4879                                                | 1203  | Chain Connecting Link for 4885.....                       | 03   |
| 16510                                               | 766   | Lifting Lever with 448c.....                              | 20   |
| 12415                                               | 768   | " " Connecting Rod.....                                   | 08   |
| 12416                                               | 1445  | " " " " " Joint.....                                      | 08   |
| 76d                                                 | 782   | " " " " " Hinge Ser.....                                  | 05   |
| 1521e                                               | 1222  | " " " " " Lock Nut.....                                   | 03   |
| 802d                                                | 782   | " " " Hinge Screw.....                                    | 12   |
| 12244                                               | 1445  | " " " Link.....                                           | 10   |
| 766d                                                | 782   | " " " " Hinge Screw.....                                  | 05   |
| 12240                                               | 1445  | " " " Pin.....                                            | 05   |
| 448c                                                | 783   | " " " " Set Screw.....                                    | 03   |
| 2763                                                | 766   | Rock Shaft.....                                           | 10   |
| 12242                                               | 766   | " " " Hanger with two wood screws,<br>1½-in., No. 10..... | 08   |
| 6337                                                | 766   | Rock Shaft Lifting Bracket with two 356c.....             | 20   |
| 12243                                               | 1231  | " " " " " Hook for 4880..                                 | 15   |
| 7125                                                | 1231  | " " " " " " " " " " " "                                   | 15   |
| 356c                                                | 783   | " " " " " " " " " " " Set Screw.....                      | 06   |

## Foot Lifter Parts.

| No.   | Plate | Name                                                                                                                                 | Each |
|-------|-------|--------------------------------------------------------------------------------------------------------------------------------------|------|
| 356c  | 783   | Rock Shaft Lifting Bracket Set Screw.....                                                                                            | 06   |
| 2770  | 766   | " " Stop Dog with 356c.....                                                                                                          | 12   |
| 356c  | 783   | " " " " Set Screw.....                                                                                                               | 06   |
| 4880  | 1231  | " " complete, Nos. 2763, 2770, 7125,<br>12243 and two each 6337 and 12242.....                                                       | 1 00 |
| 4881  | 1231  | Treadle.....                                                                                                                         | 30   |
| 4882  | 1203  | " Shaft.....                                                                                                                         | 05   |
| 4883  | 1203  | " Spring.....                                                                                                                        | 10   |
| 4884  | 1231  | " Stand.....                                                                                                                         | 25   |
| 4885  | 1231  | " complete, Nos. 4879 & 4881 to 4884.....                                                                                            | 75   |
| 19331 | —     | Foot Lifter complete, Nos. 76b, 766b, 802b,<br>1521e, 4880, 4885, 5598, 5670, 12240, 12241,<br>12415, 12416, 16510 and two 178c..... | 2 85 |

## KNEE LIFTER PARTS.

| No.   | Plate | Name                                                                                                                     | Each |
|-------|-------|--------------------------------------------------------------------------------------------------------------------------|------|
| 5596  | 768   | Bell Crank.....                                                                                                          | 05   |
| 5599  | 768   | " " Bracket.....                                                                                                         | 08   |
| 178c  | 782   | " " " " Screw.....                                                                                                       | 03   |
| 5601  | 1220  | " " Hinge Pin.....                                                                                                       | 01   |
| 5602  | 1220  | " " Spring.....                                                                                                          | 02   |
| 5598  | 768   | " " 5596 with 5599, 5601 and 5602.....                                                                                   | 20   |
| 16510 | 766   | Lifting Lever with 448c.....                                                                                             | 20   |
| 12415 | 768   | " " Connecting Rod.....                                                                                                  | 08   |
| 12416 | 1145  | " " " " Joint.....                                                                                                       | 08   |
| 76b   | 782   | " " " " " " Hinge<br>Screw.....                                                                                          | 05   |
| 1521e | 1222  | Lifting Lever Connecting Rod Lock Nut.....                                                                               | 03   |
| 802b  | 782   | " " Hinge Screw.....                                                                                                     | 12   |
| 12241 | 1145  | " " Link.....                                                                                                            | 10   |
| 766b  | 782   | " " " " Hinge Screw.....                                                                                                 | 05   |
| 12240 | 1145  | " " Pin.....                                                                                                             | 05   |
| 448c  | 783   | " " " " Set Screw.....                                                                                                   | 03   |
| 2763  | 766   | Rock Shaft.....                                                                                                          | 10   |
| 19242 | 766   | " " Hanger with two wood screws,<br>1½-in., No. 10.....                                                                  | 08   |
| 2765  | 766   | Rock Shaft Knee Arm.....                                                                                                 | 10   |
| 2766  | 766   | " " " " Hub with 356c.....                                                                                               | 15   |
| 356c  | 783   | " " " " " " Set Screw.....                                                                                               | 06   |
| 2768  | —     | " " " " " " 2765 with 2766 & 2767.....                                                                                   | 40   |
| 2767  | 766   | " " " " Plate with 356c.....                                                                                             | 18   |
| 356b  | 783   | " " " " " " Set Screw.....                                                                                               | 06   |
| 6337  | 766   | " " Lifting Bracket with two 356c.....                                                                                   | 20   |
| 2778  | 766   | " " " " Hook.....                                                                                                        | 05   |
| 356c  | 783   | " " " " " " Set Ser.....                                                                                                 | 06   |
| 2770  | 766   | " " Stop Dog with 356c.....                                                                                              | 12   |
| 356c  | 783   | " " " " " " Set Screw.....                                                                                               | 06   |
| 2777  | 766   | " " complete, 2763 with 2768, 2770,<br>2778, 6337 and two 12242.....                                                     | 1 00 |
| 16512 | —     | Knee Lifter complete, Nos. 76b, 766b, 802b,<br>1521e, 2777, 5598, 12240, 12241, 12415,<br>12416, 16510 and two 178c..... | 1 95 |

## THREAD UNWINDER

FOR TWO LARGE SPOOLS.

| No.   | Plate | Name                                                                                                           | Each |
|-------|-------|----------------------------------------------------------------------------------------------------------------|------|
| 27555 | 1203  | Spool Pin.....                                                                                                 | 08   |
| 27583 | 1163  | " Rest.....                                                                                                    | 20   |
| 27556 | —     | " " 27583 with 138b and two 27555.....                                                                         | 40   |
| 138b  | 1101  | " " Set Screw.....                                                                                             | 05   |
| 27557 | 1163  | " Stand with 138b.....                                                                                         | 25   |
| 27558 | 1163  | " Weight, 4-in. diam., with 27592.....                                                                         | 15   |
| 27592 | 1206  | " " Centre Pin.....                                                                                            | 05   |
| 27559 | 1163  | Thread Guard.....                                                                                              | 20   |
| 27563 | 1163  | " " Hub.....                                                                                                   | 20   |
| 330b  | 1221  | " " " " Set Screw.....                                                                                         | 03   |
| 27560 | 1163  | " " Rod, 26-in. long.....                                                                                      | 30   |
| 138b  | 1101  | " " " " Set Screw.....                                                                                         | 05   |
| 449c  | 1221  | " " Set Screw.....                                                                                             | 02   |
| 27561 | —     | " " 27559 with 330b, 449c & 27563.....                                                                         | 50   |
| 27562 | 1163  | " Unwinder complete, Nos. 27556,<br>27557, 27560, 27561, two 27558 and three<br>wood screws, 1-in. No. 10..... | 1 60 |

## UNDER DRIVER.

LEVER PRESSURE, RIGHT HAND (OIL CONTROLLING PULLEY).

| No.   | Plate | Name                                                                          | Each |
|-------|-------|-------------------------------------------------------------------------------|------|
| 27508 | 362   | Belt Guard.....                                                               | 08   |
| 356c  | 783   | " " Screw.....                                                                | 06   |
| 2018  | 1101  | " " " " Washer.....                                                           | 01   |
| 27509 | 362   | Cone Pulley, three speed, 2½-in., 3¼-in. and<br>5½-in. diam., with 27473..... | 60   |
| 27473 | 1101  | Cone Pulley Centre Bearing.....                                               | 08   |
| 27474 | 363   | Dress Guard (right hand).....                                                 | 08   |
| 138b  | 1101  | " " Screw.....                                                                | 05   |
| 27630 | 362   | Driving Pulley, 6-in. diam., with 955c, 27476<br>and two 7958.....            | 60   |
| 27476 | —     | Driving Pulley Friction Ring (leather).....                                   | 05   |
| 7958  | 1220  | " " " " Stop Pin.....                                                         | 01   |
| 27631 | 1101  | " " Hollow Stud with 27600.....                                               | 15   |
| 27600 | 1101  | " " " " Position Stud.....                                                    | —    |
| 356c  | 783   | " " " " Set Screw.....                                                        | 06   |
| 27632 | —     | " " " " Wick.....                                                             | 01   |
| 27633 | —     | " " " " Wire with<br>27632.....                                               | 05   |

| No.   | Plate | Name                                                                                                                                                                                                                               | Each |
|-------|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 955c  | 1101  | Driving Pulley Screw Centre Bearing.....                                                                                                                                                                                           | 08   |
| 7958  | 1220  | " " " " " Dowel Pin                                                                                                                                                                                                                | 01   |
| 27634 | 362   | Frame.....                                                                                                                                                                                                                         | 60   |
| 27529 | 362   | Lever.....                                                                                                                                                                                                                         | 25   |
| 27497 | 1101  | " Brake Strip (leather).....                                                                                                                                                                                                       | 02   |
| 27483 | 1101  | " " Spring.....                                                                                                                                                                                                                    | 02   |
| 12178 | 1101  | " Centre Plug (wood).....                                                                                                                                                                                                          | 01   |
| 427E  | 1101  | " " Adjusting Screw.....                                                                                                                                                                                                           | 08   |
| 1508c | 783   | " " " " " Nut.....                                                                                                                                                                                                                 | 06   |
| 27485 | 1101  | " Hinge Pin.....                                                                                                                                                                                                                   | 01   |
| 27635 | 362   | Oil Cup.....                                                                                                                                                                                                                       | 25   |
| 145E  | 782   | " " Screw.....                                                                                                                                                                                                                     | 04   |
| 27070 | 363   | Shaft Driving Pulley, 10-in. diam. (grooved)<br>1 3/8-in. bore, sectional, with two 597c....                                                                                                                                       | 45   |
| 597c  | 1221  | Shaft Driving Pulley Clamping Screw.....                                                                                                                                                                                           | 08   |
| 27636 | 363   | Treadle.....                                                                                                                                                                                                                       | 30   |
| 9082  | 1101  | " Bearing Cotter Pin.....                                                                                                                                                                                                          | 01   |
| 27637 | 362   | " Pitman Rod (lower).....                                                                                                                                                                                                          | 05   |
| 27638 | 1104  | " " " " Spring.....                                                                                                                                                                                                                | 03   |
| 27639 | 362   | " " " (upper).....                                                                                                                                                                                                                 | 05   |
| 9079  | 362   | " " " Clamp with 354c.....                                                                                                                                                                                                         | 12   |
| 354c  | 1101  | " " " " Screw.....                                                                                                                                                                                                                 | 06   |
| 27640 | 362   | " " complete, Nos. 2762, 9079 and<br>27637 to 27639.....                                                                                                                                                                           | 35   |
| 2762  | 1206  | Treadle Stop Collar with 362.....                                                                                                                                                                                                  | 10   |
| 362   | 1221  | " " " Set Screw.....                                                                                                                                                                                                               | 05   |
| 2878  | 363   | " Stand.....                                                                                                                                                                                                                       | 15   |
| 27642 | —     | " 27636 with 2878, 9082 and four wood<br>screws, 1-in., No. 16.....                                                                                                                                                                | 45   |
| 27643 | —     | Treadle complete, Nos. 27640 and 27642....                                                                                                                                                                                         | 80   |
| 27644 | —     | Transmitter complete for 27645, Nos. 138g,<br>427E, 1508c, 2018, 12178, 27474, 27483, 27485,<br>27497, 27508, 27509, 27529, 27630, 27631,<br>27633 to 27635, two each 145E and 356c<br>and four wood screws, 1 1/2-in., No. 16.... | 3 00 |
| 27645 | —     | Under Driver, Lever Pressure, three speed,<br>complete, Nos. 27070, 27643 and 27644....                                                                                                                                            | 4 00 |

## OBSOLETE PARTS.

| No.    | Plate | Name                                                                                                                                                            | Each |
|--------|-------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 12365  | 1201  | Crank Connecting Rod for 375c.....                                                                                                                              | 1 35 |
| 375c   | 782   | " " " Hinge Screw.....                                                                                                                                          | 12   |
| 1518E  | 783   | " " " " " Nut....                                                                                                                                               | 04   |
| 19235  | 787   | Feed Dog with 19118, for 44-33 Machine....                                                                                                                      | 1 25 |
| 19337  |       | " and Feed Lifting Eccentric with 446c,<br>for 44-36 Machine.....                                                                                               | 50   |
| *19237 |       | Needle Bar for right hand needle with 4766,<br>for 19248.....                                                                                                   | -    |
| *19238 |       | Needle Bar for left hand needle, for 19248.                                                                                                                     | -    |
| 19241  | 1229  | " " Coupling Pin for 19248.....                                                                                                                                 | 10   |
| 19242  | 1229  | " " " " Lever Bell Crank<br>with 19244, for 44-33 Machine.....                                                                                                  | 50   |
| 19243  | 1229  | Needle Bar Coupling Pin Lever Bell Crank<br>Bracket for 44-33 Machine.....                                                                                      | 2 00 |
| 19244  | 1229  | Needle Bar Coupling Pin Lever Bell Crank<br>Washer for 19242.....                                                                                               | 01   |
| 19245  | 1229  | Needle Bar Coupling Pin Lever Hub for<br>44-33 Machine.....                                                                                                     | 20   |
| 19248  |       | Needle Bar complete, 19237 and 19238, with<br>185, 335, 874, 930E, 4766, 4840, 19240,<br>19241, 19247, 19249 and two 621D, use<br>19458, for 44-33 Machine..... | 5 00 |
| 19257  |       | Needle Bar Trip Lever Pitman for 44-33<br>Machine.....                                                                                                          | 50   |
| 19249  | 1229  | Needle Clamp for left hand needle with<br>19250, for 19248.....                                                                                                 | 1 25 |
| 19250  | 1229  | Needle Clamp Thread Guard for 19249.....                                                                                                                        | 02   |
| 19251  | 1229  | Oil Cup with 12486, for 19253.....                                                                                                                              | 20   |
| 19252  | 1229  | " " Extension for 19253.....                                                                                                                                    | 07   |
| 180    | 782   | " " " Screw.....                                                                                                                                                | 03   |
| 1548D  | 1222  | " " Nut.....                                                                                                                                                    | 03   |
| 19253  |       | " " complete, Nos. 1548D, 19251 & 19252                                                                                                                         | 30   |
| 12485  |       | " " with 12486, use 24022.....                                                                                                                                  | 25   |
| 19125  |       | Oscillating Rock Shaft for 375c and 1902....                                                                                                                    | 1 00 |
| 19126  |       | " " " 19125 with 12388....                                                                                                                                      | 1 50 |
| 12443  | 1229  | " " " Oil Pad for 16508....                                                                                                                                     | 01   |
| 16508  | 1229  | " " " " " Holder with<br>12443.....                                                                                                                             | 05   |
| 238D   | 782   | Oscillating Rock Shaft Oil Pad Holder Ser.                                                                                                                      | 01   |
| 19166  | 1203  | " " " for 908c and 1902....                                                                                                                                     | 1 00 |
| 19167  |       | Oscillating Rock Shaft 19166 with 12388....                                                                                                                     | 1 50 |
| 12390  | 1229  | " Shaft Crank 19496 with 460c,<br>1518g and 1902.....                                                                                                           | 65   |
| 1902   | 783   | Oscillating Shaft Crank Roller and Screw<br>Stud.....                                                                                                           | 35   |
| 19133  |       | Shuttle (outside) Bobbin Case complete,<br>Nos. 591, 592E, 2521, 19135 and 19150, use<br>19170.....                                                             | 75   |

| No.   | Plate | Name                                                                                                        | Each |
|-------|-------|-------------------------------------------------------------------------------------------------------------|------|
| 19150 |       | Shuttle (outside) Tension Spring, use 19172                                                                 | 40   |
| 19314 |       | " " Bobbin Case complete,<br>Nos. 591, 592w, 2521, 19172 and 19311, use<br>19313, .....                     | 75   |
| 19141 |       | Shuttle Race Body for 19140, .....                                                                          | 1 75 |
| 19142 | 1211  | " " Ring (inside) for 19140, .....                                                                          | 1 50 |
| 19143 | 1211  | " " " (outside) for 19140, .....                                                                            | 1 50 |
| 19144 | 1211  | " " Loop Separator for 19140, .....                                                                         | 1 00 |
| 756b  | 1221  | " " " Screw for 19140                                                                                       | 02   |
| 19140 | 1211  | " " complete, Nos. 19141 to 19144,<br>two each 756b, 907b, 2533, and four 2532,<br>for 44-32 Machine, ..... | 6 00 |

NOTE: When ordering Nos. 19140 to 19141  
give gauge required.

|       |      |                                                                                                |      |
|-------|------|------------------------------------------------------------------------------------------------|------|
| 19151 | 1229 | Tension Plate for upper tension with 19152.                                                    | 40   |
| 19152 | 1229 | " " Stud, .....                                                                                | 10   |
| 19153 | 1229 | " (upper) complete, No. 19151 with<br>two each 637, 1547b, 1560b, 8238 and four<br>2102, ..... | 95   |
| 19254 | 787  | Throat Plate for 19235, .....                                                                  | 1 25 |
| 19383 |      | " " Body, .....                                                                                | 1 25 |
| 19378 | 790  | " " Loop Separator, .....                                                                      | 1 00 |
| 19384 | 790  | " " complete, Nos. 219, 19378 and<br>19383, use 20128, .....                                   | 2 25 |

## Numerical List of Parts.

| No.  | Plate | Name                                                                                 | Each |
|------|-------|--------------------------------------------------------------------------------------|------|
| 32b  | 782   | Bobbin Winder Frame Hinge Screw for<br>19260 and 27651, .....                        | 15   |
| 35b  | 1221  | Bobbin Winder Stop Latch Hinge Screw for<br>27651, .....                             | 07   |
| 58e  | 782   | Feed Regulator Hinge Screw, .....                                                    | 15   |
| 65b  | 782   | Driving Arm Pitman Hinge Screw for 19264, .....                                      | 15   |
| 75b  | 782   | Bobbin Winder Stop Latch Hinge Screw for<br>19260, .....                             | 12   |
| 76b  | 782   | Lifting Lever Connecting Rod Joint Hinge<br>Screw for 16512 and 19331, .....         | 05   |
| 76b  | 782   | Needle Bar Trip Lever Connection Joint<br>Hinge Screw for 44-33 Machine, .....       | 05   |
| 90b  | 1221  | Needle Bar Trip Lever Pitman Hinge Screw<br>(lever end) for 44-33 Machine, .....     | 05   |
| 95b  | 1221  | Needle Bar Trip Lever Pitman Hinge Screw<br>(crank end) for 44-33 Machine, .....     | 05   |
| 130b | 782   | Starting Crank Shaft Bracket Screw (short)<br>for 19264, .....                       | 08   |
| 131b | 1221  | Tension Plate Screw, .....                                                           | 06   |
| 138e | 1101  | Dress Guard Screw for 27644, .....                                                   | 05   |
| 138b | 1101  | Thread Unwinder Spool Rest Set Screw for<br>27556, .....                             | 05   |
| 138b | 1101  | Thread Unwinder Thread Guard Rod Set<br>Screw for 27557, .....                       | 05   |
| 144b | 782   | Arm Shaft Screw, .....                                                               | 12   |
| 145e | 782   | Feed Lifting Rock Shaft Crank Connecting<br>Rod Cap Screw, .....                     | 04   |
| 145e | 782   | Oil Cup Screw for 27644, .....                                                       | 04   |
| 145  | 782   | Shuttle Race Screw, .....                                                            | 04   |
| 152  | 782   | Bobbin Winder Stop Latch Adjusting Screw<br>for 19258, .....                         | 03   |
| 157e | 782   | Feed Lifting Rock Shaft Crank (front)<br>Clamping Screw, .....                       | 04   |
| 158e | 1206  | Bed Frame Cushion Screw for 19399, .....                                             | 03   |
| 159  | 1221  | Arm Spool Bracket Screw, .....                                                       | 03   |
| 171  | 1221  | Roller Needle Guard (round) Set Screw for<br>19211 to 19214, .....                   | 03   |
| 176  | 1221  | Roller Arm Lock Spring Screw for 19211 to<br>19214, .....                            | 03   |
| 178c | 782   | Bell Crank Bracket Screw for 16512 & 19331                                           | 03   |
| 178e | 782   | Needle Bar Trip Lever Bell Crank Bracket<br>Screw for 44-33 Machine, .....           | 03   |
| 180  | 782   | Bobbin Winder Spring Screw for 19260, .....                                          | 03   |
| 180  | 782   | Oil Cup Extension Screw for 19253, .....                                             | 03   |
| 185  | 1219  | Thread Retainer Disc Cover Screw for 44-33<br>Machine, .....                         | 02   |
| 187  | 1219  | Needle Bar Trip Lever Connection Spring<br>Collar Set Screw for 44-33 Machine, ..... | 02   |

## Numerical List of Parts.

| No.  | Plate | Name                                                                                                | Each |
|------|-------|-----------------------------------------------------------------------------------------------------|------|
| 190b | 782   | Face Plate Screw.....                                                                               | 03   |
| 190D | 782   | Needle Bar Coupling Pin Lever Shaft Bracket<br>Screw for 44-33 Machines.....                        | 03   |
| 190D | 782   | Presser Foot Screw.....                                                                             | 03   |
| 190D | 782   | Roller Presser Screw.....                                                                           | 03   |
| 191c | 1221  | Feed Dog Screw.....                                                                                 | 03   |
| 193  | 1221  | Stay Guide Screw (A. and A.).....                                                                   | 03   |
| 207  | 1219  | Guide Screw for 44-35 and 44-36 Machines.....                                                       | 02   |
| 207  | 1219  | Lap Seam Feller Holder Screw for 18118.....                                                         | 02   |
| 207  | 1219  | Needle Bar Coupling Pin Lever Hub Set<br>Screw for 44-33 Machine.....                               | 02   |
| 207  | 1219  | Needle Bar Coupling Pin Rest Set Screw for<br>44-33 Machine.....                                    | 02   |
| 207  | 1219  | Roller Needle Guard (flat) Screw for 19211<br>and 19213.....                                        | 02   |
| 209  | 1221  | Needle Set Screw (right) for 19308.....                                                             | 02   |
| 209  | 1221  | " " " for 19276.....                                                                                | 02   |
| 211  | 1206  | Bed Frame Hinge Connection Cap Screw<br>for 19398.....                                              | 03   |
| 213  | 1221  | Oil Cup Screw for 44-32 to 44-34 Machines.....                                                      | 03   |
| 219  | 790   | Arm Side Cap Screw.....                                                                             | 02   |
| 219  | 790   | Folder Holder Seat Cover Screw for 44-37<br>Machine.....                                            | 02   |
| 219  | 790   | Guide Screw for 44-32 and 44-33 Machines.....                                                       | 02   |
| 219  | 790   | Spool Holder Bracket Screw for 26041.....                                                           | 02   |
| 219  | 790   | Throat Plate Loop Separator Screw for 19384<br>and 20128.....                                       | 02   |
| 224  | 1219  | Needle Bar Spring Collar Screw for 44-33<br>Machine.....                                            | 02   |
| 228D | 1221  | Presser Foot Extension Screw.....                                                                   | 02   |
| 228D | 1221  | Presser Foot Strip Gauge Screw for 19216.....                                                       | 02   |
| 229D | 782   | Oscillating Shaft Crank Slide Block Cap Ser.<br>" Rock Shaft Oil Pad Holder Screw<br>for 16508..... | 02   |
| 238D | 782   | Throat Plate Spring Guide Screw for 19484.....                                                      | 01   |
| 240D | 782   | Arm Side Cover Thumb Screw.....                                                                     | 01   |
| 286D | 783   | Face Plate Thumb Screw.....                                                                         | 08   |
| 286D | 783   | Tape Holder Disc Thumb Screw for 26062.....                                                         | 08   |
| 286D | 783   | " " Tension Adjusting Collar<br>Thumb Screw for 26073.....                                          | 08   |
| 287D | 783   | Spool Holder Bracket Thumb Screw for 26041.....                                                     | 09   |
| 307c | 783   | Feed Lifting Rock Shaft Screw Centre.....                                                           | 06   |
| 307c | 783   | " Rock Shaft Screw Centre.....                                                                      | 06   |
| 313c | 783   | " Bar Screw Centre.....                                                                             | 04   |
| 316  | 1221  | Roller Arm Bracket Screw Centre for 19211<br>to 19214.....                                          | 03   |
| 330B | 1221  | Thread Unwinder Thread Guard Hub Set<br>Screw for 27561.....                                        | 03   |
| 333D | 782   | Bobbin Winder Friction Wheel Washer<br>Screw for 16515.....                                         | 04   |
| 337D | 1221  | Shuttle Race Needle Guard Screw for 44-34<br>and 44-36 Machines.....                                | 02   |

## Numerical List of Parts.

| No.  | Plate | Name                                                                  | Each |
|------|-------|-----------------------------------------------------------------------|------|
| 354c | 1101  | Treadle Pitman Rod Clamp Screw for 9079.....                          | 06   |
| 356c | 783   | Belt Guard Screw for 27644.....                                       | 06   |
| 356c | 783   | Driving Pulley Hollow Stud Set Ser. for 27644.....                    | 06   |
| 356c | 783   | Rock Shaft Knee Arm Hub Set Ser. for 2766.....                        | 06   |
| 356c | 783   | " " " Plate Set Screw for 2767.....                                   | 06   |
| 356c | 783   | " " " Lifting Bracket Hook Set Screw<br>for 6337.....                 | 06   |
| 356c | 783   | Rock Shaft Lifting Bracket Set Ser. for 6337.....                     | 06   |
| 356c | 783   | " " Stop Dog Set Screw for 2770.....                                  | 06   |
| 362  | 1221  | Starting Crank Shaft Stop Collar Set Screw<br>for 19263.....          | 05   |
| 362  | 1221  | Treadle Stop Collar Set Screw for 2762.....                           | 05   |
| 375c | 782   | Crank Connecting Rod Hinge Screw for 12365.....                       | 12   |
| 375c | 782   | Feed Connecting Link Hinge Screw.....                                 | 12   |
| 375c | 782   | " Forked Connection Hinge Screw.....                                  | 12   |
| 375c | 782   | " Lifting Rock Shaft Crank Connecting<br>Rod Hinge Screw.....         | 12   |
| 386D | 1101  | Roller Screw for 1839.....                                            | 08   |
| 397D | 782   | Oil Cover Screw for 19264.....                                        | 04   |
| 405E | 1226  | Lap Seam Feller Folder Slide Spring Screw.....                        | 02   |
| 418D | 1221  | Bobbin Winder Tension Screw Stud for 27308.....                       | 08   |
| 427E | 1101  | Driving Arm Friction Plug Adjusting Ser.<br>for 19260.....            | 08   |
| 427E | 1101  | Lever Centre Plug Adjusting Screw for 27644.....                      | 08   |
| 430c | 1144  | Thread Take-up Lever Link Hinge Pin Set<br>Screw.....                 | 04   |
| 440  | 1221  | Roller Arm Adjusting Screw for 19211 to 19214.....                    | 03   |
| 446c | 783   | Feed and Feed Lifting Eccentric Set Screw<br>for 12428 and 19275..... | 03   |
| 446c | 783   | Feed Cam and Feed Lifting Eccentric Set<br>Screw for 12197.....       | 03   |
| 448c | 783   | Arm Shaft Flanged Bushing (back) Set Ser.....                         | 03   |
| 448c | 783   | Balance Wheel Set Screw.....                                          | 03   |
| 448c | 783   | Lifting Lever Pin Set Screw for 16510.....                            | 03   |
| 448c | 783   | Oscillating Rock Shaft Hinge Pin Set Screw.....                       | 03   |
| 448c | 783   | Thread Take-up Spring Regulator " ".....                              | 03   |
| 449c | 1221  | " Unwinder Thread Guard " ".....<br>for 27561.....                    | 02   |
| 453c | 783   | Needle Bar Connecting Stud Set Ser. for 12384.....                    | 02   |
| 453c | 783   | Presser " Guide Bracket Set Screw.....                                | 02   |
| 453c | 783   | Shuttle Driver Set Screw.....                                         | 02   |
| 460  | 783   | Needle Set Screw (left) for 19308.....                                | 02   |
| 460  | 783   | " " " for 19124.....                                                  | 02   |
| 460c | 783   | Oscillating Shaft Crank Set Screw.....                                | 02   |
| 462c | 1221  | Feed Lifting Rock Shaft Crank (back) Set<br>Screw.....                | 02   |
| 462c | 1221  | Feed Rock Shaft Crank Set Screw.....                                  | 02   |
| 465c | 1227  | Presser Foot Bracket Set Screw for 19477.....                         | 01   |
| 468  | 1219  | Needle Clamp Thread Guide Set Ser. for 19461.....                     | 02   |
| 591  | 1216  | Shuttle Tension Regulating Screw.....                                 | 02   |

## Numerical List of Parts.

| No.  | Plate | Name                                                                                  | Each |
|------|-------|---------------------------------------------------------------------------------------|------|
| 592E | 1216  | Shuttle Bobbin Case Latch and Position<br>Finger Stop Screw.....                      | 02   |
| 597C | 1221  | Shaft Driving Pulley Clamping Ser. for 27070                                          | 08   |
| 620  | 1219  | Needle Set Screw for right hand needle, for<br>44-33 Machine.....                     | 02   |
| 634D | 1221  | Roller Screw for 1875.....                                                            | 08   |
| 651E | 1221  | Shuttle Race Slide Friction Spring Screw for<br>19148, 19185 and 19189.....           | 01   |
| 662E | 782   | Shuttle Race Slide (outside) Friction Spring<br>Screw for 19322, 19491 and 19492..... | 01   |
| 665D | 1219  | Needle Bar Thread Guide Screw for 19460.....                                          | 02   |
| 688E | 783   | Pressure Regulating Thumb Screw.....                                                  | 25   |
| 689C | 782   | Presser Bar Lifter Hinge Screw.....                                                   | 08   |
| 690E | 1144  | Thread Take-up Crank Wedge Screw.....                                                 | 05   |
| 691  | 782   | Shuttle Race Slide Guide Screw for 44-32,<br>44-33 and 44-35 Machines.....            | 04   |
| 691  | 782   | Throat Plate Screw.....                                                               | 04   |
| 692D | 783   | Bracket Screw for 16530.....                                                          | 12   |
| 693D | 782   | Driving Arm Hinge Screw for 19260.....                                                | 40   |
| 696E | 782   | Needle Bar Plug Screw for 18914.....                                                  | 03   |
| 735D | 1227  | Presser Foot Guide Set Screw for 4460.....                                            | 02   |
| 736D | 1221  | Tape Holder Foot Screw for 26064 & 26325.....                                         | 10   |
| 748E | 782   | Arm Screw (back).....                                                                 | 08   |
| 756D | 1221  | Shuttle Race Loop Separator Screw for 19140                                           | 02   |
| 766D | 782   | Lifting Lever Link Hinge Screw for 16512<br>and 19331.....                            | 05   |
| 775E | 1144  | Thread Take-up Lever Cap Screw.....                                                   | 06   |
| 794C | 1144  | Needle Bar Connecting Link Adjusting Ser.                                             | 03   |
| 802D | 782   | Lifting Lever Hinge Screw for 16512 & 19331                                           | 12   |
| 802D | 782   | Needle Bar Trip Lever Hinge Screw for 44-33<br>Machine.....                           | 12   |
| 818D | 783   | Feed Regulator Thumb Screw.....                                                       | 12   |
| 855C | 783   | Needle Bar Crank Timing Screw.....                                                    | 10   |
| 858C | 783   | " " " Set Screw.....                                                                  | 03   |
| 860E | 782   | Presser Bar Plug Screw.....                                                           | 03   |
| 868E | 1221  | Arm Screw (front).....                                                                | 10   |
| 878D | 783   | Oscillating Rock Shaft Hinge Pin Oil Hole<br>Stop Screw.....                          | 06   |
| 896E | 1221  | Crank Connecting Rod Cap Screw.....                                                   | 04   |
| 905D | 1218  | Thread Guide Screw for 19162.....                                                     | 04   |
| 907D | 1221  | Shuttle Race Ring Spring Screw.....                                                   | 05   |
| 908C | 1221  | Crank Connecting Rod Hinge Screw.....                                                 | 12   |
| 914  | 1221  | Shuttle Race Slide Guide Screw for 19189.....                                         | 04   |
| 916  | 1146  | Tension Screw Stud.....                                                               | 08   |
| 930E | 1219  | Needle Bar Connecting Stud Screw for 44-33<br>Machine.....                            | 04   |
| 931D | 1219  | Needle Bar Screw Bushing for 44-33 Mach..                                             | 10   |
| 932D | 1221  | Starting Crank Shaft Bracket Screw (long)<br>for 19264.....                           | 08   |
| 934D | 1221  | Shuttle Race Loop Separator Screw for<br>19282.....                                   | 02   |

## Numerical List of Parts.

| No.   | Plate | Name                                                                      | Each |
|-------|-------|---------------------------------------------------------------------------|------|
| 936D  | 1221  | Needle Bar Screw Bushing for 44-32 & 44-34<br>to 44-37 Machines.....      | 06   |
| 955C  | 1101  | Driving Pulley Screw Centre Bearing for<br>27630.....                     | 08   |
| 969C  | 1208  | Oscillating Shaft Crank Slide Block Screw<br>Stud.....                    | 15   |
| 979D  | 1221  | Bed Frame Thumb Screw for 19399.....                                      | 20   |
| 994   | 1219  | Needle Set Screw for left hand needle, for<br>44-33 Machine.....          | 03   |
| 1508C | 783   | Driving Arm Friction Plug Adjusting Screw<br>Nut for 19260.....           | 06   |
| 1508C | 783   | Lever Centre Plug Adjusting Screw Nut for<br>27644.....                   | 06   |
| 1513C | 783   | Feed Lifting Rock Shaft Screw Centre Nut.                                 | 05   |
| 1513C | 783   | " Rock Shaft Screw Centre Nut.....                                        | 05   |
| 1518E | 783   | Crank Connecting Rod Hinge Screw Nut for<br>375C.....                     | 04   |
| 1518E | 783   | Feed Connecting Link Hinge Screw Nut....                                  | 04   |
| 1518E | 783   | " Forked Connection Hinge Screw Nut..                                     | 04   |
| 1518E | 783   | " Lifting Rock Shaft Crank Connecting<br>Rod Hinge Screw Nut.....         | 04   |
| 1518E | 783   | Oscillating Shaft Crank Slide Block Screw<br>Stud Nut.....                | 04   |
| 1519E | 783   | Feed Bar Screw Centre Nut.....                                            | 03   |
| 1520C | 783   | Presser Bar Lifter Hinge Screw Nut.....                                   | 03   |
| 1521E | 1222  | Lifting Lever Connecting Rod Lock Nut for<br>16512 and 19331.....         | 03   |
| 1521E | 1222  | Needle Bar Trip Lever Connection Lock Nut<br>for 44-33 Machine.....       | 03   |
| 1541E | 1222  | Tape Spool Fixture Regulating Thumb Nut<br>for 4517.....                  | 05   |
| 1547D | 1146  | Roller Arm Adjusting Screw Nut for 19211<br>to 19214.....                 | 03   |
| 1547D | 1146  | Roller Arm Bracket Screw Centre Nut for<br>19211 to 19214.....            | 03   |
| 1547D | 1146  | Tension Screw Stud Nut.....                                               | 03   |
| 1548D | 1222  | Oil Cup Nut for 19251.....                                                | 03   |
| 1548D | 1222  | Roller Screw Nut for 1839 and 1875.....                                   | 03   |
| 1549D | 1222  | " Arm Lock Spring Screw Nut for<br>19211 to 19214.....                    | 03   |
| 1550  | 783   | Bobbin Winder Stop Latch Adjusting Screw<br>Nut for 19258.....            | 03   |
| 1560C | 1146  | Tension Regulating Thumb Nut.....                                         | 04   |
| 1562D | 1222  | Bobbin Winder Tension Regulating Thumb<br>Nut for 27308.....              | 04   |
| 1579C | 783   | Driving Arm Hinge Screw Nut for 19260....                                 | 08   |
| 1607D | 1227  | Presser Foot Stop Nut for 19478.....                                      | 03   |
| 1619E | 1222  | Crank Connecting Rod Hinge Screw Nut....                                  | 05   |
| 1839  | 1210  | Roller, 1 1/2-in. diam., with 386D and 1548D, for<br>19211 and 19212..... | 40   |

## Numerical List of Parts.

| No.  | Plate | Name                                                                                    | Each |
|------|-------|-----------------------------------------------------------------------------------------|------|
| 1875 | 1210  | Roller, 1½-in. diam., with 634b and 1548b, for 19213 and 19214.....                     | 60   |
| 1902 | 783   | Oscillating Shaft Crank Roller and Screw Stud for 12390.....                            | 35   |
| 1904 | 1144  | Needle Bar Connecting Stud Roller (roller only).....                                    | 12   |
| 2018 | 1101  | Belt Guard Screw Washer for 27644.....                                                  | 01   |
| 2022 | 1220  | Driving Arm Pitman Crank Pin for 19262.....                                             | 01   |
| 2022 | 1220  | Starting Crank Pin for 19262.....                                                       | 01   |
| 2049 | 1220  | Feed Lifting Rock Shaft Crank (back) Pin.....                                           | 01   |
| 2049 | 1220  | Feed Rock Shaft Crank Pin.....                                                          | 01   |
| 2049 | 1220  | Oscillating Shaft Crank Pin.....                                                        | 01   |
| 2049 | 1220  | Shuttle Driver Pin.....                                                                 | 01   |
| 2062 | 1145  | Presser Bar Lifter.....                                                                 | 25   |
| 2106 | 1220  | Bobbin Winder Tension Thread Guide for 27308.....                                       | 01   |
| 2269 | 1146  | Bobbin Winder Stop Latch Stop Pin for 16518.....                                        | 01   |
| 2269 | 1146  | Tension Releasing Lever (intermediate) Hinge Pin.....                                   | 01   |
| 2273 | 1219  | Needle Bar Coupling Pin Lever Shaft Crank Pin for 44-33 Machine.....                    | 01   |
| 2273 | 1219  | Needle Clamp Pin.....                                                                   | 01   |
| 2415 | 1200  | Arm Spool Bracket.....                                                                  | 25   |
| 2455 | 1220  | Bobbin Winder Tension Disc for 27308.....                                               | 02   |
| 2521 | 1216  | Shuttle Bobbin Case Latch and Position Finger Spring.....                               | 02   |
| 2532 | 1220  | Shuttle Race Ring Position Pin.....                                                     | 10   |
| 2533 | 1215  | " " " Spring.....                                                                       | 15   |
| 2762 | 1206  | Treadle Stop Collar with 362, for 14233, 15130 and 27640.....                           | 10   |
| 2763 | 766   | Rock Shaft for 2777 and 4880.....                                                       | 10   |
| 2765 | 766   | " " Knee Arm for 2768.....                                                              | 10   |
| 2766 | 766   | " " " Hub with 356c, for 2768.....                                                      | 15   |
| 2767 | 766   | Rock Shaft Knee Plate with 356c, for 2768.....                                          | 18   |
| 2768 | "     | " " " Arm 2765 with 2766 and 2767, for 2777.....                                        | 40   |
| 2770 | 766   | Rock Shaft Stop Dog with 356c, for 2777 and 4880.....                                   | 12   |
| 2777 | 766   | Rock Shaft complete, No. 2763 with 2768, 2770, 2778, 6337 and two 12242, for 16512..... | 1 00 |
| 2778 | 766   | Rock Shaft Lifting Bracket Hook for 2777.....                                           | 05   |
| 2877 | 1230  | Treadle Pitman Rod (upper) for 15130.....                                               | 05   |
| 2878 | 363   | " Stand for 27642.....                                                                  | 15   |
| 2921 | 1146  | Tension Disc.....                                                                       | 05   |
| 2923 | 1146  | " Spring.....                                                                           | 03   |
| 2928 | 1207  | Driving Arm Brake (leather) for 16518.....                                              | 05   |
| 3033 | 1145  | Feed Connecting Link.....                                                               | 20   |
| 3039 | 768   | " Regulator.....                                                                        | 25   |
| 3043 | 1208  | " Rock Shaft Crank with 462c.....                                                       | 15   |

## Numerical List of Parts.

| No.   | Plate | Name                                                                                   | Each |
|-------|-------|----------------------------------------------------------------------------------------|------|
| 3094  | 1144  | Thread Take-up Crank Wedge.....                                                        | 10   |
| 4347  | 1161  | Wrench for 1513 and 1518 (A & A).....                                                  | 15   |
| 4460  | 1227  | Presser Foot Guide with 735c, for 19478.....                                           | 75   |
| 4461  | 1227  | " " Spring for 19478.....                                                              | 02   |
| 4462  | 1227  | " " " Screw Bushing for 19478.....                                                     | 15   |
| 4515  |       | Throat Plate Spring Guide for 19481.....                                               | 25   |
| 4516  |       | Tape Spool Fixture (wire) with fixed cone for 4517.....                                | 60   |
| 4517  | 1205  | Tape Spool Fixture 4516 with 1541b, 4518 and 8019 (A & A).....                         | 75   |
| 4518  | 1206  | Tape Spool Fixture Cone for 4517.....                                                  | 10   |
| 4715  |       | Spool Fixture (wire) with two 10145, for 4716.....                                     | 55   |
| 4716  | 1205  | " " 4715 with two 4717 and three 4718 (A & A).....                                     | 75   |
| 4717  |       | Spool Fixture Flange for 4716.....                                                     | 10   |
| 4718  |       | Spool Fixture Washer (felt) for 4716.....                                              | 01   |
| *4766 |       | Needle Bar Coupling for 19237 and 19466.....                                           | 30   |
| 4768  | 1219  | " " " Pin Lever for 44-33 Mach.....                                                    | 03   |
| 4777  |       | Roller Arm Bracket for 19213.....                                                      | 35   |
| 4784  | 1101  | Oscillating Rock Shaft Oil Pad.....                                                    | 01   |
| 4822  | 1207  | Wrench for 1547, 1548 and 1549 (A, and A.).....                                        | 05   |
| 4840  | 1219  | Needle Bar Spring for left hand needle, for 44-33 Machine.....                         | 02   |
| 4879  | 1203  | Chain Connecting Link for 4885.....                                                    | 03   |
| 4880  | 1231  | Rock Shaft complete for 19331.....                                                     | 1 00 |
| 4881  | 1231  | Treadle for 4885.....                                                                  | 30   |
| 4882  | 1203  | " Shaft for 4885.....                                                                  | 05   |
| 4883  | 1203  | " Spring " ".....                                                                      | 10   |
| 4884  | 1231  | " Stand " ".....                                                                       | 25   |
| 4885  | 1231  | " complete for 19331.....                                                              | 75   |
| 5596  | 768   | Bell Crank for 5598.....                                                               | 05   |
| 5596  | 768   | Needle Bar Trip Lever Bell Crank for 5598.....                                         | 05   |
| 5598  | 768   | Bell Crank 5596 with 5599, 5601 and 5602, for 16512 and 19331.....                     | 20   |
| 5598  | 768   | Needle Bar Trip Lever Bell Crank 5596 with 5599, 5601 and 5602, for 44-33 Machine..... | 20   |
| 5599  | 768   | Bell Crank Bracket for 5598.....                                                       | 08   |
| 5599  | 768   | Needle Bar Trip Lever Bell Crank Bracket for 5598.....                                 | 08   |
| 5601  | 1220  | Bell Crank Hinge Pin for 5598.....                                                     | 01   |
| 5601  | 1220  | Needle Bar Trip Lever Bell Crank Hinge Pin for 5598.....                               | 01   |
| 5602  | 1220  | Bell Crank Spring for 5598.....                                                        | 02   |
| 5602  | 1220  | Needle Bar Trip Lever Bell Crank Spring.....                                           | 02   |
| 5670  |       | Foot Lever Chain, length 26 in. to 35 in., for 19331.....                              | 15   |
| 5960  | 768   | Bobbin Winder Friction Wheel (leather) for 16515.....                                  | 10   |
| 5961  | 768   | Bobbin Winder Friction Wheel Washer for 16515.....                                     | 05   |
| 5963  | 768   | Bobbin Winder Spindle Flange for 16515.....                                            | 06   |

| No.    | Plate | Name                                                                  | Each |
|--------|-------|-----------------------------------------------------------------------|------|
| 6312   | 1219  | Needle Bar Trip Lever Connection Spring Washer for 44-33 Machine..... | 03   |
| 6337   | 766   | Rock Shaft Lifting Bracket with two 356c, for 2777 and 4880.....      | 20   |
| 7071   | 1220  | Guide Screw Washer.....                                               | 01   |
| 7071   | 1220  | Stay Guide Screw Washer (A. and A.).....                              | 01   |
| 7125   | 1231  | Rock Shaft Lifting Bracket Hook for 4880.....                         | 15   |
| 7336   | 1218  | Thread Take-up Spring Regulator.....                                  | 25   |
| 7556   | 1210  | Roller Arm Lock Spring for 19211 to 19214.....                        | 05   |
| 7958   | 1220  | Balance Wheel Friction Ring Stop Pin for 16592.....                   | 01   |
| 7958   | 1220  | Driving Pulley Screw Centre Bearing Dowel Pin for 27630.....          | 01   |
| 7958   | 1220  | Driving Pulley Friction Ring Stop Pin for 27630.....                  | 01   |
| 8019   | 1206  | Tape Spool Fixture Spring for 4517.....                               | 02   |
| 8505   | 1227  | Lap Seam Feller Holder Spring Rivet for 18118.....per 100..           | 10   |
| 8582   | 1220  | Arm Dowel Pin.....                                                    | 02   |
| 8908   | 1161  | Wrench for 1520 (A. and A.).....                                      | 10   |
| 9079   | 362   | Treadle Pitman Rod Clamp with 354c, for 14233, 15130 and 27640.....   | 12   |
| 9082   | 1101  | Treadle Bearing Cotter Pin for 27642.....                             | 01   |
| 9534   | 1219  | Needle Bar Trip Lever Connection Spring for 44-33 Machine.....        | 06   |
| 9543   | 1219  | Thread Retainer Disc for 19234.....                                   | 02   |
| 9544   | 1219  | " " " Cover for 19234.....                                            | 12   |
| 9545   | 1219  | " " " Spring " ".....                                                 | 05   |
| 10141  | 1220  | Bobbin Winder Tension Spring for 27308.....                           | 01   |
| 10145  | 1220  | Spool Fixture Thread Eyelet for 4115.....                             | 01   |
| 10236  | 1207  | Driving Friction Pulley Centre Bearing for 16594.....                 | 09   |
| 10874  | 1205  | Tweezers (A. and A.).....                                             | 10   |
| *11104 | —     | Arm Shaft Bushing (front).....                                        | 30   |
| 11119  | 1220  | " Oil Tube for oiling 19156.....                                      | 10   |
| 11167  | 1203  | Presser Bar Spring (spiral) light (.051 wire).....                    | 05   |
| 11170  | 1220  | " " " Washer.....                                                     | 01   |
| 11204  | 1144  | Thread Take-up Lever Link Hinge Pin.....                              | 15   |
| 11241  | 1203  | Arm Spool Bracket Washer (cloth).....per 100                          | 25   |
| 11241  | 1203  | Bobbin Winder Spool Washer (cloth) for 27308.....per 100..            | 25   |
| 12123  | 1201  | Feed Forked Connection for 44-32 to 44-34 Machines.....               | 60   |
| 12139  | 1203  | Presser Bar Spring (spiral) medium (.055 wire).....                   | 05   |
| 12149  | 1218  | Tension Thread Guard.....                                             | 05   |
| 12152  | 1220  | Thread Guard Rivet.....per 100..                                      | 10   |
| 12166  | 1144  | " Take-up Lever Hinge Pin.....                                        | 05   |
| 12170  | 1207  | Bobbin Winder Spring for 19260.....                                   | 03   |
| 12178  | 1101  | Driving Arm Friction Plug (wood) for 19260.....                       | 01   |

| No.    | Plate | Name                                                                             | Each |
|--------|-------|----------------------------------------------------------------------------------|------|
| 12178  | 1101  | Lever Centre Plug (wood) for 27644.....                                          | 01   |
| 12188  | 768   | Oil Cover for 19264.....                                                         | 05   |
| 12189  | 768   | Starting Crank for 19262.....                                                    | 15   |
| 12193  | 1202  | Arm Side Cover.....                                                              | 10   |
| 12197  | 1203  | Feed Cam and Feed Lifting Eccentric with 446c, for 44-32 to 44-34 Machines.....  | 50   |
| 12200  | 1208  | Feed Lifting Rock Shaft Crank (back) with 462c, for 44-35 to 44-37 Machines..... | 20   |
| *12204 | —     | Feed Lifting Rock Shaft Crank Connecting Rod Cap.....                            |      |
| 12240  | 1145  | Lifting Lever Pin for 16512 and 19331.....                                       | 05   |
| 12241  | 1145  | " " " Link " " " ".....                                                          | 10   |
| 12242  | 766   | Rock Shaft Hanger with two wood screws, 1½-in. No. 10, for 2777 and 4880.....    | 08   |
| 12243  | 1231  | Rock Shaft Lifting Bracket Hook for 4880.....                                    | 15   |
| 12326  | 1145  | Presser Bar Guide Bracket with 453c.....                                         | 25   |
| 12327  | 1145  | " " Lifting and Releasing Lever Bracket.....                                     | 50   |
| 12329  | 1145  | Tension Releasing Lever Spring.....                                              | 02   |
| 12357  | 1203  | Arm Shaft Flanged Bushing (back).....                                            | 25   |
| 12358  | —     | Balance Wheel, light rim, 2½-in. pulley, with two 448c.....                      | 75   |
| 12359  | 1200  | Balance Wheel, light rim, 3-in. pulley, with two 448c.....                       | 75   |
| 12361  | 1207  | Machine Hinge Connection for 12363.....                                          | 15   |
| 12362  | 1207  | " " Plate for 12363.....                                                         | 15   |
| 12363  | —     | " " complete, Nos. 12361, 12362 & two wood screws, 1½-in. No. 14 (A. & A.).....  | 30   |
| 12365  | 1201  | Crank Connecting Rod for 375c (obsolete).....                                    | 1 35 |
| 12382  | 1144  | Needle Bar Connecting Link with 794c.....                                        | 50   |
| 12383  | —     | " " " Stud.....                                                                  | 40   |
| 12384  | 1144  | " " " " 12383 with 453c and 1904, for 44-32 & 44-34 to 44-37 Machs.....          | 50   |
| 12385  | 1203  | Needle Bar Crank with 855c and 858c.....                                         | 80   |
| 12388  | 1203  | Oscillating Rock Shaft Hinge Pin.....                                            | 50   |
| 12390  | 1229  | " Shaft Crank 19496 with 460c, 1518c and 1902 (obsolete).....                    | 65   |
| 12391  | 1203  | Presser Bar (hollow).....                                                        | 80   |
| 12397  | 1145  | Tension Releasing Lever.....                                                     | 20   |
| 12398  | 1145  | " " " Hinge Pin.....                                                             | 01   |
| 12403  | 1220  | Arm Spool Bracket Spool Pin and Thread Eyelet.....                               | 05   |
| 12404  | 1144  | Thread Take-up Crank.....                                                        | 80   |
| 12405  | 1207  | Machine Rest, felt (A. & A.).....                                                | 02   |
| 12409  | 1144  | Thread Take-up Lever Link.....                                                   | 25   |
| 12415  | 768   | Lifting Lever Connecting Rod for 16512 and 19331.....                            | 08   |
| 12415  | 768   | Needle Bar Trip Lever Connection for 44-33 Machine.....                          | 08   |
| 12416  | 1145  | Lifting Lever Connecting Rod Joint for 16512 and 19331.....                      | 08   |



| No.    | Plate | Name                                                                                                     | Each |
|--------|-------|----------------------------------------------------------------------------------------------------------|------|
| 19133  | —     | Shuttle (outside) Bobbin Case complete, (obsolete) use 19170.....                                        | 75   |
| 19134  | 1216  | Shuttle (inside) Bobbin Case Latch and Position Finger for 19132.....                                    | 35   |
| 19135  | 1216  | Shuttle (outside) Bobbin Case Latch & Position Finger for 19170.....                                     | 35   |
| 19136  | 1216  | Shuttle (inside) Body for 19129 and 19324.....                                                           | 75   |
| 19137  | 1216  | " (outside) " " 19130 " 19325.....                                                                       | 75   |
| *19138 | —     | " Driver.....                                                                                            | 2 50 |
| 19139  | 1208  | " " 19138 with two 453e.....                                                                             | 2 50 |
| 19140  | 1211  | " Race complete for 44-32 Machine (obsolete).....                                                        | 6 00 |
| 19141  | —     | Shuttle Race Body for 19140 (obsolete).....                                                              | 1 75 |
| 19142  | 1211  | " " Ring (inside) for 19140 (obsolete).....                                                              | 1 50 |
| 19143  | 1211  | Shuttle Race Ring (outside) for 19140 (obsolete).....                                                    | 1 50 |
| 19144  | 1211  | Shuttle Race Loop Separator for 19140 (obsolete).....                                                    | 1 00 |
| 19145  | 1204  | Shuttle Race Slide (inside) for 44-32, 44-33 and 44-35 Machines.....                                     | 30   |
| 19146  | 1204  | Shuttle Race Slide (outside) for $\frac{7}{16}$ -in. gauge and below, for 44-32, 44-33 & 44-35 Mchs..... | 25   |
| 19147  | 1220  | Shuttle Race Slide Friction Spring for 19148, 19185 and 19189.....                                       | 03   |
| 19147  | 1220  | Shuttle Race Slide (outside) Friction Spring for 19322, 19191 and 19192.....                             | 03   |
| 19148  | 1204  | Shuttle Race Slide Guide with 651e & 19147, for 44-32, 44-33 and 44-35 Machines.....                     | 50   |
| 19149  | 1216  | Shuttle (inside) Tension Spring for 19132 & 19312.....                                                   | 10   |
| 19150  | —     | Shuttle (outside) Tension Spring for 19133 (obsolete) use 19172.....                                     | 10   |
| 19151  | 1229  | Tension Plate for upper tension with 19152 (obsolete).....                                               | 40   |
| 19152  | 1229  | Tension Plate Stud for 19151.....                                                                        | 10   |
| 19153  | 1229  | " (upper) complete, No. 19151 with two each 637, 1547b, 1560c, 8238 and four 2102 (obsolete).....        | 95   |
| 19154  | 1220  | Thread Guard (lower) for 19110 and 19231.....                                                            | 25   |
| 19155  | 1220  | " " (upper) " " " 19305.....                                                                             | 20   |
| 19156  | 1144  | " Take-up Lever.....                                                                                     | 30   |
| 19157  | 1144  | " " " 19156 with 12166 and 12409.....                                                                    | 65   |
| 19158  | 1218  | Thread Take-up Spring (music wire).....                                                                  | 03   |
| 19159  | 1218  | " Guide Body.....                                                                                        | 30   |
| 19160  | 1218  | " " Roller.....                                                                                          | 10   |
| 19161  | 1218  | " " Cap.....                                                                                             | 10   |
| 19162  | —     | " " complete (roller) Nos. 905b and 19159 to 19161.....                                                  | 50   |
| 19163  | 785   | Throat Plate for 19215 and 19342.....                                                                    | 1 50 |

| No.   | Plate | Name                                                                                                                                                          | Each |
|-------|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 19166 | 1203  | Oscillating Rock Shaft for 908c and 1902 (obsolete).....                                                                                                      | 1 00 |
| 19167 | —     | Oscillating Rock Shaft 19166 with 12388 (obsolete).....                                                                                                       | 1 50 |
| 19169 | 1217  | Shuttle (outside) $1\frac{1}{16}$ -in. diam., No. 19171 with 19131 and 19170, for gauges up to $\frac{13}{16}$ -in., for 44-32, 44-33 and 44-35 Machines..... | 1 50 |
| 19170 | 1216  | Shuttle (outside) Bobbin Case complete for 19130 and 19169.....                                                                                               | 75   |
| 19171 | 1217  | Shuttle (outside) Body for 19169 and 19326.....                                                                                                               | 75   |
| 19172 | 1216  | " " Tension Spring for 19170 and 19313.....                                                                                                                   | 10   |
| 19183 | 787   | Feed Dog with 19118, for $\frac{1}{8}$ -in. to $\frac{3}{16}$ -in. gauge, for shoe staying, for 44-32 and 44-33 Mchs.....                                     | 1 50 |
| 19184 | 787   | Throat Plate for 19183.....                                                                                                                                   | 1 50 |
| 19185 | 1204  | Shuttle Race Slide Guide with 651e and 19147, for 19230 and 26268, for 44-32 and 44-33 Machines.....                                                          | 50   |
| 19186 | 1223  | Presser Foot (long toe) for inside stays, for 44-32 and 44-34 Machines.....                                                                                   | 1 50 |
| 19189 | 1204  | Shuttle Race Slide Guide with 651e & 19147, for 26272 and 26397 (A. & A.).....                                                                                | 75   |
| 19190 | 785   | Throat Plate for 19340.....                                                                                                                                   | 1 50 |
| 19191 | 1146  | Tension Plate for upper tension, with 19231.....                                                                                                              | 50   |
| 19192 | 1146  | " Releaser.....                                                                                                                                               | 15   |
| 19193 | 1146  | " Releasing Lever (intermediate).....                                                                                                                         | 10   |
| 19194 | 1146  | " " " " Spring.....                                                                                                                                           | 03   |
| 19195 | 1146  | Tension (upper) complete with Tension Release.....                                                                                                            | 1 50 |
| 19196 | —     | Roller Arm for 19211.....                                                                                                                                     | 20   |
| 19197 | —     | " " " 19212.....                                                                                                                                              | 20   |
| 19198 | —     | " " " 19213.....                                                                                                                                              | 20   |
| 19199 | —     | " " " 19214.....                                                                                                                                              | 20   |
| 19200 | —     | " " Bracket for 19212 and 19214.....                                                                                                                          | 30   |
| 19201 | 1210  | " Needle Guard (flat) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge, for 19211.....                                                                        | 40   |
| 19204 | 1210  | Roller Needle Guard (flat) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge, for 19213.....                                                                   | 40   |
| 19207 | 1210  | Roller Needle Guard (round) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge, for 19211.....                                                                  | 45   |
| 19208 | 1210  | Roller Needle Guard (round) $\frac{1}{32}$ -in. to $\frac{1}{8}$ -in. gauge, for 19212 and 19214.....                                                         | 45   |
| 19209 | 1210  | Roller Needle Guard (round) $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge, for 19213.....                                                                  | 45   |
| 19211 | 1209  | Roller Presser complete, $1\frac{1}{8}$ -in. roller, for $\frac{1}{32}$ -in. to $\frac{1}{16}$ -in. gauge, for 44-32 and 44-34 Machines.....                  | 2 05 |
| 19212 | 1209  | Roller Presser complete, $1\frac{1}{8}$ -in. roller, for $\frac{3}{32}$ -in. to $\frac{1}{8}$ -in. gauge, for 44-32 and 44-34 Machines.....                   | 1 65 |

## Numerical List of Parts.

| No.    | Plate | Name                                                                                                                                     | Each |
|--------|-------|------------------------------------------------------------------------------------------------------------------------------------------|------|
| 19213  | 1209  | Roller Presser complete, $\frac{1}{2}$ -in. roller, for $\frac{3}{8}$ -in. to $\frac{1}{4}$ -in. gauge, for 44-32 to 44-34 Machines..... | 2 25 |
| 19214  | 1209  | Roller Presser complete, $\frac{1}{2}$ -in. roller, for $\frac{3}{8}$ -in. to $\frac{1}{4}$ -in. gauge, for 44-32 to 44-34 Machines..... | 1 85 |
| 19215  | 1228  | Guide for collars and cuffs, for 44-35 and 44-36 Machines.....                                                                           | 30   |
| 19216  | 1225  | Presser Foot with 228b, for strip gauge, for 44-35 and 44-36 Machines.....                                                               | 1 00 |
| 19219  | 1206  | Bed Frame Cushion (leather) for 19399.....                                                                                               | 05   |
| 19220  | 1206  | " " " Spring " " ".....                                                                                                                  | 05   |
| 19221  | 1161  | Wrench for 936 and 1619 (A. & A.).....                                                                                                   | 15   |
| 19226  | 1206  | Bed Frame Hinge Connection for 19398.....                                                                                                | 15   |
| 19230  | 1228  | Guide for 44-32 and 44-33 Machines.....                                                                                                  | 15   |
| 19231  | 1146  | Tension Releasing Lever (intermediate) Hinge Block for 19191.....                                                                        |      |
| *19232 | -     | Arm for 44-33 Machine.....                                                                                                               | 4 25 |
| 19233  |       | Face Plate.....                                                                                                                          | 75   |
| 19234  | 1202  | " " 19233 complete for 44-33 Machine.....                                                                                                | 1 25 |
| 19235  | 787   | Feed Dog with 19118, for 44-33 Machine (obsolete).....                                                                                   | 1 25 |
| 19236  | -     | Feed Lifting Rock Shaft 16504 with 16556 and 19120, for 44-32 to 44-34 Machines.....                                                     | 1 65 |
| *19237 | ----- | Needle Bar for right hand needle with 4766, for 19248 (obsolete).....                                                                    | ---  |
| *19238 | ----- | Needle Bar for left hand needle for 19248 (obsolete).....                                                                                | ---  |
| 19239  | ---   | Needle Bar Connecting Stud for 19240.....                                                                                                | 40   |
| 19240  | 1219  | " " " " 19239 with 1904, for 44-33 Machine.....                                                                                          | 50   |
| 19241  | 1229  | Needle Bar Coupling Pin for 19248 (obsolete).....                                                                                        | 10   |
| 19242  | 1229  | Needle Bar Coupling Pin Lever Bell Crank with 19244, for 44-33 Machine (obsolete).....                                                   | 50   |
| 19243  | 1229  | Needle Bar Coupling Pin Lever Bell Crank Bracket for 44-33 Machine (obsolete).....                                                       | 2 00 |
| 19244  | 1220  | Needle Bar Coupling Pin Lever Bell Crank Washer for 19242 (obsolete).....                                                                | 01   |
| 19245  | 1229  | Needle Bar Coupling Pin Lever Hub for 44-33 Machine (obsolete).....                                                                      | 20   |
| 19246  | 1219  | Needle Bar Coupling Pin Rest for 44-33 Machine.....                                                                                      | 05   |
| 19247  | 1219  | " " Spring Collar for 44-33 Machine.....                                                                                                 | 15   |
| 19248  | ---   | " " complete, for 44-33 Machine (obsolete) use 19458.....                                                                                | 5 00 |
| 19249  | 1229  | Needle Clamp for left hand needle with 19250, for 19248 (obsolete).....                                                                  | 1 25 |
| 19250  | 1229  | Needle Clamp Thread Guard for 19249 (obsolete).....                                                                                      | 02   |
| 19251  | 1229  | Oil Cup with 12486, for 19253 (obsolete).....                                                                                            | 20   |
| 19252  | 1229  | " " Extension for 19253 " ".....                                                                                                         | 07   |
| 19253  | ---   | " " complete, Nos. 1548b, 19251 and 19252 (obsolete).....                                                                                | 30   |

## Numerical List of Parts.

| No.    | Plate | Name                                                                                                               | Each |
|--------|-------|--------------------------------------------------------------------------------------------------------------------|------|
| 19254  | 787   | Throat Plate for 19235 (obsolete).....                                                                             | 1 25 |
| 19255  | 1201  | Needle Bar Trip Lever for 44-33 Machine.....                                                                       | 35   |
| 19256  | 1219  | " " " " Connection Spring Collar with 187, for 44-33 Machine.....                                                  | 17   |
| 19257  | ---   | Needle Bar Trip Lever Pitman for 44-33 Machine (obsolete).....                                                     | 50   |
| 19258  | 1207  | Bobbin Winder Stop Latch with 152 & 1550, for 19260.....                                                           | 50   |
| 19259  | 1201  | Driving Arm Pitman Crank for 19262.....                                                                            | 15   |
| 19260  | "     | " " complete, for 19264.....                                                                                       | 3 00 |
| 19261  | 1201  | Starting Crank Shaft Bracket for 19262.....                                                                        | 35   |
| 19262  | "     | " " " " complete for 19264.....                                                                                    | 1 00 |
| 19263  | 1207  | Starting Crank Shaft Stop Collar with 362, for 19262.....                                                          | 10   |
| 19264  |       | Driving Attachment complete.....                                                                                   | 5 00 |
| 19274  | 788   | Feed Dog with 19118, for $\frac{1}{8}$ -in. to $\frac{3}{16}$ -in. gauge, for lap seam feller, for 44-35 Mach..... | 1 50 |
| 19275  | 1203  | Feed and Feed Lifting Eccentric with 4460, for 44-35 Machine.....                                                  | 50   |
| 19276  | 1218  | Needle Clamp with two 209, for $\frac{7}{8}$ -in. gauge and above, for 44-35 to 44-37 Machines.....                | 1 25 |
| 19277  |       | Shuttle Race Body for 19282.....                                                                                   | 1 75 |
| 19278  | 1212  | " " Loop Separator for 19282.....                                                                                  | 1 50 |
| 19279  | 1212  | " " Ring (inside) " ".....                                                                                         | 1 50 |
| 19280  | 1212  | " " " (outside) " ".....                                                                                           | 1 50 |
| 19281  | 1204  | " " Slide " " $\frac{1}{2}$ -in. to $\frac{3}{8}$ -in. gauge, for 44-35 Machine.....                               | 25   |
| 19282  | 1212  | Shuttle Race complete for 44-32, 44-33 and 44-35 Machines.....                                                     | 6 00 |
| 19283  | 788   | Throat Plate for 19274.....                                                                                        | 1 50 |
| 19287  | 786   | " " " 19338.....                                                                                                   | 1 50 |
| 19288  | 786   | " " " 19339.....                                                                                                   | 1 50 |
| 19289  | 788   | " " " 19344.....                                                                                                   | 1 50 |
| 19290  | 789   | " " " 19343.....                                                                                                   | 1 50 |
| 19291  | 789   | " " " 19341.....                                                                                                   | 1 50 |
| 19294  | 1226  | Lap Seam Feller Folder Slide Spring (A. & A.).....                                                                 | 05   |
| 19295  | 790   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{3}{4}$ -in. gauge, for vamping, for 44-32 Machine.....       | 1 25 |
| 19296  | 790   | Throat Plate with Loop Separator (solid) for 19295.....                                                            | 1 50 |
| *19303 |       | Bed for 44-34 and 44-36 Machines.....                                                                              | 4 50 |
| 19304  |       | Face Plate.....                                                                                                    | 50   |
| 19305  | 1202  | " " 19304 complete, for 44-34, 44-36 and 44-37 Machines.....                                                       | 1 00 |
| 19306  | 790   | Feed Dog with 19118, $\frac{1}{2}$ -in. to $\frac{3}{8}$ -in. gauge, for vamping, for 44-34 Machine.....           | 1 25 |
| 19307  |       | Feed and Feed Lifting Eccentric with 4460, for 44-36 Machine (obsolete).....                                       | 50   |
| 19308  | 1218  | Needle Clamp with 209 and 460, for $\frac{7}{8}$ -in. gauge and above, for 44-32 and 44-34 Mchs.....               | 1 25 |

| No.   | Plate | Name                                                                                                                                                                   | Each |
|-------|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 19309 | 1213  | Shuttle Race Needle Guard for 19323 and 24013.....                                                                                                                     | 25   |
| 19310 | 1217  | Shuttle (inside) Bobbin Case Latch and Position Finger for 19313.....                                                                                                  | 35   |
| 19311 | 1217  | Shuttle (outside) Bobbin Case Latch and Position Finger for 19313.....                                                                                                 | 35   |
| 19312 | 1217  | Shuttle (inside) Bobbin Case complete for 19324.....                                                                                                                   | 75   |
| 19313 | 1217  | Shuttle (outside) Bobbin Case complete for 19325 and 19326.....                                                                                                        | 75   |
| 19314 | -     | Shuttle (outside) Bobbin Case complete (obsolete) use 19313.....                                                                                                       | 75   |
| 19315 | -     | Shuttle Race Body for 19323 and 24013.....                                                                                                                             | 1 75 |
| 19316 | 1213  | " " Loop Separator for 19323.....                                                                                                                                      | 15   |
| 19317 | 1213  | " " Ring (inside) " 19309, 19323 and 24013.....                                                                                                                        | 1 50 |
| 19318 | 1213  | Shuttle Race Ring (outside) for 19323, 24013 and 24014.....                                                                                                            | 1 50 |
| 19319 | 1204  | Shuttle Race Slide (inside) for 44-34, 44-36 and 44-37 Machines.....                                                                                                   | 35   |
| 19320 | 1220  | Shuttle Race Slide (inside) Stop Stud for 44-34, 44-36 and 44-37 Machines.....                                                                                         | 05   |
| 19321 | 1220  | Shuttle Race Slide (inside) Stop Stud Spring for 44-34, 44-36 and 44-37 Machines.....                                                                                  | 02   |
| 19322 | 1204  | Shuttle Race Slide (outside) with 662E and 19147, for $\frac{7}{16}$ -in. gauge and below, for 44-34, 44-36 and 44-37 Machines.....                                    | 30   |
| 19323 | 1213  | Shuttle Race complete, for $\frac{3}{8}$ -in. to $\frac{3}{16}$ -in. gauge, for 44-36 and 44-37 Machines.....                                                          | 5 00 |
| 19324 | 1217  | Shuttle (inside) $1\frac{1}{16}$ -in. diam., No. 19136 with 19131 and 19312, for 44-34, 44-36 and 44-37 Machines.....                                                  | 1 50 |
| 19325 | 1217  | Shuttle (outside) $1\frac{1}{16}$ -in. diam., No. 19137 with 19131 and 19313, for $\frac{7}{16}$ -in. gauge and above, for 44-34, 44-36 and 44-37 Machines.....        | 1 50 |
| 19326 | 1217  | Shuttle (outside) $1\frac{1}{16}$ -in. diam., No. 19171 with 19131 and 19313, for $\frac{1}{2}$ -in. to $\frac{13}{16}$ -in. gauge, for 44-34, 44-36 and 44-37 Mch.... | 1 50 |
| 19327 | 1220  | Thread Guard (lower) for 19305.....                                                                                                                                    | 25   |
| 19329 | 791   | Feed Dog with 19118, for 44-37 Machine....                                                                                                                             | 1 50 |
| 19330 | 791   | Throat Plate for 19329.....                                                                                                                                            | 1 50 |
| 19331 | -     | Foot Lifter complete.....                                                                                                                                              | 2 85 |
| 19333 | 1223  | Presser Foot for inside stays, for 44-32 and 44-34 Machines.....                                                                                                       | 1 50 |
| 19337 | 1219  | Thread Retainer Thread Guard for 19234....                                                                                                                             | 05   |
| 19338 | 786   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{3}{8}$ -in. gauge, for general work, for 44-35 Mach. 1 50                                                       |      |
| 19339 | 786   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{5}{16}$ -in. gauge, for general work, for 44-35 Mch. 1 50                                                       |      |
| 19340 | 785   | Feed Dog with 19118, for $\frac{3}{16}$ -in. to $\frac{1}{2}$ -in. gauge, for lap seam feller, for 44-35 Mach 1 50                                                     |      |

| No.   | Plate | Name                                                                                                                            | Each |
|-------|-------|---------------------------------------------------------------------------------------------------------------------------------|------|
| 19341 | 789   | Feed Dog with 19118, for $\frac{1}{4}$ -in. to $\frac{1}{2}$ -in gauge, for knit goods and general work, for 44-35 Machine..... | 1 50 |
| 19342 | 785   | Feed Dog with 19118, for $\frac{1}{4}$ -in. to $\frac{3}{8}$ -in. gauge, for collars and cuffs, for 44-35 Machine.....          | 1 50 |
| 19343 | 789   | Feed Dog with 19118, for $\frac{1}{4}$ -in. to $\frac{7}{16}$ -in. gauge, for general work, for 44-35 Mach.....                 | 1 50 |
| 19344 | 788   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{3}{16}$ -in. gauge, for lap seam feller, for 44-35 Mach.....              | 1 50 |
| 19378 | 790   | Throat Plate Loop Separator for 19384 (obsolete).....                                                                           | 1 00 |
| 19379 |       | Shuttle Race Body for 19382 and 24014.....                                                                                      | 1 75 |
| 19380 | 1214  | " " Ring (inside) for 19382 & 24014.....                                                                                        | 1 50 |
| 19381 | 1214  | " " " (outside) " 19382.....                                                                                                    | 1 50 |
| 19382 | 1214  | " " complete, for $\frac{1}{4}$ -in. to $\frac{5}{16}$ -in. gauge, for 44-34, 44-36 and 44-37 Machs.....                        | 5 00 |
| 19383 |       | Throat Plate Body for 19384 (obsolete).....                                                                                     | 1 25 |
| 19384 | 790   | " " complete, Nos. 219, 19378 and 19383 (obsolete) use 20128.....                                                               | 2 25 |
| 19385 | 1204  | Shuttle Race Slide (outside) for $\frac{3}{16}$ -in. to $1\frac{1}{4}$ -in. gauge, for 44-35 Machine.....                       | 25   |
| 19386 | 1203  | Oscillating Rock Shaft.....                                                                                                     | 1 00 |
| 19387 |       | " " " 19386 with 4784 and 12388.....                                                                                            | 1 50 |
| 19388 | 1208  | Oscillating Shaft Crank 19496 with 460c, 1518g and 19390.....                                                                   | 80   |
| 19389 | 1208  | Oscillating Shaft Crank Slide Block.....                                                                                        | 35   |
| 19390 | 1208  | " " " " " 19389 with 2290, 969c and 12424.....                                                                                  | 50   |
| 19395 | 791   | Feed Dog with 19118, for general work, for 44-37 Machine.....                                                                   | 1 50 |
| 19396 | 791   | Throat Plate for 19395.....                                                                                                     | 1 50 |
| 19397 | 1206  | Bed Frame Hinge Connection Cap for 19398, 19398                                                                                 | 03   |
| 19398 |       | " " " " 19226 with 211 and 19397, for 19399.....                                                                                | 20   |
| 19399 | 1231  | Bed Frame complete.....                                                                                                         | 2 35 |
| 19450 | 792   | Feed Dog with 19118, for 44-36 Machine....                                                                                      | 1 50 |
| 19451 | 792   | Throat Plate for 19450.....                                                                                                     | 1 50 |
| 19452 | 1219  | Needle Bar Coupling Pin for 44-33 Machine.....                                                                                  | 10   |
| 19453 | 1219  | " " " " Lever Hub with 207, for 44-33 Machine.....                                                                              | 20   |
| 19454 | 1219  | Needle Bar Coupling Pin Lever Shaft for 44-33 Machine.....                                                                      | 05   |
| 19455 | 1219  | Needle Bar Coupling Pin Lever Shaft Bracket for 44-33 Machine.....                                                              | 2 00 |
| 19456 | 1219  | Needle Bar Coupling Pin Lever Shaft Crank for 19457.....                                                                        | 20   |
| 19457 | -     | Needle Bar Coupling Pin Lever Shaft 19454 with 2273 and 19456, for 44-33 Machine..                                              | 25   |
| 19458 | 1205  | Needle Bar complete, for $\frac{3}{16}$ -in. to $\frac{3}{4}$ -in. gauge, for 44-33 Machine.....                                | 5 00 |

| No.    | Plate | Name                                                                                                                                           | Each |
|--------|-------|------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 19459  | 1219  | Needle Clamp for left hand needle with 468, 994 and 19461, for $\frac{3}{8}$ -in. to $\frac{5}{8}$ -in. gauge, for 44-33 Machine.....          | 1 25 |
| 19460  | 1219  | Needle Bar Thread Guide for 19458, 24017 and 24018.....                                                                                        | 20   |
| 19461  | 1219  | Needle Clamp Thread Guide for 19459 and 24015.....                                                                                             | 01   |
| 19462  | 1203  | Needle Bar Trip Lever Pitman for 44-33 Machine.....                                                                                            | 50   |
| *19465 | ----  | Needle Bar for right hand needle with 620, for 44-33 Machine.....                                                                              | —    |
| *19466 | ----  | Needle Bar for left hand needle with 4766, for 44-33 Machine.....                                                                              | —    |
| 19468  | 792   | Feed Dog with 19118, for general work, for 44-37 Machine.....                                                                                  | 1 50 |
| 19469  | 792   | Throat Plate for 19468.....                                                                                                                    | 1 50 |
| 19470  | 793   | Feed Dog with 19118, $\frac{3}{8}$ -in. to $\frac{3}{4}$ -in. gauge, for shoe staying, for 44-34 Machine.....                                  | 1 50 |
| 19471  | 793   | Throat Plate for 19470.....                                                                                                                    | 1 50 |
| 19476  | 1227  | Presser Foot for 19478.....                                                                                                                    | 2 50 |
| 19477  | 1227  | " " Bracket with 465c, for 19478.....                                                                                                          | 1 60 |
| 19478  | 1227  | " " complete (spring presser) Nos. 1607b, 4460 to 4462, 19476 and 19477, for 44-32 and 44-34 Machines.....                                     | 5 00 |
| 19479  | 793   | Feed Dog with 19118, for staying overgaiters, for 44-35 Machine.....                                                                           | 1 50 |
| 19480  | 1223  | Presser Foot for staying overgaiters, for 44-35 Machine.....                                                                                   | 1 50 |
| 19481  | 793   | Throat Plate with 4515, for 19479.....                                                                                                         | 1 50 |
| 19482  | 794   | Feed Dog with 19118, for rounding overgaiters, for 44-35 Machine.....                                                                          | 1 50 |
| 19483  | 1223  | Presser Foot for rounding overgaiters, for 44-35 Machine.....                                                                                  | 1 50 |
| 19484  | 794   | Throat Plate with 240b, 19485 and 19486, for 19482.....                                                                                        | 2 50 |
| 19485  | ----  | Throat Plate Arm for 19484.....                                                                                                                | 15   |
| 19486  | ----  | Throat Plate Spring Guide for 19484.....                                                                                                       | 50   |
| 19491  | 1202  | Shuttle Race Slide (outside) with 662e and 19147, for $\frac{1}{2}$ -in. to $\frac{1}{4}$ -in. gauge, for 44-34, 44-36 and 44-37 Machines..... | 30   |
| 19492  | 1202  | Shuttle Race Slide (outside) with 662e and 19147, for $\frac{3}{4}$ -in. to 1-in. gauge, for 44-34, 44-36 and 44-37 Machines.....              | 30   |
| 19494  | 794   | Feed Dog with 19118, for knit goods and general work, for 44-37 Machine.....                                                                   | 1 50 |
| 19495  | 794   | Throat Plate for 19494.....                                                                                                                    | 1 50 |
| 19496  | ----  | Oscillating Shaft Crank.....                                                                                                                   | 25   |
| 20023  | 1203  | Presser Bar Spring (spiral) heavy (.063 wire).....                                                                                             | 05   |
| 20044  | ----  | " Foot Plate for 20045.....                                                                                                                    | 1 00 |
| 20045  | 1223  | " " (hinged) Nos. 20044, 26275 and 26276, for 44-35 and 44-37 Machines.....                                                                    | 1 75 |

| No.   | Plate | Name                                                                                                                                                             | Each |
|-------|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 20046 | 1223  | Presser Foot (tube) for 44-35 Machine.....                                                                                                                       | 2 00 |
| 20047 | ----  | " " Plate for 20049.....                                                                                                                                         | 2 00 |
| 20048 | ----  | " " Shank " ".....                                                                                                                                               | 15   |
| 20049 | 1224  | " " (tube) hinged, Nos. 20047, 20048, 26231 and 26276, for 44-35 Machine.....                                                                                    | 2 75 |
| 20050 | 1224  | Presser Foot (tube) for taping, for 44-35 Mach.....                                                                                                              | 2 00 |
| 20051 | 1223  | " " with keel, slotted for tape, for staying, for 44-32 and 44-34 Machines.....                                                                                  | 1 75 |
| 20052 | 1224  | Presser Foot, for outside stays and strips, for 44-35 Machine.....                                                                                               | 1 50 |
| 20053 | 1224  | Presser Foot (strip) for boning, for 44-35 Machine.....                                                                                                          | 1 75 |
| 20055 | 795   | Feed Dog with 19118, for general work, for 44-37 Machine.....                                                                                                    | 1 50 |
| 20056 | 795   | Throat Plate for 20055.....                                                                                                                                      | 1 50 |
| 20068 | 795   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{7}{8}$ -in. gauge, for boning and corset strip, for 44-35 Machine.....                                     | 1 50 |
| 20069 | 795   | Throat Plate for 20068.....                                                                                                                                      | 1 50 |
| 20070 | 796   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{3}{4}$ -in. gauge, one long and one short row of teeth, for vamping, for 44-33 Machine.....                | 1 50 |
| 20071 | 796   | Throat Plate for 20070.....                                                                                                                                      | 1 50 |
| 20072 | 796   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{1}{2}$ -in. gauge, two long rows of teeth, for 44-35 Machine.....                                          | 1 50 |
| 20073 | 796   | Throat Plate for 20072.....                                                                                                                                      | 1 50 |
| 20074 | 797   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{1}{4}$ -in. gauge, for knit goods and general work, for 44-35 Machine.....                                 | 1 50 |
| 20075 | 797   | Throat Plate for 20074.....                                                                                                                                      | 1 50 |
| 20076 | 797   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{1}{4}$ -in. gauge, two long and two short rows of teeth, for heavy lap seam feller, for 44-35 Machine..... | 1 50 |
| 20077 | 797   | Throat Plate for 20076.....                                                                                                                                      | 1 50 |
| 20080 | 798   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{3}{4}$ -in. gauge (used with 19478) for 44-32 Machine.....                                                 | 1 50 |
| 20081 | 798   | Throat Plate for 20080.....                                                                                                                                      | 1 50 |
| 20082 | 798   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{3}{4}$ -in. gauge, for collars & cuffs, for 44-35 Mach.....                                                | 1 50 |
| 20083 | 798   | Throat Plate for 20082.....                                                                                                                                      | 1 50 |
| 20084 | 799   | Feed Dog with 19118, for $\frac{3}{4}$ -in. to 1-in. gauge, three long and two short rows of teeth, for general work, for 44-35 Machine.....                     | 1 50 |
| 20085 | 799   | Throat Plate for 20084.....                                                                                                                                      | 1 50 |
| 20086 | 799   | Feed Dog with 19118, for $\frac{3}{8}$ -in. to $\frac{5}{8}$ -in. gauge, for heavy bolting cloth, for 44-35 Machine.....                                         | 1 50 |
| 20087 | 799   | Throat Plate for 20086.....                                                                                                                                      | 1 50 |
| 20088 | 800   | Feed Dog with 19118, for $\frac{3}{4}$ -in. to 1-in. gauge, three long and two short rows of teeth, for heavy lap seam feller, for 44-35 Mach.....               | 1 75 |

## Numerical List of Parts.

| No.    | Plate | Name                                                                                                                                          | Each |
|--------|-------|-----------------------------------------------------------------------------------------------------------------------------------------------|------|
| 20089  | 800   | Throat Plate for 20088.....                                                                                                                   | 1 50 |
| 20103  | 800   | Feed Dog with 19118, for $\frac{3}{32}$ -in. to $\frac{1}{4}$ -in. gauge,<br>for lap seam feller, for 44-35 Machine....                       | 1 50 |
| 20104  | 800   | Throat Plate for 20103.....                                                                                                                   | 1 50 |
| 20108  | 801   | Feed Dog (spiked teeth) with 19118, for $\frac{3}{32}$ -in.<br>to $\frac{1}{4}$ -in. gauge, for collars and cuffs, for<br>44-35 Machine.....  | 1 50 |
| 20109  | 801   | Throat Plate for 20108.....                                                                                                                   | 1 50 |
| 20110  | 801   | Feed Dog (spiked teeth) with 19118, for $\frac{3}{32}$ -in.<br>to $\frac{1}{4}$ -in. gauge, for 44-36 Machine.....                            | 1 50 |
| 20111  | 801   | Throat Plate for 20110.....                                                                                                                   | 1 50 |
| 20112  | 1225  | Presser Foot with 228p, for 20108, 20110 and<br>25967, for 44-35 and 44-36 Machines.....                                                      | 1 00 |
| 20121  | 802   | Feed Dog with 19118, for $\frac{3}{32}$ -in. to $\frac{1}{4}$ -in.<br>gauge, for general work, for 44-37 Mach. ....                           | 1 50 |
| 20122  | 802   | Throat Plate for 20121.....                                                                                                                   | 1 50 |
| 20126  | —     | “ “ Body for 20128.....                                                                                                                       | 1 00 |
| 20127  | 802   | “ “ Loop Separator for 20128.....                                                                                                             | 1 25 |
| 20128  | 802   | “ “ complete, Nos. 219, 20126 and<br>20127, for 19306.....                                                                                    | 2 25 |
| 24013  | 1215  | Shuttle Race complete, for $\frac{13}{16}$ -in. gauge and<br>above, for 44-34, 44-36 and 44-37 Machines ..                                    | 5 00 |
| 24014  | 1215  | Shuttle Race complete, for $\frac{3}{32}$ -in. to $\frac{5}{16}$ -in.<br>gauge, for vamping, for 44-34 Machine....                            | 5 00 |
| *24015 | —     | Needle Clamp, for left hand needle, with 468,<br>620, 994 and 19461, for $\frac{3}{32}$ -in. to $\frac{13}{16}$ -in.<br>gauge, for 24017..... | 1 25 |
| 24016  | —     | Needle Clamp, for left hand needle, with two<br>620, for $\frac{3}{32}$ -in. gauge and above, for 24018 ..                                    | 1 25 |
| 24017  | —     | Needle Bar complete, for $\frac{3}{32}$ -in. to $\frac{13}{16}$ -in.<br>gauge, for 44-33 Machine.....                                         | 5 00 |
| 24018  | —     | Needle Bar complete, for $\frac{3}{32}$ -in. gauge and<br>above, for 44-33 Machine.....                                                       | 5 00 |
| 24020  | 1206  | Oil Cup.....                                                                                                                                  | 20   |
| 24021  | 1206  | “ “ Extension.....                                                                                                                            | 05   |
| 24022  | 1206  | “ “ complete, Nos. 12186, 24020 and 24021,<br>for 44-32 to 44-34 Machines.....                                                                | 25   |
| *24076 | —     | Bed for 44-37 Machine.....                                                                                                                    | 4 50 |
| 24077  | 1227  | Folder Holder Seat Cover for 44-37 Machine....                                                                                                | 15   |
| 24079  | —     | Drip Pan with four 1-in. wire nails.....                                                                                                      | 25   |
| 25955  | 1161  | Oiler with 25956 (A. & A.).....                                                                                                               | 15   |
| 25956  | 1161  | “ Spout, 8 $\frac{1}{2}$ -in. long (A. & A.).....                                                                                             | 07   |
| 25967  | 1225  | Presser Foot Strip Gauge (A. & A.).....                                                                                                       | 15   |
| 26026  | 1161  | Screw Driver (machine) (A. & A.).....                                                                                                         | 10   |
| 26027  | 1161  | “ “ (shuttle tension) (A. & A.)....                                                                                                           | 05   |
| 26041  | 1205  | Spool Holder Bracket with 219 and 287p, for<br>26043.....                                                                                     | 15   |
| 26042  | 1205  | Spool Holder Spindle with Disc, for 26043..                                                                                                   | 30   |
| 26043  | 1205  | “ “ (disc) complete, Nos. 26041 and<br>26042 (A. & A.).....                                                                                   | 50   |
| 26061  | 989   | Tape Holder Bracket Wire with Disc, for 26063                                                                                                 | 20   |
| 26062  | 989   | “ “ Disc (adjustable) with 286p, for<br>26063.....                                                                                            | 30   |

## Numerical List of Parts.

| No.   | Plate | Name                                                                                    | Each |
|-------|-------|-----------------------------------------------------------------------------------------|------|
| 26063 | 989   | Tape Holder (8-in. disc) complete, Nos. 26061<br>and 26062, for 26065.....              | 50   |
| 26064 | 1200  | Tape Holder Foot with 736p, for 26343.....                                              | 20   |
| 26065 | —     | “ “ 26063 with 26325 (A. & A.)....                                                      | 70   |
| 26066 | 989   | “ “ Bracket Wire for 26067.....                                                         | —    |
| 26067 | —     | “ “ “ “ 26066 with 26068<br>and 26072, for 26074.....                                   | 60   |
| 26068 | 989   | Tape Holder Disc for 26071.....                                                         | —    |
| 26069 | 989   | “ “ “ Hub for 26071.....                                                                | —    |
| 26070 | —     | “ “ “ “ Rivet for 26071.....                                                            | —    |
| 26071 | —     | “ “ “ “ 26068 with 26069 and three<br>26070, for 26074.....                             | 40   |
| 26072 | 989   | Tape Holder Tape Guide for 26074.....                                                   | —    |
| 26073 | 1206  | “ “ Tension Adjusting Collar with<br>286p, for 26074.....                               | 15   |
| 26074 | 989   | Tape Holder (10-in. disc) complete, Nos.<br>13211, 26067 and 26071, for 26343.....      | 1 25 |
| 26234 | 1220  | Presser Foot Spring for 20049.....                                                      | 02   |
| 26266 | 1228  | Stay Guide Plate (lower) for 26268.....                                                 | 20   |
| 26267 | 1228  | “ “ “ (upper) “ “ ..                                                                    | 20   |
| 26268 | —     | “ “ complete, Nos. 26266 and 26267<br>(A. & A.).....                                    | 40   |
| 26269 | —     | Lap Seam Feller Folder for 26272.....                                                   | 3 25 |
| 26272 | 1226  | “ “ “ (right hand) complete, Nos.<br>18114 and 26269 (A. & A.).....                     | 3 40 |
| 26273 | 1223  | Presser Foot (hinged) for light lap seam fel-<br>ler (A. & A.).....                     | 2 00 |
| 26274 | —     | Presser Foot Plate for 26273.....                                                       | 1 25 |
| 26275 | —     | “ “ Shank “ 20045, 26273, 26329,<br>26406, 26410 and 26418. ....                        | 75   |
| 26276 | 1220  | Presser Foot Hinge Pin for 20045, 20049,<br>26273, 26329, 26383, 26406, 26410 and 26418 | 01   |
| 26279 | —     | Presser Foot Extension, $\frac{1}{16}$ -in., for 19216<br>(A. & A.).....                | 15   |
| 26280 | 1225  | Presser Foot Extension, $\frac{1}{8}$ -in., for 19216<br>(A. & A.).....                 | 15   |
| 26281 | —     | Presser Foot Extension, $\frac{1}{4}$ -in., for 19216<br>(A. & A.).....                 | 15   |
| 26282 | —     | Presser Foot Extension, $\frac{3}{8}$ -in., for 19216<br>(A. & A.).....                 | 15   |
| 26283 | —     | Presser Foot Extension, $\frac{1}{2}$ -in., for 19216<br>(A. & A.).....                 | 15   |
| 26325 | 1200  | Tape Holder Foot with 736p, for 26065.....                                              | 20   |
| 26329 | 1226  | Presser Foot (hinged) for medium or heavy<br>lap seam feller (A. & A.).....             | 2 50 |
| 26330 | —     | Presser Foot Plate for 26329.....                                                       | 1 75 |
| 26343 | —     | Tape Holder 26074 with 26064 (A. & A.)....                                              | 1 45 |
| 26382 | —     | Presser Foot Plate for 26383.....                                                       | 1 75 |
| 26383 | 1226  | “ “ (hinged) for X heavy, XX heavy<br>and XXX heavy lap seam feller.....                | 2 50 |
| 26395 | —     | Presser Foot Shank for 26383.....                                                       | 75   |

| No.    | Plate | Name                                                                                                                               | Each |
|--------|-------|------------------------------------------------------------------------------------------------------------------------------------|------|
| *26396 | —     | Folder for 26397.....                                                                                                              | 3 25 |
| 26397  | 1226  | Lap Seam Feller (left hand) complete, Nos.<br>18114 and 26396 (A & A).....                                                         | 3 40 |
| 26404  | 1224  | Presser Foot (tube) for reeding (A & A)....                                                                                        | 2 50 |
| 26405  | —     | “ “ Plate for 26406.....                                                                                                           | 2 50 |
| 26406  | 1224  | “ “ (tube) hinged, for reeding (A<br>& A).....                                                                                     | 3 25 |
| 26407  | 1224  | Presser Foot for double strips (tube) for<br>reeding (A & A).....                                                                  | 3 00 |
| 26408  | 1224  | Presser Foot for double strips (tube) (A & A) ..                                                                                   | 2 25 |
| 26409  | —     | “ “ Plate for 26410.....                                                                                                           | 2 25 |
| 26410  | 1224  | “ “ for double strips (tube) hinged<br>(A & A).....                                                                                | 3 00 |
| 26411  | 1225  | Presser Foot (strip folding) for cording<br>(A & A).....                                                                           | 4 00 |
| *26412 | —     | Strip Folder for 26413.....                                                                                                        | 2 35 |
| 26413  | 1226  | “ “ 26412 with 18114 (A & A).....                                                                                                  | 2 50 |
| 26414  | 1225  | Presser Foot (strip folding) for opening<br>seams and inclosing folded edges (A & A) ..                                            | 5 75 |
| 26415  | 1225  | Presser Foot, strip folding (A & A).....                                                                                           | 3 50 |
| 26416  | 1225  | “ “ “ “ with guide for<br>opening seams (A & A).....                                                                               | 3 50 |
| 26417  | —     | Presser Foot Plate for 26418.....                                                                                                  | 3 50 |
| 26418  | 1225  | “ “ (strip folding) hinged, with<br>guide for opening seams (A & A).....                                                           | 4 25 |
| 27070  | 363   | Shaft Driving Pulley, 10-in. diam., grooved,<br>1 $\frac{3}{8}$ -in. bore, sectional, with two 597c, for<br>19264 and 27645.....   | 45   |
| 27302  | 1162  | Bobbin Winder Frame for 27651.....                                                                                                 | 15   |
| 27303  | 1220  | “ “ “ Spring for 27651.....                                                                                                        | 03   |
| 27303  | 1220  | “ “ Stop Latch Spring for 19260.....                                                                                               | 03   |
| 27306  | 1162  | “ “ Spool Pin for 27308.....                                                                                                       | 05   |
| 27307  | 1162  | “ “ “ Stand for 27308.....                                                                                                         | 10   |
| 27308  | 1162  | “ “ “ “ 27307 complete,<br>for 27588.....                                                                                          | 35   |
| 27473  | 1101  | Cone Pulley Centre Bearing for 27509.....                                                                                          | 08   |
| 27474  | 363   | Dress Guard (right hand) for 27644.....                                                                                            | 08   |
| 27476  | —     | Driving Pulley Friction Ring (leather) for<br>27630.....                                                                           | 05   |
| 27483  | 1101  | Lever Brake Spring for 27644.....                                                                                                  | 02   |
| 27485  | 1101  | “ Hinge Pin “ “ ..                                                                                                                 | 01   |
| 27497  | 1101  | “ Brake Strip (leather) for 27644.....                                                                                             | 02   |
| 27508  | 362   | Belt Guard for 27644.....                                                                                                          | 08   |
| 27509  | 362   | Cone Pulley, three speed, 2 $\frac{1}{2}$ -in., 3 $\frac{3}{8}$ -in. and<br>5 $\frac{1}{4}$ -in. diam., with 27473, for 27644..... | 60   |
| 27529  | 362   | Lever for 27644.....                                                                                                               | 25   |
| 27538  | 1162  | Bobbin Winder Spindle with 15072, for 27651 ..                                                                                     | 20   |
| 27552  | 1162  | “ “ Base for 27651.....                                                                                                            | 15   |
| 27553  | 1162  | “ “ Pulley for 27651.....                                                                                                          | 20   |
| 27555  | 1203  | Thread Unwinder Spool Pin for 27556.....                                                                                           | 08   |
| 27556  | —     | “ “ “ Rest 27583 with 138b<br>and two 27555, for 27562.....                                                                        | 40   |

| No.   | Plate | Name                                                                                     | Each |
|-------|-------|------------------------------------------------------------------------------------------|------|
| 27557 | 1163  | Thread Unwinder Spool Stand with 138b,<br>for 27562.....                                 | 25   |
| 27558 | 1163  | Thread Unwinder Spool Weight, 4-in. diam.,<br>with 27592, for 27562.....                 | 15   |
| 27559 | 1163  | Thread Unwinder Thread Guard for 27561.....                                              | 20   |
| 27560 | 1163  | “ “ “ “ Rod, 26-in.<br>long, for 27562.....                                              | 30   |
| 27561 | —     | Thread Unwinder Thread Guard 27559 with<br>330b, 449c and 27563, for 27562.....          | 50   |
| 27562 | 1163  | Thread Unwinder for two large spools com-<br>plete.....                                  | 1 60 |
| 27563 | 1163  | Thread Unwinder Thread Guard Hub for<br>27561.....                                       | 20   |
| 27583 | 1163  | Thread Unwinder Spool Rest for 27556.....                                                | 20   |
| 27587 | 1162  | Bobbin Winder Stop Latch for 27561.....                                                  | 10   |
| 27588 | —     | “ “ (swinging automatic, right<br>hand, complete, 27651 with 27308.....                  | 1 35 |
| 27592 | 1206  | Thread Unwinder Spool Weight Centre Pin<br>for 27558.....                                | 05   |
| 27600 | 1101  | Driving Pulley Hollow Stud Position Stud<br>for 27631.....                               | —    |
| 27630 | 362   | Driving Pulley, 6-in. diam., with 955c, 27476<br>and two 7958, for 27644.....            | 60   |
| 27631 | 1101  | Driving Pulley Hollow Stud with 27600, for<br>27644.....                                 | 15   |
| 27632 | —     | Driving Pulley Hollow Stud Wick for 27633.....                                           | 01   |
| 27633 | —     | “ “ “ “ Wire with<br>27632, for 27644.....                                               | 05   |
| 27634 | 362   | Frame for 27644.....                                                                     | 60   |
| 27635 | 362   | Oil Cup “ “ ..                                                                           | 25   |
| 27636 | 363   | Treadle “ 27642.....                                                                     | 30   |
| 27637 | 362   | “ Pitman Rod (lower) for 14233, 15130<br>and 27640.....                                  | 05   |
| 27638 | 1101  | Treadle Pitman Rod (lower) Spring for 14233,<br>15130 and 27640.....                     | 03   |
| 27639 | 362   | Treadle Pitman Rod (upper) for 27640.....                                                | 05   |
| 27640 | 362   | “ “ complete for 27643.....                                                              | 35   |
| 27642 | —     | “ complete for 14234, 15131 & 27643.....                                                 | 45   |
| 27643 | —     | “ & Pitman complete, Nos. 27640 & 27642 ..                                               | 80   |
| 27644 | —     | Transmitter complete for 27645.....                                                      | 3 00 |
| 27645 | —     | Under Driver, Lever Pressure, three speed,<br>complete, Nos. 27070, 27643 and 27644..... | 4 00 |
| 27651 | 1162  | Bobbin Winder for 27588.....                                                             | 1 00 |

PLATE 362—ONE-FOURTH SIZE




PLATE 363—ONE-FOURTH SIZE




PLATE 766 ONE-FOURTH SIZE




PLATE 768—ONE-HALF SIZE




PLATE 782—FULL SIZE




PLATE 783—FULL SIZE




PLATE 785—FULL SIZE




PLATE 786—FULL SIZE






PLATE 787—FULL SIZE


19183



19184



19254



19235






PLATE 788—FULL SIZE


19274



19283



19289



19344




PLATE 789—FULL SIZE




PLATE 790—FULL SIZE






PLATE 791—FULL SIZE


19329



19330



19396



19395






PLATE 792—FULL SIZE


19450



19451



19469



19468




PLATE 793—FULL SIZE




PLATE 794—FULL SIZE






PLATE 795—FULL SIZE


20055



20056



20069



20068






PLATE 796—FULL SIZE


20070



20071



20073



20072




PLATE 797—FULL SIZE




PLATE 798—FULL SIZE




PLATE 799—FULL SIZE




PLATE 800—FULL SIZE






PLATE 801—FULL SIZE


20108



20109



20111



20110






PLATE 802—FULL SIZE

20121



20128



20122




PLATE 989—ONE-FOURTH SIZE




PLATE 1101—FULL SIZE




PLATE 1144—FULL SIZE




PLATE 1145—FULL SIZE




PLATE 1146—FULL SIZE




PLATE 1161—ONE-HALF SIZE




PLATE 1162—ONE-HALF SIZE




PLATE 1163—ONE-FOURTH SIZE




PLATE 1200—ONE-HALF SIZE




PLATE 1201—ONE-HALF SIZE




PLATE 1202—ONE-HALF SIZE.




PLATE 1203—ONE-HALF SIZE




PLATE 1204—ONE-HALF SIZE




PLATE 1205—ONE-HALF SIZE




PLATE 1206—FULL SIZE




PLATE 1207—FULL SIZE




PLATE 1208—FULL SIZE




PLATE 1209—FULL SIZE




PLATE 1210—FULL SIZE




PLATE 1211—FULL SIZE




PLATE 1212—FULL SIZE




PLATE 1213 FULL SIZE






PLATE 1214—FULL SIZE

19382



19380



19381






PLATE 1215—FULL SIZE

24014



24013



2533




PLATE 1216—FULL SIZE




PLATE 1217—FULL SIZE





PLATE 1218—FULL SIZE



END VIEW OF NEEDLE BARS,  
FOR No.44-33 MACHINE,  
SHOWING POSITION OF NEEDLE HOLES.




PLATE 1219—FULL SIZE




PLATE 1220—FULL SIZE




PLATE 1221—FULL SIZE




PLATE 1222—FULL SIZE




PLATE 1223—FULL SIZE




PLATE 1224—FULL SIZE




PLATE 1225—FULL SIZE




PLATE 1226—FULL SIZE




PLATE 1227—FULL SIZE




PLATE 1228—FULL SIZE




PLATE 1229--FULL SIZE




PLATE 1230—ONE-FOURTH SIZE




PLATE 1231—ONE-FOURTH SIZE

