







CLOTH DRILL KD-200L PARTS LIST

PART NO.	PARTS NAME	PART NO.	PARTS NAME	PART NO.	PARTS NAME
DM01 -1	Handle	DM27	Hollow Screw	DM52-1	Horizontal Level
DM02	Screw	DM28	Hollow Tube	DM53	Drill 1.6 or 2.0 mm
DM04-1	Rubber Collar	DM29	O-Ring	DM55	Label
DM05-1	Top Cover	DM30	Clamp Small	DM57	Screw
DM06	Condenser 110V or 220V	DM31	Guide Tube (specify Needle size)	DM58	Spring
DM07	Switch	DM32	Clamp Large	DM59	Spring Fixed Bar
DM08	Bearing	DM36	Screw	DM60	Spring Washer
DM09	Stator, 110V,220V	DM37	Spring Washer	DM61	Screw
DM10-1	Motor Housing	DM37-1	Washer	DM62	Screw
DM12	Screw	DM38	Heater Fixed Base	DM63	Screw
DM15	Rotor	DM40	Heater Assembly	DM64	Screw
DM16	Bearing	DM40 1	Heater 110V,220V	DM65	Screw
DM17-1	Lower Cover	DM41-1	Base Plate	DM66	Cable Clamp
DM18	Chuck	DM43	Nut	DM67	Screw
DM18-1	Chuck Wrench	DM46- 1	Fixing Plate	DM68-1	Variable Res,istor/PC Board
DM22	4P Connector	DM47	Acrylic Board	DM70	Sleeve
DM22-1	Power Cord	DM48	Screw	DM73	Nut
DM25	Spring	DM49	Tum Knob		
DM26	Telescopic Tube	DM50-1	Thermo Control Cover		